

SIEMENS



LMV37.4...

Basic unit with integrated air-fuel ratio control for forced draft burners

Basic Documentation

The LMV37.4... and this Basic Documentation are intended for OEMs which integrate the units in their products!

Software version
V03.10

CC1P7546en
01.12.2009

**Building Technologies
HVAC Products**

Supplementary documentation

User Documentation Modbus AZL2.....	A7541
Environmental Product Declaration LMV2... / LMV3.....	E7541
Installation and Operating Instructions PC Software ACS410	J7352
Product Range Overview LMV2... / LMV3.....	Q7541

Contents

1	Safety notes	12
1.1	Warning notes	12
1.2	Mounting notes	13
	– Note on mounting	13
1.3	Installation notes	14
1.4	Electrical connection of the LMV37.4	15
1.5	Electrical connection of flame detectors	16
1.6	Commissioning notes	16
	– Air-fuel ratio control system	16
	– Basic unit section	16
1.7	Setting and parameter setting notes	18
1.8	Standards and certificates	19
1.9	Service notes	19
1.10	Life cycle	19
1.11	Disposal notes	19
2	System make-up / function description	20
2.1	For Europe	20
2.2	For North America	20
2.3	General	21
3	Type summary	21
4	Technical Data	22
4.1	Basic unit LMV37.4	22
4.1.1	Terminal loading «Inputs»	22
4.1.2	Terminal loading «Outputs»	23
4.1.3	Analog output / power output X74.3	23
4.1.4	Cable lengths	24
4.1.5	Cross-sectional areas	24
4.2	Signal cable AGV50... from AZL2... → BCI	24
4.3	Environmental conditions	25
4.4	Flame detectors	26
4.4.1	Ionization probe	26
4.4.2	UV-Flame detectors QRA2... / QRA4.U / QRA10	27
4.4.3	Photoresistive detectors QRB	28
4.4.4	Blue-flame detectors QRC	28
5	Dimensions	29
5.1	LMV37.4	29
6	Basic unit	30
6.1	Description of inputs and outputs	30
	– Flame signal input and flame detector X10–05 and X10–06	30
6.2	Flame detectors	31
6.2.1	Loss of flame	32
6.2.2	Extraneous light	32

6.2.3	No flame at the end of safety time 1 (TSA1).....	32
6.2.4	Flame intensity	32
6.2.5	Supervision of flame detector	33
6.3	Digital inputs	34
6.3.1	Safety loop X3–04, terminals 1 and 2	34
6.3.2	(Burner flange) X3–03, terminals 1 and 2	35
6.3.3	Input for external controller (ON / OFF) X5–03, terminal 1.....	35
6.3.4	Inputs X5-03 terminal 2 and terminal 3 (Opening / Closing or stage 2 / stage 3)	35
6.3.5	Air pressure switch (APS) X3–02	36
6.3.6	Pressure switch valve proving gas (P LT) X9–04	37
6.3.7	Pressure switch-min-gas (Pmin) / -min-oil, start release gas X5–01.....	38
6.3.8	Setting the time for making the pressure switch test	39
6.3.9	Pressure switch-max-gas (Pmax) / or POC contact / max-oil, start release oil X5–02.....	40
6.3.10	Reset X8-04, terminal 1	42
6.4	Digital outputs.....	43
6.4.1	Output alarm, type No-SI X3–05, terminal 2	43
6.4.2	Fan motor contactor, type SI X3–05, terminal 1	43
6.4.3	Fan continuous purging X3–05, terminal 3	43
6.4.4	Output ignition (Z), type SI (IGNITION) X4–02.....	44
6.4.5	Outputs fuel valves, type SI (V1...V3 / PV) X8–02, X7-01, X7-02.....	45
6.4.6	Output safety valve (SV), type SI X6–03	45
6.4.7	Output for indication of operation X8-04, terminal 2	45
6.5	Program sequence	46
6.5.1	Time parameters.....	46
6.5.2	Valve proving.....	47
6.5.2.1.	Valve proving with separate pressure switch (P LT) X9-04.....	48
6.5.2.2.	Valve proving via pressure switch-min-gas X5-01	49
6.5.2.3.	Lockout phase (phase 00).....	49
6.5.2.4.	Safety phase (phase 01)	49
6.5.3	Special functions during the program sequence	50
6.5.3.1.	Reset / manual lockout	50
6.5.3.2.	Alarm upon start prevention	51
6.5.3.3.	Possible start preventions	52
6.5.3.4.	Repetition counter.....	53
6.5.3.5.	Start without prepurging (as per EN 676)	55
6.5.3.6.	Gas shortage program.....	55
6.5.3.7.	Program stop function	56
6.5.3.8.	Forced intermittent operation (<24 hours)	56
6.5.3.9.	Low-fire shutdown.....	56
6.5.3.10.	Continuous fan	57
6.5.3.11.	Test function for approval of burner – loss-of-flame test (TÜV test).....	58
6.6	Fuel trains (application examples).....	59
	– Gas direct ignition	59
	– (Operating mode 1, 7, 14, 19).....	59
	– Gas pilot ignition 1	59
	– (Operating mode 2, 8, 15, 20).....	59
	– Gas pilot ignition 2	59
	– (Operating mode 3, 9, 16, 21).....	59

	– Fuel valve control program.....	59
	– Light oil direct ignition, multistage.....	60
	– (Operating mode 5, 17).....	60
	– (Operating mode 5, 17).....	60
	– (Operating mode 6, 18).....	60
	– Light oil direct ignition, modulating.....	61
	– (Operating mode 4, 22).....	61
	– (Operating mode 4, 22).....	61
	– Fuel valve control program.....	61
	– Light oil direct ignition modulating with 2 fuel valves.....	62
	– (Operating mode 12).....	62
	– (Operating mode 12).....	62
	– Fuel valve control program.....	62
6.7	Sequence diagrams.....	63
6.7.1	Gas direct ignition «G mod», «G mod pneu».....	64
6.7.2	Gas pilot ignition 1 «Gp1 mod», «Gp1 mod pneu».....	65
6.7.3	Gas pilot ignition 2 «Gp2 mod», «Gp2 mod pneu».....	66
6.7.4	Light oil direct ignition «Lo mod», «Lo 2-stage», «Lo 3-stage».....	67
6.7.5	Legend to the sequence diagrams.....	68
7	Selection of operating mode.....	69
8	Connection to load controllers.....	71
8.1	Controller on contact X5-03, terminal 1.....	71
8.2	External load controller via contacts X5-03, terminal 2 / terminal 3.....	71
8.3	Load controller via building automation X92.....	74
8.4	Manual output.....	75
8.5	Output with curve settings.....	75
8.6	External load controller via analog input X64.1 / X64.2.....	76
	– Switching thresholds / minimum positioning step.....	76
8.6.1	Thresholds for modulating operation.....	76
8.6.2	Switching thresholds for 2-stage operation.....	76
8.7	Prioritization of power sources.....	77
8.7.1	Emergency operation with several load controllers.....	77
8.7.2	Manual control.....	77
9	Electronic air-fuel ratio control.....	78
9.1	General.....	78
9.2	Behavior outside operation.....	78
9.2.1	Running speed.....	78
9.2.2	No-load position.....	78
9.2.3	Prepurging.....	79
9.2.4	Ignition.....	79
9.2.5	Postpurging.....	79
9.3	Modulating operation.....	80
9.3.1	Definition of curves.....	80
9.3.2	Running speed / maximum curve slope.....	81
9.3.3	Entering the running position.....	81
9.3.4	Running position.....	81
9.3.5	Restriction of modulation range.....	82

9.3.6	Setting the minimum and maximum output	83
9.4	Multistage operation	84
9.4.1	Definition of curves	84
9.4.2	Running speed.....	84
9.4.3	Adjustment of output.....	85
9.4.4	Changing to the running position.....	85
9.4.5	Running position	85
9.4.6	Restriction of the modulation range.....	86
9.5	End of running position.....	86
9.6	Setting and parameter setting notes	87
10	Actuators X53 / X54	88
10.1	Function principle	88
10.2	Definition of angles	88
10.3	Referencing	89
10.3.1	Reference travel.....	90
10.4	Direction of rotation.....	92
10.5	Monitoring the positions	93
10.6	Changing the error detection band for monitoring the positions	94
10.7	Forced travel	94
10.8	Detection of open-circuit.....	94
10.9	Protection against actuator mixup	95
10.9.1	Proposal for implementation	95
11	Fan control.....	96
11.1	Function principle.....	96
11.2	Activating the VSD / PWM fan	96
11.3	VSD control X74.3	97
11.4	PWM fan control X64.3.....	97
11.5	Safe separation of mains voltage and protective extra low-voltage.....	97
11.6	Ramp time	98
	– For VSD operation.....	98
11.7	Acquisition of speed.....	99
11.7.1	Acquisition of speed with proximity switch	99
	– Speed input X74.4	99
11.7.2	Acquisition of speed with Hall generator.....	100
11.8	Speed control	101
11.9	Speed supervision	101
11.10	Parameterizing of the VSD.....	102
11.11	Standardization of speed.....	103
	– Automatic speed standardization	103
11.12	Control of fan motor with pneumatic air-fuel ratio control	105
11.13	EMC LMV37.4... – VSD.....	106
11.14	Description of the terminals.....	107
11.14.1	VSD.....	107
11.14.2	PWM fan	107

12	Power output X74.3	108
12.1	Safe separation of mains voltage and extra low-voltage	108
12.2	Modulating operation	108
12.3	2-stage operation	108
12.4	3-stage operation	109
13	Fuel meter input X75.1 / X75.2	110
13.1	Configuration of fuel meter.....	110
13.1.1	Types of fuel meters	110
13.1.2	Configuration of pulses per volume unit.....	110
13.1.3	Reading and resetting the meter readings.....	110
13.2	Fuel throughput	111
13.2.1	Configuration	111
13.2.2	Reading out the fuel throughput.....	111
14	Inputs and outputs	112
15	Special feature: Identification of burner (ID)	113
16	Connection to superposed systems	113
16.1	General and functions of building automation system	113
16.2	Modbus	115
17	PC software ACS410	116
18	Error history	117
18.1	Error classes.....	117
18.2	Make-up of error history	118
	– Deleting the error history	118
19	Lifecycle function	118
20	Safety notes for use of the AZL2	119
21	Operating the AZL2... unit	120
21.1	Description of the unit / display and buttons	120
21.2	Meaning of symbols on the display.....	121
21.3	Brightness of the display	121
21.4	Special functions	122
21.4.1	Manual lockout	122
21.4.2	Manual control (manual request for output)	122
21.5	Timeout for menu operation	123
21.6	Backup / restore	124
21.6.1	Backup	125
21.6.2	Restore	127
22	Operation of basic unit via AZL2	129
22.1	Normal display.....	129
22.1.1	Display in standby mode	129
22.1.2	Display during startup / shutdown.....	129
22.1.2.1.	Display of program phases.....	129

22.1.2.2.	Display of program phase with remaining running time until end of the phase is reached	129
22.1.2.3.	List of phase displays	130
22.1.3	Display of operating position	131
22.1.4	Fault status message, display of errors and info	132
22.1.4.1.	Display of errors (faults) with lockout	132
22.1.4.2.	Reset.....	132
22.1.4.3.	Activating info / service mode from lockout	132
22.1.4.4.	Error with safety shutdown.....	133
22.1.4.5.	General information	133
22.1.4.6.	Start prevention.....	133
22.1.4.7.	Safety loop.....	133
23	Menu-driven operation.....	134
23.1	Assignment of levels.....	134
24	Info level.....	135
24.1	Display of info level.....	136
24.2	Display of info values (examples).....	136
24.2.1	Identification date	136
24.2.2	Identification number	136
24.2.3	Identification of burner	137
24.2.4	Number of startups resettable.....	137
24.2.5	Total number of startups	138
24.2.6	End of the info level	138
25	Service level.....	139
25.1	Display of the service level.....	139
25.2	Display of service values (example).....	140
25.2.1	Number of faults.....	140
25.2.2	Error history	140
25.2.3	Intensity of flame	140
25.2.4	End of the service level	140
26	Parameter level.....	141
26.1	Entering the password.....	142
26.2	Entering the burner's identification	144
26.3	Changing the heating engineer's password.....	145
26.4	Changing the OEM's password	146
26.5	Use of the parameter level	146
26.6	Assignment of the parameter levels	147
26.7	Parameters without index, with direct display.....	148
26.7.1	Using the example of parameter 208: Program stop	148
26.8	Parameters without index, with no direct display (with parameters having a value range >5 digits)	150
26.8.1	Using the example of parameter 162: Operating hours resettable	150
26.9	Parameter with index, with direct display	152
26.9.1	Using the example of parameter 501: Non-flame positions fuel actuator ...	152
26.10	Parameters with index, with no direct display.....	154

26.10.1	Using the example of parameter 701: Errors.....	154
26.11	Air-fuel ratio curves – settings and commissioning	157
26.11.1	Initial commissioning.....	157
26.11.2	Setting curvepoints P0 and P9 for modulating mode («G mod», «Gp1 mod», «Gp2 mod» and «Lo mod»).....	160
26.11.3	Setting curvepoints P0 and P9 for «G mod pneu», «Gp1 mod pneu» and «Gp2 mod pneu»	162
26.11.4	Warm settings for modulating mode («G mod», «Gp1 mod», «Gp2 mod» and «Lo mod»).....	163
26.11.5	Warm settings for modulating mode («G mod pneu», «Gp1 mod pneu» and «Gp2 mod pneu»).....	168
26.11.6	Cold settings for «G mod», «Gp1 mod», «Gp2 mod» and «Lo mod»	168
26.11.7	Cold settings for «G mod pneu», «Gp1 mod pneu» and «Gp2 mod pneu»	168
26.11.8	Editing the curvepoints	169
26.11.9	Interpolating the curvepoints	170
26.11.10	Setting the curvepoints for multistage mode («Lo 2-stage» and «Lo 3-stage»).....	173
26.11.11	Warm settings for «Lo 2-stage» and «Lo 3-stage»	175
26.11.12	Cold settings for multistage mode («Lo 2-stage» and «Lo 3-stage»).....	179
27	Parameter list LMV37.4.....	180
28	Error code list.....	194
29	Revision history of basic unit LMV37.4.....	207
	– Software changes	207
30	List of figures.....	212

1 Safety notes

1.1 Warning notes



To avoid injury to persons, damage to property or the environment, the following warning notes must be observed!

LMV37.4... are safety devices! Do not open, interfere with or modify the units. Siemens does not assume responsibility for damage resulting from unauthorized interference!

The chapters covering the LMV37.4... contain additional warning notes which should also be observed when using the different unit versions!

After commissioning and after each service visit, check the flue gas values across the entire output range!

The present Basic Documentation describes a wide choice of applications and functions and shall serve as a guideline. The correct functioning of the units is to be checked and proven by function checks on a test rig or on the plant itself!

- All activities (mounting, installation and service work, etc.) must be performed by qualified staff
- Degree of protection IP40 as per DIN EN 60 529 for the basic unit must be ensured through adequate mounting by the burner or boiler manufacturer
- Before making any wiring changes in the connection area, completely isolate the plant from mains supply (all-polar disconnection). Ensure that the plant cannot be inadvertently switched on again and that it is indeed dead. If not disconnected, there is a risk of electric shock hazard
- Protection against electric shock hazard on the LMV37.4... and on all connected electrical components must be ensured through adequate mounting. In terms of design, stability and protection, the cover must conform to EN 60730
- After each activity (mounting, installation and service work, etc.), check to ensure that wiring is in an orderly state and that the parameters are correctly set
- Fall or shock can adversely affect the safety functions. Such units must not be put into operation even if they do not exhibit any damage
- When programming the air-fuel ratio control curves, the commissioning engineer is obliged to constantly watch the quality of the combustion process (e.g. by means of a flue gas analyzer) and, in the event of poor combustion values or dangerous conditions, take appropriate actions, e.g. by shutting down the system manually
- The following plug-on terminations carry FELV (Functional Extra Low Voltage) (also refer to section *Electrical connection of the LMV37.4...*) which means that they do not provide safe separation from mains voltage:
 - The BCI (X56) for the connecting cable of the AZL2... or the PC tool ACS410
 - COM (X92) for accessories, such as the OCI410...These plug-on terminations may be removed or replaced only when the plant is dead (all-polar disconnection)
- The connectors of the connecting cables for the LMV37.4... or other accessories, such as the OCI410... (plugged into the BCI), may only be removed or exchanged when the plant is shut down (all-polar disconnection), since the BCI interface does not provide safe separation from mains voltage
- The connections for the SQM3... or SQN1... actuators do not provide safe separation from mains voltage. Prior to connecting or changing one of these actuators, the plant must be shut down (all-polar disconnection)

To ensure safety and reliability of the LMV37.4... system, the following points must also be observed:

- Condensation and ingress of humidity must be avoided. Should such conditions occur, make sure that the unit is completely dry before switching on again!
- Static charges must be avoided since they can damage the unit's electronic components when touched.


Recommendation: Use ESD equipment

- If the unit fuse was blown due to overload or a short-circuit at the connection terminals, the LMV37.4... must be replaced since the switching contacts might have been damaged
- If error codes 95...98 appear during operation, this may be an indication of contact problems and the LMV37.4... should be replaced

1.2 Mounting notes

- Ensure that the relevant national safety regulations and standard notes are complied with
- In geographical areas where DIN regulations are in use, the requirements of VDE must be satisfied, especially DIN / VDE 0100, 0550 and DIN / VDE 0722
- The LMV37.4... basic unit must be secured with fixing screws M4 (UNC32) or M5 (UNC24), observing a maximum tightening torque of 1.8 Nm and using all 4 fixing points. The additional mounting surfaces on the housing are provided to improve mechanical stability. These must fully rest on the mounting surface to which the unit is secured. The flatness of that mounting surface must be within a tolerance band of 0.3 mm

Note on mounting



1.3 Installation notes

- Always run the high-voltage ignition cables separate from the unit and other cables while observing the greatest possible distances
- Ensure that the electrical wiring inside the boiler is in compliance with national and local safety regulations
- Mains power must always be supplied via *L* and *N*. This means that no potential differential must exist between the neutral conductor *N* and protective earth *PE*
- Phase and neutral conductor must not be interchanged (dangerous malfunctions, loss of protection against electric shock hazard, etc.)
- Make certain that strain relief of the connected cables is in compliance with the relevant standards (e.g. as per DIN EN 60 730 and DIN EN 60335)
- Ensure that spliced wires cannot get into contact with neighboring terminals. Use adequate ferrules
- Run the high-voltage ignition cable completely separate from all other cables
- The burner manufacturer must protect unused terminals of the LMV37.4... by fitting dummy plugs (exception: X64 (reserve) and X74)
- When making the wiring, the AC 120 V or AC 230 V section must be strictly separated from other voltage sections, thus ensuring protection against electric shock hazard. For more detailed information, refer to section *Electrical connection of the LMV37.4...*
- The connectors of the connecting cables for the LMV37.4... may only be removed or exchanged when the plant is turned off (all-polar disconnection), since the BCI interface does not provide safe separation from mains voltage
- AGV50... signal cable between LMV37.4... and AZL2...
Since the BCI carries FELV (refer to section *Electrical connection of the LMV37.4...*), the connection between LMV37.4... and AZL2... must be established via the AGV50... signal cable, or by ensuring compliance with the specification. The signal cable is specified for use under the burner hood. When using other types of signal cable that do not meet the specification requirements, safety against electric shock hazard is not necessarily ensured
- Do not lay the signal cable AGV50... from the LMV37.4... to the AZL2... together with other cables
- Service operation with a longer signal cable from LMV37.4...:
If a longer signal cable is required for service work for example (short-time usage, <24 hours), note that the above application under the burner hood no longer applies and, for this reason, the signal cable can be subjected to increased mechanical stress. In that case, use a reinforced signal cable
- Both the AGV50... signal cable and the AZL2... must be shipped and stored so that no damage due to dust and water can occur when the products are used in the plant
- To ensure protection against electric shock hazard, make certain that, prior to switching on power, the AGV50... signal cable is correctly connected to the AZL2...
- The AZL2... must be used in a dry and clean environment
- The mechanical coupling between the actuators and the controlling elements for fuel and air, or any other controlling elements, must be rigid

1.4 Electrical connection of the LMV37.4...

The LMV37.4... operates with the following low-voltages:

- SELV (Safety Extra Low-Voltage) and PELV (Protective Extra Low-Voltage) ensure protection against electric shock hazard
- FELV (Functional Extra Low Voltage) without safe separation offers no protection which, in the event of fault, would not exclude risks




Figure 1: Electrical connection



Note

SELV or PELV depends on the safety class of the connected components. In the case of PELV, the relevant component is connected to protective earth.

1.5 Electrical connection of flame detectors

It is important to achieve practically disturbance- and loss-free signal transmission:

- Never run the detector cables together with other cables
 - Line capacitance reduces the magnitude of the flame signal
 - Use a separate cable
- Observe the permissible detector cable lengths
- The mains-powered ionization probe is not protected against electric shock hazard. It must be protected against accidental contact
- Earth the burner in compliance with the relevant regulations; earthing the boiler alone does not suffice
- Locate the ignition electrode and the ionization probe such that the ignition spark cannot arc over to the ionization probe (risk of electrical overloads)

1.6 Commissioning notes

- When commissioning the unit, check **all safety functions**
- There is no absolute protection against incorrect use of the RASTx connectors. For this reason, prior to commissioning the plant, check the correct assignment of all connectors
- Electromagnetic emissions must be checked on an application-specific basis

After the plant has been installed and commissioned, the person responsible for the plant / heating engineer must **document** the parameterized values and settings (e.g. curve characteristics) used for air-fuel ratio control.

These data can be printed out with the help of the ACS410 PC software, for example, or must be written down.

This document must be kept in a safe place and checked by the expert.



Caution!

On the OEM level of the LMV37.4..., parameter settings other than those specified in the application standards can be made. For this reason, check whether the parameter settings made are in compliance with the relevant application standards (e.g. EN 298, EN 230, EN 676, EN 267, etc.), or whether the respective plant demands special approval!

Air-fuel ratio
control system

The selected setting values of fuel and combustion air must be assigned such that – while giving consideration to the combustion chamber / fuel pressure, temperature and combustion air pressure, as well as wear of actuators and controlling elements, etc. – correct operation with sufficient amounts of excess air is ensured across the burner's full output range for an extensive period of time (until the next regular inspection is due; also refer to section *Monitoring the positions*). This must be proven by the burner / boiler manufacturer by measuring the characteristic combustion process values. If the standardization process is repeated, the air-fuel ratio control system must be rechecked.

Basic unit section

Prior to commissioning the system, the following points must be checked:

- Parameterization of operating mode (e.g. «G mod», «Gp1 mod», «Lo mod», etc.) must accord with the type of burner used (refer to chapter *Selection of operating mode*)
- Correct assignment of the valves to the valve outputs of the LMV37.4...
- Correct setting of the time parameters, especially the safety and prepurge times
- Correct functioning of the flame detector in the event of loss of flame during operation (including the response time), with extraneous light, during the prepurge time and, when there is no establishment of flame, at the end of the safety time
- Activation of the valve proving function and determination of the correct leakage rate, if required by the application (refer to subsection *Valve proving*)

The functions of the following available or required input status signals must be checked:

- Air pressure
- Minimum gas pressure / maximum gas pressure or POC
- Gas pressure valve proving
- Minimum oil pressure and maximum oil pressure
- Safety loop (e.g. safety limiter)

Duties of the expert when making the approval tests

	Action	Check / response
a)	Burner startup with flame detector darkened	Lockout at the end of safety time 1 (TSA1)
b)	Burner startup with flame detector exposed to extraneous light, e.g. to incandescent light with detectors for visible radiation, quartz-halogen bulb or cigarette lighter flame with detectors for UV radiation	Lockout at prepurge time (t1)
c)	Simulation of loss of flame during operation. For that, darken the flame detector in the operating position and maintain that state	Lockout or restart, depending on the basic unit's configuration
d)	Check the plant's response time with loss of flame during operation. For that purpose, manually disconnect the fuel valves from power and check the time from this moment the basic unit requires to turn off power to the valve	Turning off power to the valves by the basic unit within the period of time permitted for the respective type of plant
e)	Check the safe operation of the burner while giving consideration to system tolerances	<p>System tolerances are the result of a number of factors, such as:</p> <ul style="list-style-type: none"> - Tolerances of actuators plus mechanical linkage to the controlling elements - Environmental conditions (temperature, air conditions) - Type of fuel (calorific value / pressure) - Type of supply air path and flue ways <p>Example of procedure for checking the burner's response to actuator tolerances:</p> <ul style="list-style-type: none"> - Approach a output point in programming mode (e.g. low-fire or high-fire) - Change the actuator's position against the optimum fuel-air ratio setting as can be expected in the case of tolerances - Check the flue gas values with a flue gas analyzer <p>Recommendation: Make this readjustment against the optimum fuel-air ratio setting for one actuator at a time!</p>

Further checks may be required, depending on the field of use and the relevant standards.

1.7 Setting and parameter setting notes

- When adjusting the electronic air-fuel ratio control system integrated in the LMV37.4..., allow for sufficient amounts of excess air since – over a period of time – the flue gas settings are affected by a number of factors (e.g. density of air, wear of actuators and controlling elements, etc.). For this reason, the flue gas values initially set must be checked at regular intervals
- To safeguard against inadvertent or unauthorized parameter transfer from the PC software to the basic unit, the OEM must assign an **individual burner identification** (ID) for each burner. Compliance with this regulation is mandatory to ensure that the LMV37.4... system prevents the transfer of parameter sets of some other plant (with inadequate and possibly dangerous parameter values) to the LMV37.4... system via the PC tool. In addition, the air-fuel ratio control parameters must be manually approached and the combustion values checked
- With the LMV37.4... system, it is to be noted that the unit's characteristics are determined primarily by the specific parameter settings rather than the type of unit. This means that, among other things, each time a plant is commissioned, the parameter settings must be checked and the LMV37.4... must not be transferred from one plant to another without adapting the parameter settings to the new plant
- When using the ACS410 PC software, the safety notes given in the relevant Installation and Operating Instructions (J7352) must also be observed
- A password protects the parameter level against unauthorized access. The OEM allocates individual passwords to the setting levels he can access. The default passwords used by Siemens must be changed by the OEM. These passwords are confidential and may only be given to persons authorized to access such setting levels
- The responsibility for setting the parameters lies with the person who – in accordance with his access rights – made changes to the respective setting level

In particular, the OEM (burner and / or boiler manufacturer) assumes responsibility for the correct parameter settings in compliance with the standards covering the specific applications (e.g. EN 676, EN 267, EN 1643, etc.).

1.8 Standards and certificates



Conformity to EEC directives
 - Electromagnetic compatibility EMC (immunity)
 - Directive for gas-fired appliances
 - Low-voltage directive
 - Directive for pressure devices

2004/108/EC
 90/396/EEC
 2006/95/EC
 97/23/EC



ISO 9001: 2000
 Cert. 00739



ISO 14001: 2004
 Cert. 38233



Type	
LMV37.400A1	---
LMV37.400A2	---
LMV37.420A1	x

- Identification code to EN230 / EN298, chapter 4

FT / M C L B B

1.9 Service notes

- If fuses are blown, the unit must be returned to Siemens (refer to section *Warning notes*)

1.10 Life cycle

Burner management system type LMV3... has a designed lifetime* of 250,000 burner startup cycles which, under normal operating conditions in heating mode, correspond to approx. 10 years of usage (starting from the production date given on the type field). This lifetime is based on the endurance tests specified in standard EN230 / EN298 and the table containing the relevant test documentation as published by the European Association of Component Manufacturers (Afecon) (www.afecor.org).

The designed lifetime is based on use of the basic unit according to the manufacturer's Basic documentation. After reaching the designed lifetime in terms of the number of burner startup cycles, or the respective time of usage, the basic unit is to be replaced by authorized personnel.

* The designed lifetime is not the warranty time specified in the Terms of Delivery

1.11 Disposal notes




The unit contains electrical and electronic components and must not be disposed of together with household waste. Local and currently valid legislation must be observed.

2 System make-up / function description

The LMV37.4... is a microprocessor-based burner management system with matching system components for the control and supervision of forced draft burners of medium to high capacity.

Integrated in the basic unit of the LMV37.4... are:

- Burner management system complete with valve proving system
- Electronic air-fuel ratio control system for a maximum of 2 SQM3... or SQN1... actuators
- Control VSD air fan
- Modbus interface



Example: Modulating gas burner

The system components (display and operating unit, actuators) are connected directly to the LMV37.4... basic unit. All safety-related digital inputs and outputs of the system are monitored by a contact feedback network.

2.1 For Europe

For intermittent operation in connection with the LMV37.4..., the ionization probe or the QRA..., QRB... or QRC... optical flame detector can be used. **Continuous operation is possible only when using an ionization probe.**

2.2 For North America

For intermittent operation could in connection with the LMV37.4..., the ionization probe or the optical flame detector QRA4... or QRB... can be used. **Continuous operation is possible only when using an ionization probe.**

2.3 General

The burner management system is operated and parameterized either via the AZL2... display and operating unit or with the help of the PC tool. The AZL2... with LCD and menu-driven operation facilitates straightforward use and targeted diagnostics. When making diagnostics, the display shows operating states, the type of error and the point in time the error occurred. Passwords protect the different parameter levels of the burner / boiler manufacturer and heating engineer against unauthorized access. There is also a COM port which can be accessed from a superposed system, such as a building automation and control system (BACS). A PC with ACS410 software can be connected via the BCI and OCI410... interface. Among other things, the ACS410 software affords convenient readout of settings and operating states, parameterization of the LMV37.4..., and trend recordings. The burner / boiler manufacturer can select from different types of fuel trains and make use of a wide choice of individual parameter settings (program times, configuration of inputs / outputs, etc.), enabling him to make optimum adaptations to the relevant application. The actuators are driven by stepper motors and can be positioned with high resolution. Specific features and actuator settings are defined by the LMV37.4... basic unit.

3 Type summary

Microprocessor-based basic unit for single-fuel burners of any capacity, electronic air-fuel ratio control, up to 2 actuators, integrated gas valve proving system

Product no.	Mains voltage	Parameter set	Product no. of flame detector
LMV37.400A1	AC 120 V	Europe	QRA2... / QRA4.U / QRA10... / QRB... / ION
LMV37.400A2	AC 230 V	Europe	QRA2... / QRA4.U / QRA10... / QRB... / QRC... / ION
LMV37.420A1	AC 120 V	North America	QRA4.U / QRB... / ION

4 Technical Data

4.1 Basic unit LMV37.4...

Mains voltage	
- LMV37.400A1, LMV37.420A1	AC 120 V -15 % / +10 %
- LMV37.400A2	AC 230 V -15 % / +10 %
Mains frequency	50 / 60 Hz \pm 6 %
Power consumption	<30 W (typically)
Safety class	I, with parts according to II and III to DIN EN 60730-1
Degree of protection	IP00

Note

The burner or boiler manufacturer must ensure degree of protection IP40 to DIN EN 529 for burner controls by adequate installation of the LMV37.4...

4.1.1 Terminal loading «Inputs»

• Perm. mains primary fuse (externally)	Max. 16 AT
• Unit fuse F1 (internally)	6.3 AT (DIN EN 60127 2 / 5)
• Mains supply: Input current depending on the operating state of the unit	
Undervoltage	
• Safety shutdown from operating position at mains voltage	
- LMV37.400A1, LMV37.420A1	Approx. AC 93 V
- LMV37.400A2	Approx. AC 186 V
• Restart on rise in mains voltage	
- LMV37.400A1, LMV37.420A1	Approx. AC 96 V
- LMV37.400A2	Approx. AC 195 V
Status inputs: Status inputs (with the exception of the safety loop) of the contact feedback network (CFN) are used for system supervision and require mains-related input voltage	
• Input safety loop	refer to «Terminal loading outputs»
• Input currents and input voltages	
- UeMax	UN +10 %
- UeMin	UN -15 %
- IeMax	1.5 mA peak
- IeMin	0.7 mA peak
• Contact material recommendation for external signal sources (LP, Pmin, Pmax, etc.)	Gold-plated silver contacts
• Transition / settling behavior / bounce	
- Perm. bounce time of contacts when switching on / off	Max. 50 ms (after the bounce time, the contact must stay closed or open)
• UN	
- LMV37.400A1, LMV37.420A1	AC 120 V
- LMV37.400A2	AC 230 V
• Voltage detection	
- On	
- LMV37.400A1, LMV37.420A1	AC 90...132 V
- LMV37.400A2	AC 180...253 V
- Off	
- LMV37.400A1, LMV37.420A1	<AC 40 V
- LMV37.400A2	<AC 80 V

4.1.2 Terminal loading «Outputs»

Total contact loading:

- | | |
|--|----------------------|
| • Nominal voltage | |
| - LMV37.400A1, LMV37.420A1 | AC 120 V, 50 / 60 Hz |
| - LMV37.400A2 | AC 230 V, 50 / 60 Hz |
| • Unit input current (safety loop) from: | Max. 5 A |
| - Fan motor contactor | |
| - Ignition transformer | |
| - Valves | |
| - Oil pump / magnetic clutch | |

Individual contact loading:

Fan motor contactor

- | | |
|----------------------------|--|
| • Nominal voltage | |
| - LMV37.400A1, LMV37.420A1 | AC 120 V, 50 / 60 Hz |
| - LMV37.400A2 | AC 230 V, 50 / 60 Hz |
| • Nominal current | |
| - LMV37.400A1, LMV37.420A1 | 2 A |
| - LMV37.400A2 | 1,6 A pilot duty load declaration to UL372 |
| • Power factor | $\text{Cos}\varphi > 0.4$ |

Alarm output

- | | |
|----------------------------|---------------------------|
| • Nominal voltage | |
| - LMV37.400A1, LMV37.420A1 | AC 120 V, 50 / 60 Hz |
| - LMV37.400A2 | AC 230 V, 50 / 60 Hz |
| • Nominal current | 1 A |
| • Load factor | $\text{Cos}\varphi > 0.4$ |

Ignition transformer

- | | |
|----------------------------|---|
| • Nominal voltage | |
| - LMV37.400A1, LMV37.420A1 | AC 120 V, 50 / 60 Hz |
| - LMV37.400A2 | AC 230 V, 50 / 60 Hz |
| • Nominal current | |
| - LMV37.400A1, LMV37.420A1 | 2 A |
| - LMV37.400A2 | 1.6 A pilot duty load declaration to UL372
or
250 VA ignition load declaration to UL372 |
| • Power factor | $\text{Cos}\varphi > 0.2$ |

Fuel valves

- | | |
|----------------------------|--|
| • Nominal voltage | |
| - LMV37.400A1, LMV37.420A1 | AC 120 V, 50 / 60 Hz |
| - LMV37.400A2 | AC 230 V, 50 / 60 Hz |
| • Nominal current | |
| - LMV37.400A1, LMV37.420A1 | 2 A |
| - LMV37.400A2 | 1.6 A pilot duty load declaration to UL372 |
| • Power factor | $\text{Cos}\varphi > 0.4$ |

Operation display

- | | |
|----------------------------|---------------------------|
| • Nominal voltage | |
| - LMV37.400A1, LMV37.420A1 | AC 120 V, 50 / 60 Hz |
| - LMV37.400A2 | AC 230 V, 50 / 60 Hz |
| • Nominal current | 0.5 A |
| • Power factor | $\text{Cos}\varphi > 0.4$ |

4.1.3 Analog output / power output X74.3

Accuracy of output voltage	$\pm 1\%$
----------------------------	-----------

4.1.4 Cable lengths

• Mains line AC 120 V / AC 230 V	Max. 100 m (100 pF/m)
• Display, BCI	For used under the burner cover or the control panel Max. 3 m (100 pF/m)
• Load controller (LR) X5-03	Max. 20 m (100 pF/m)
• Load controller X64 (24 mA)	Max. 20 m (100 pF/m)
• Safety loop / burner flange (total)	Max. 20 m (100 pF/m)
• External lockout reset button	Max. 20 m (100 pF/m)
• Other lines	Max. 3 m (100 pF/m)

Specification as per EN 60730-1

Type of shutdown or interruption of each circuit	
Shutdown with microswitch	1-pole
Mode of operation	Type 2 B

4.1.5 Cross-sectional areas

The cross-sectional areas of the mains power lines (L, N, and PE) and, if required, the safety loop (safety limit thermostat, water shortage, etc.) must be sized for nominal currents according to the selected external primary fuse. The cross-sectional areas of the other cables must be sized in accordance with the internal unit fuse (max. 6.3 AT).

Min. cross-sectional area	0.75 mm ² (single- or multi-core to VDE 0100)
---------------------------	---

Cable insulation must meet the relevant temperature requirements and environmental conditions.

Fuses used in the LMV37.4... basic unit - F1	6.3 AT DIN EN 60127 2 / 5
---	---------------------------

4.2 Signal cable AGV50... from AZL2... → BCI

Signal cable	Color white Unshielded Conductor 4 x 0,141 mm ² With RJ11 plug
Cable length - AGV50.100 - AGV50.300	1 m 3 m
Supplier	Reference: Hütter http://www.huetter.co.at/telefonkabel.htm Order number: on request
Location	Under the burner hood (arrangements for SKII EN 60730-1 additional required)

4.3 Environmental conditions

Storage	DIN EN 60721-3-1
Climatic conditions	Class 1K3
Mechanical conditions	Class 1M2
Temperature range	-20...+60 °C
Humidity	<95 % r.h.
Transport	DIN EN 60721-3-2
Climatic conditions	Class 2K2
Mechanical conditions	Class 2M2
Temperature range	-30...+60 °C
Humidity	<95 % r.h.
Operation	DIN EN 60721-3-3
Climatic conditions	Class 3K3
Mechanical conditions	Class 3M3
Temperature range	-20...+60 °C
Humidity	<95 % r.h.



Caution!
Condensation, formation of ice and ingress of water are not permitted!

4.4 Flame detectors

4.4.1 Ionization probe

For continuous operation!

No-load voltage at ION terminal (X10-05 terminal 2)	Approx. U_{Mains}
--	----------------------------



Caution!
Protect the ionization probe against electric shock hazard!

Short-circuit current	Max. AC 1 mA
Required detector current	Min. DC 4 μA , flame display approx. 30%
Possible detector current	Max. DC 16...40 μA , flame display approx. 100%
Max. perm. length of detector cable (laid separately)	3 m (wire-ground 100 pF/m)



Note

With increasing detector cable capacitance (cable length), the voltage at the ionization probe, and thus the detector current, drops. Long cable lengths plus very highly resistive flames might necessitate low-capacitance detector cables (e.g. ignition cable). In spite of technical measures taken in the circuitry aimed at compensating potential adverse effects of the ignition spark on the ionization current, it must be made certain that the minimum detector current required will already be reached during the ignition phase. If this is not the case, the connections on the primary side of the ignition transformer must be changed and / or the electrodes relocated.




Figure 2: Ionization input at AC 120 V / AC 230 V

4.4.2 UV-Flame detectors QRA2... / QRA4.U / QRA10...



Caution!

If flame detectors type QRA2... / QRA4.U / QRA10... are used for flame supervision with the LMV37.4..., it must be ensured that the basic unit is permanently connected to power (conforming to EN 230 / EN 298), thus enabling the system to detect flame detector failures during startup and shutdown.

For technical data, refer to Data Sheet N7712 UV flame detectors QRA2... / QRA10...!

For technical data, refer to Data Sheet N7711 UV flame detectors QRA4.U!

4.4.3 Photoresistive detectors QRB...

No-load voltage at QRB... terminal (X10-05 terminal 3)	Approx. DC 5 V
Max. perm. length of QRB... detector cable (laid separately)	3 m (wire – wire 100 pF/m)



Note

A detector resistance of $R_F < 500 \Omega$ is identified as a short-circuit and leads to safety shutdown in operation as if the flame had been lost.

For this reason, before considering the use of a highly sensitive photoresistive detector (QRB1B... or QRB3S), it should be checked whether this type of flame detector is really required! Increased line capacitance between QRB... connection and mains live wire L has an adverse effect on sensitivity and increases the risk of damaged flame detectors due to overvoltage. Always run detector cables separately!

Threshold value flame supervision QRB... with LMV37.4...

Start prevention (extraneous light) with R QRB	$< 400 \text{ k}\Omega$ Intensity $> 10\%$
Operation with R QRB	$< 230 \text{ k}\Omega$ Intensity $> 16\%$
Short-circuit detection with R QRB	$< 0.5 \text{ k}\Omega$




Figure 3: QRB... input at AC 120 V / AC 230 V

4.4.4 Blue-flame detectors QRC...

Check the flame intensity via AZL2...

For system specific reasons, the display by AZL2... of maximum intensity is limited to approx. 55 %.



Caution!

QRC... flame detectors are only suited for operation at AC 230 V.

5 Dimensions

5.1 LMV37.4...

Dimensions in mm




Figure 4: LMV37.4...: Dimension

6 Basic unit

6.1 Description of inputs and outputs

This chapter covers the key features of the basic unit's inputs and outputs. For exact use of the inputs and the activation of outputs, refer to *Sequence diagrams*.

Flame signal input and flame detector X10-05 and X10-06




Figure 5: Flame signal input X10-05




Figure 6: Flame signal input X10-06

Connection choices:

- Ionization probe
- QRA2... / QRA10...
- QRA4.U
- QRB...
- QRC...

6.2 Flame detectors

- For display of the flame on the AZL2..., the following general conditions apply:
 - Display is subject to various component tolerances, which means that deviations of $\pm 10\%$ can occur
 - Note that, for physical reasons, there is no linear relationship between flame display and detector signal values

The LMV37.4... system can be used with different types of flame detectors. For the correct use of the flame detectors, refer to *Sequence diagrams*.

The flame detector used must be correctly parameterized.



Caution!
Only ionization probes are suited for continuous operation!

In the hardware of the LMV37.4..., the flame signals are subdivided into 2 groups (group 0 covering types the QRB... and QRC..., and group 1 covering ionization and the QRA...). The flame detector selection for gas is made via parameter 221, for oil via parameter 261.

No.	Parameter
221	Gas: Active detector flame evaluation 0 = QRB... / QRC... 1 = ION / QRA...
261	Oil: Active detector flame evaluation 0 = QRB... / QRC... 1 = ION / QRA...

6.2.1 Loss of flame

In the event of loss of flame, the unit initiates safety shutdown, followed by a restart, if required. A repetition counter can be used to select after how many losses of flame the unit shall initiate lockout (refer to subsection *Repetition counter*).

Error code	Diagnostic code	Meaning for the LMV37.4... system
7	0	Loss of flame

No.	Parameter
186	Software drop out delay time of flame signal (100 ms) Index = = QRB... / QRC... (0 = inactive, >1) Index 1 = ION / QRA... (0 = inactive, >3 - only 200 ms-steps)
240	Repetition limit loss of flame 1 = no repetition 2 = 1 repetition
280	Repetition limit loss of flame 1 = no repetition 2 = 1 repetition



Caution!

The response time of the flame detector leads to a prolongation of the second safety time (TSA2)! This must be taken into consideration when designing the burner!

6.2.2 Extraneous light

Extraneous light during standby (phase 12) leads to start prevention, followed by a re-start. Extraneous light during the prepurge phase leads to immediate lockout. If extraneous light occurs during the shutdown phase, the system switches to the safety phase.

One repetition is permitted. This means that if the error occurs again the next time the system is shut down, the unit initiates lockout.

Error code	Diagnostic code	Meaning for the LMV37.4... system
4	0	Extraneous light during startup
	1	Extraneous light during shutdown
	2	Extraneous light during startup – start prevention

6.2.3 No flame at the end of safety time 1 (TSA1)

If no flame has been established at the end of the first safety time, the unit initiates lockout.

Error code	Diagnostic code	Meaning for the LMV37.4... system
2	1	No flame at the end of safety time 1 (TSA1)
	2	No flame at the end of safety time 2 (TSA2)

6.2.4 Flame intensity

The flame's intensity can be displayed.
It is standardized from 0 to 100%.

No.	Parameter
954	Flame intensity

6.2.5 Supervision of flame detector

Error code	Diagnostic code	Meaning for the LMV37.4... system
93	3	Short-circuit of sensor

At the QRB... / QRC... flame detector's input, the LMV37.4... checks the detector for short-circuits in operation.

6.3 Digital inputs

6.3.1 Safety loop X3-04, terminals 1 and 2

Input for the safety loop. When any of the series-connected contacts included in the loop opens, power supply to the fuel valves, the fan and the ignition equipment is instantly cut.

The following contacts are included in the safety loop:

- External burner switch (ON / OFF)
- Safety limiter / safety pressure limiter (SL / SPL)
- External control thermostat and / or pressurestat, if required
- Water shortage switch



Note

- Pressure switch-max (Pmax) when using POC via X5-02




Figure 7: Safety loop X3-04

For diagnostics purposes, the contacts of the safety loop and the burner flange contact are combined for delivering the safety loop signal. If there is no such signal, the system initiates safety shutdown in any event.

If with *Load controller on*, there is no signal from the safety loop (start prevention), error code 22 is translated to text display **OFF S** (S = safety loop); the numerical value appears in the error history.

Error code	Diagnostic code	Meaning for the LMV37.4... system
22 OFF S	0	Safety loop / burner flange open

For the input, a repetition counter can be parameterized. Here, it is possible to set the number of errors that are permitted until lockout occurs (refer to subsection *Repetition counter*).

No.	Parameter
215	Repetition limit safety loop 1 = no repetition 2...15 = number of repetitions 16 = constant repetition

6.3.2 (Burner flange) X3-03, terminals 1 and 2

- End switch burner flange (component of safety loop)




Figure 8: Burner flange X3-03

For error diagnostics and parameters, refer to subsection *Safety loop*.

6.3.3 Input for external controller (ON / OFF) X5-03, terminal 1

When the external control loop is closed, the internal input message «Heat request» is generated.

A heat request exists when the external controller signal is pending and, depending on the configuration, a load controller calls for heat (refer to chapter *Connection of load controller*).

When there are no more requests for heat, the burner shuts down. The fuel valves are closed, either immediately when the timer has elapsed, or when the low-fire position is reached, depending on the parameterization (refer to section *End of running position*).



Note

Burner startup can take place only when this contact is closed.




Figure 9: Inputs for external load controller ON / OFF X5-03

6.3.4 Inputs X5-03 terminal 2 and terminal 3 (Opening / Closing or stage 2 / stage 3)

Inputs for connection of an external controller with contact outputs (refer to subsection *External load controller via contacts X5-03, terminals 2 and 3*).




Figure 10: Inputs external load controller Opening / Closing X5-03

6.3.5 Air pressure switch (APS) X3-02

Input for connection of an air pressure switch.

Air pressure is anticipated after the fan has been switched on. If there is no air pressure signal, the system initiates lockout.

The air pressure switch must have an NO contact.

If no air pressure switch is required (e.g. when firing on oil), a wire link to the fan output must be fitted (between X3-02, terminal 1, and X3-05, terminal 1).



Caution!

The OEM must check to see whether the burner can be operated without using an air pressure switch. This may necessitate a special approval, depending on the application.




Figure 11: Air pressure switch (APS) X3-02

Error code	Diagnostic code	Meaning for the LMV37.4... system
3	0	Air pressure off
	1	Air pressure on
	4	Air pressure on – start prevention

6.3.6 Pressure switch valve proving gas (P LT) X9-04

Input for the pressure switch valve proving (P LT) X9-04. The input is active only when operating on gas and when valve proving is activated (see program sequence).

No.	Parameter
241	Gas: Execution valve proving 0 = no valve proving 1 = valve proving on startup 2 = valve proving on shutdown 3 = valve proving on startup and shutdown




Figure 12: Pressure switch valve proving gas (P LT) X9-04

Pressure switch valve proving (P LT)

Input for connection the valve proving with a specific pressure switch. The input is active only when firing on gas and when the valve proving is activated.

Error code	Diagnostic code	Meaning for the LMV37.4... system
12	0	Fuel valve 1 (V1) leaking
	1	Fuel valve 2 (V2) leaking



Note

When using configuration *Valve proving via pressure switch-min-gas (Pmin)*, it is not possible to use the input for *Start release gas*.

6.3.7 Pressure switch-min-gas (Pmin) / -min-oil, start release gas X5-01

Input for connection of a pressure switch-min for gas or oil: If the plant does not require a pressure switch-min, a wire link between terminal 2 and terminal 3 must be fitted.

Pressure switch-min-gas

In all types of gas trains, the minimum gas pressure is expected from phase 22. If no gas pressure is detected after the maximum time (P214) has elapsed, the gas shortage program is started (refer to subsection *Gas shortage program*).




Figure 13: Pressure switch-min-gas (Pmin) / -min-oil X5-01



Caution!

The OEM must check to see whether the burner can be operated without using an air pressure switch-min. This may necessitate a special approval, depending on the application.

No.	Parameter
214	Max. time to start release

During the safety times (TSA1 / TSA2), the signal received from pressure switch-min is only assessed after a certain period of time has elapsed, in order to ignore the pressure shocks that occur the moment the valves open. The time to elapse for signal assessment can be parameterized.

No.	Parameter
229	Gas: Time to respond to pressure faults within safety time 1 (TSA1) and safety time 2 (TSA2)

If the gas pressure fails, at least safety shutdown is initiated.

Error code	Diagnostic code	Meaning for the LMV37.4... system
20	0	Pressure switch-min (Pmin) No min. gas / oil pressure

For the input, a repetition counter can be parameterized. It can be used to set the number of errors permitted until lockout occurs. The counter also impacts the gas shortage program (refer to subsection *Repetition counter*).

No.	Parameter
223	Repetition limit pressure switch-min-gas 1 = no repetition 2...15 = number of repetitions 16 = constant repetition

Start release gas

If, at the same time, the input is used as a start release input, e.g. for an air supply damper, it can be connected in series with the pressure switch.
When selecting *Valve proving via pressure switch-min* (P236), function „Start release gas“ is not supported.

Pressure switch-min-oil

In all types of oil train, the minimum oil pressure is expected from phase 38. If no oil pressure is detected after the maximum time (P217) has elapsed or if, subsequently, the oil pressure fails, the system initiates lockout.

No.	Parameter
217	Maximum waiting time for detecting a detector or pressure switch signal (e.g. home run, preignition)

Error code	Diagnostic code	Meaning for the LMV37.4... system
20	0	Pressure switch-min (Pmin) No min. gas / oil pressure

During the safety times (TSA1 / TSA2), the signal from pressure switch-min is only assessed after a certain period of time has elapsed in order to ignore the pressure shocks that occur the moment the valves open. The time to elapse for signal assessment can be parameterized.

No.	Parameter
269	Oil: Time to respond to pressure faults within safety time 1 (TSA1) and safety time 2 (TSA2)

6.3.8 Setting the time for making the pressure switch test

For pressure switch-min-oil, the point in time after which the evaluation is made can be set via parameter 276 (active from phase 38 or from the safety time (TSA)).

No.	Parameter
276	Oil. Pressure switch-min-input 0 = inactive 1 = active from phase 38 2 = active from the safety time (TSA)

6.3.9 Pressure switch-max-gas (Pmax) / or POC contact / max-oil, start release oil X5-02

Input for connection of a pressure switch-max for gas or oil: The pressure switch must have an NC contact, which means that the contact opens when the adjusted maximum pressure is exceeded. If the plant does not require a pressure switch-max, a wire link must be fitted between terminal 2 and terminal 3.



Caution!

The OEM must check to see whether the burner can be operated without using a pressure switch-max. This may necessitate a special approval, depending on the application.




Figure 14: Pressure switch-max-gas (Pmax) / -max-oil or POC X5-02

The connection can also be used as POC (Proof of Closure) (refer to *Sequence diagram*).

No.	Parameter
237	Gas: Pressure switch-max / POC input 0 = deactivated 1 = Pressure switch-max 2 = POC



Note

If the input is used for POC, pressure switch-max can be included in the safety loop. In that case, pressure switch-max must not be fitted between the valves, but after them.

Pressure switch-max-gas

In all types of gas trains, the maximum gas pressure is monitored from phase 40. If the maximum gas pressure is exceeded, the system initiates lockout.

Error code	Diagnostic code	Meaning for the LMV37.4... system
14	0	POC open
	1	POC closed
21	0	Pressure switch-max (Pmax): Max. gas pressure exceeded POC: POC open (software version \leq V02.00)
	1	POC closed (software version \leq V02.00)

During the safety times (TSA1 / TSA2), the signal from pressure switch-max is only assessed after a certain period time has elapsed in order to ignore the pressure shocks that occur the moment the valves open.

No.	Parameter
229	Gas: Time to respond to pressure faults within safety time 1 (TSA1) and safety time 2 (TSA2)

Pressure switch-max-oil

In all types of oil trains, the maximum oil pressure is monitored from phase 22. If the maximum oil pressure is exceeded after the maximum time (P214) has elapsed, or during the subsequent phases, the system initiates lockout.

No.	Parameter
214	Max. time start release

Error code	Diagnostic code	Meaning for the LMV37.4... system
14	0	POC open
	1	POC closed
21	0	Pressure switch-max (Pmax): Max. oil pressure exceeded POC: POC open (software version \leq V02.00)
	1	POC: closed (software version \leq V02.00)

During the safety times (TSA1 / TSA2), the signal from pressure switch-max is only assessed after a certain period of time has elapsed in order to ignore the pressure shocks that occur the moment the valves open.

No.	Parameter
269	Oil: Time to respond to pressure faults within safety time 1 (TSA1) and safety time 2 (TSA2)

The connection facility can also be used for POC (proof of closure) (see sequence diagram).

No.	Parameter
277	Oil: Pressure switch-max- / POC input 0 = inactive 1 = Pressure switch-max 2 = POC



Note

If the input is used for POC, pressure switch-max can be included in the safety loop. In that case, pressure switch-max must not be installed between the valves, but always downstream from them.

Start release oil

If the input is simultaneously used as a start release input, e.g. for an air supply damper, the latter can be connected in series with the pressure switch.

Parameters with POC functionality cannot be used as start release input.

6.3.10 Reset X8-04, terminal 1

Input for connection of a reset button. The basic unit can be reset or manually locked via this input (refer to subsection *Reset / manual locking*).



Figure 15: Reset X8-04

6.4 Digital outputs

Safety-related outputs, type SI

Using a contact feedback network (CFN), these contacts are read back by the micro-computers and checked for their correct positions.

Non-safety-related outputs, type No-SI

These outputs are not monitored by the CFN and, for this reason, can only be used for non-safety-related actuators, or actuators made safe in some other form (e.g. alarm).

6.4.1 Output alarm, type No-SI X3-05, terminal 2




Figure 16: Output alarm X3-05

Output for connection of an alarm lamp or horn.
The output is activated when the unit is in the lockout position (phase 00).
This output can also be used to indicate start prevention.

6.4.2 Fan motor contactor, type SI X3-05, terminal 1




Figure 17: Fan motor contactor X3-05

Output for control of a fan power contactor (200 VA). In accordance with the sequence diagrams, the fan is on in phase 22 (refer to *Sequence diagrams*).

6.4.3 Fan continuous purging X3-05, terminal 3




Figure 18: Fan continuous purging X3-05

If continuous purging is required, the fan motor contactor must be connected to fan continuous purging X3-05, terminal 3. This terminal is tapped behind the unit fuse and the safety loop (refer to subsection *Continuous fan*).

6.4.4 Output ignition (Z), type SI (IGNITION) X4-02




Figure 19: Output ignition (Z) X4-02

Output for the connection of ignition transformers or electronic ignition modules.

Gas

When firing on gas, ignition is switched on in phase 38 just before reaching safety time 1 (TSA1).

The preignition time in phase 38 can be parameterized.

No.	Parameter
226	Gas: Preignition time

Oil

When firing on oil, there is a choice of short preignition and long preignition (same as with gas).

No.	Parameter
281	Oil: Point in time oil is ignited 0 = short preignition (Ph38) 1 = long preignition (with fan) (Ph22)

When using long preignition, ignition is switched on in phase 22, together with the fan.

In the case of short preignition, the preignition time can be parameterized.

No.	Parameter
266	Oil: Preignition time

6.4.5 Outputs fuel valves, type SI (V1...V3 / PV) X8-02, X7-01, X7-02




Figure 20: Output fuel valve (V1) X8-02




Figure 21: Output fuel valve (V2) X7-01




Figure 22: Output fuel valve (V3) / pilot valve (PV) X7-02

Outputs for connection of the gas or oil valves, depending on the selected type of fuel train (refer to *Sequence diagrams*).

6.4.6 Output safety valve (SV), type SI X6-03




Figure 23: Output safety valve (SV) X6-03

Output for connection of an oil shutoff valve / oil connection valve or safety valve for liquefied gas. The output is connected parallel to output fan.

6.4.7 Output for indication of operation X8-04, terminal 2




Figure 24: Output for indication of operation X8-04

Output for connection for indication of operation.



Caution!
The output is connected parallel to the fuel valve (V1).

6.5 Program sequence

The program sequence is shown in the form of sequence diagrams (refer to section *Fuel trains*). Using a number of parameters, the program sequence can be adapted to the respective application.

6.5.1 Time parameters

Using a number of time parameters, the time characteristics of the different types of fuel trains can be matched to the requirements of the respective application.

No.	Parameter
211	Fan ramp up time
212	Max. time to low-fire
213	Waiting time home run
214	Max. time to start release
217	Max. waiting time for detecting a detector or pressure switch signal (e.g. home run, preignition)
225	Gas: Prepurge time
226	Gas: Preignition time
227	Gas: Safety time 1 (TSA1)
229	Gas: Time to respond to pressure faults within safety time 1 (TSA1) and safety time 2 (TSA2)
230	Gas: Interval 1
231	Gas: Safety time 2 (TSA2)
232	Gas: Interval 2
233	Gas: Afterburn time
234	Gas: Postpurge time (no extraneous light test)
242	Gas: Valve proving evacuation time
243	Gas: Valve proving time test atmospheric pressure
244	Gas: Valve proving filling time
245	Gas: Valve proving time test gas pressure
246	Gas: Gas shortage waiting time
248	Gas: Postpurge time (t3) (interruption if load controller (LR) ON)
265	Oil: Prepurge time
266	Oil: Preignition time
267	Oil: Safety time 1 (TSA1)
269	Oil: Time to respond to pressure faults within safety time 1 (TSA1) and safety time 2 (TSA2)
270	Oil: Interval 1
271	Oil: Safety time 2 (TSA2)
272	Oil: Interval 2
273	Oil: Afterburn time
274	Oil: Postpurge time (no extraneous light test)
284	Oil: Postpurge time (t3) (interruption if load controller (LR) ON)



Caution!

The OEM or the heating engineer is responsible for making certain that the times conform to the standards covering the respective type of plant.

6.5.2 Valve proving

Valve proving is only active when firing on gas. This is a valve proving designed to detect leaking gas valves and, if necessary, to prevent the valves from opening or ignition from being switched on. Lockout is initiated.

When performing valve proving, the gas valve on the burner side is opened first to bring the test space to atmospheric pressure. After closing the valve, the pressure in the test space must not exceed a certain level. Then, the gas valve on the mains side is opened to fill the gas pipe. After closing the valve, the gas pressure must not fall below a certain level.

Valve proving can be parameterized to take place on startup, shutdown, or on both. The type of valve proving can be selected via parameter 236.

Recommendation:
Perform valve proving on shutdown.

No.	Parameter
236	Gas: Pressure switch-min input 0 = inactive 1 = pressure switch-min (before fuel valve 1 (V1)) 2 = valve proving via pressure switch-min (between fuel valve 1 (V1) and fuel valve 2 (V2))
241	Gas: Execution valve proving 0 = no valve proving 1 = valve proving on startup 2 = valve proving on shutdown 3 = valve proving on startup and shutdown
242	Gas: Valve proving evacuation time
243	Gas: Valve proving time atmospheric pressure
244	Gas: Valve proving filling time
245	Gas: Valve proving time gas pressure



Caution!

If valve proving is parameterized to take place «on startup and shutdown», the gas valves must run through additional switching cycles. As a result, strain on the gas valves (wear) increases.



Caution!

The OEM must set the evacuation, filling and test times for atmospheric or mains pressure on every plant in compliance with the requirements of EN 1643.

It must be ensured that the 2 test times are correctly set. It is to be checked whether the gas required for the test may be fed into the combustion chamber (on the relevant application). The test times are safety-related. After a reset and in the case of aborted or prevented valve proving, the unit performs valve proving on the next startup (only when valve proving is activated). In the case of a valve proving, prepurging is active during the startup phase, even if it has been deactivated.

Examples of aborted valve proving:

When the safety loop or the start prevention input for gas (containing Pmin) opens during valve proving.

Valve proving – calculation of leakage rate

$$t_{\text{Test}} = \frac{(P_G - P_W) \cdot V \cdot 3600}{P_{\text{atm}} \cdot Q_{\text{Leck}}}$$

QLeck	in l / h	Leakage rate in liters per hour
PG	in mbar	Overpressure between the valves at the beginning of the test phase
PW	in mbar	Overpressure set on the pressure switch (normally 50% of the gas inlet pressure)
Patm	in mbar	Absolute air pressure (1013 mbar normal pressure)
V	in l	Volume between the valves (test volume) including valve volume and pilot pipe, if present (Gp1 mod)
tTest	in s	Test time

6.5.2.1. Valve proving with separate pressure switch (P LT) X9-04




Figure 25: Valve proving with separate pressure switch (P LT)

When performing valve proving, the gas valve on the burner side is opened first to bring the test space to atmospheric pressure. Then, the valve is closed whereupon the pressure in the test space must not exceed a certain level. Then, the gas valve on the mains side is opened to fill the gas pipe. When the valve is closed again, the gas pressure must not drop below a certain level.

t80	Evacuation (P242)
t81	Atmospheric test (P243)
t82	Filling (P244)
t83	Pressure test (P245)
V...	Fuel valve
GP	Gas pressure switch
■	Signal ON
▨	Signal OFF
▩	Permissible signal

6.5.2.2. Valve proving via pressure switch-min-gas X5-01




Figure 26: Valve proving via pressure switch-min-gas

When performing valve proving, the gas valve on the burner side is opened first to bring the test space to atmospheric pressure. Then, the valve is closed whereupon the pressure in the test space must not exceed a certain level. Then, the gas valve on the mains side is opened to fill the gas pipe. When the valve is closed again, the gas pressure must not drop below a certain level

t80	Evacuation (P242)
t81	Atmospheric test (P243)
t82	Filling (P244)
t83	Pressure test (P245)
V...	Fuel valve
GP	Gas pressure switch
■	Signal ON
▨	Signal OFF
▩	Permissible signal

When making the valve proving test via pressure switch-min-gas, the impact on the program sequence is as follows (see *Sequence diagram G*):

- a) Valve proving on startup
In place of sampling pressure switch-min-gas (gas shortage test) in phase 22, it is sampled during the time valve proving is performed at the end of the filling time.
- b) Valve proving on shutdown / deactivated
Pressure switch-min-gas is sampled at the end of preignition. For that purpose, a new phase 39 (Test *Pmin*) is introduced and evaluation of gas shortage is made at the end of the phase (duration of phase = filling time). In practice, this represents a *prolongation* of preignition by the filling time, if valve proving via pressure switch-min-gas was selected.

The valve proving test can only be made via pressure switch-min-gas, which must be fitted between the valves. This has an impact on the control sequence (see *Sequence diagram*). Valve proving is still activated via parameter 241.

6.5.2.3. Lockout phase (phase 00)

The relays of the fuel valves and the safety relay (fan) are de-energized, the alarm relay is energized and lockout takes place. This means that phase 00 can only be quit via a manual reset. The time of phase 00 is unlimited.

6.5.2.4. Safety phase (phase 01)

The safety phase is an intermediate phase which is completed prior to triggering lockout. The relays of the fuel valves and the safety relay (fan) are de-energized, but lockout does not yet take place. The alarm relay is not yet activated. If possible or permitted, safety checks or repetition counter checks are made whose results decide on the transition to *Lockout phase* or *Standby*. The duration of the safety phase is dynamic (depending in the extent of testing), the maximum time being 30 seconds.

This process is aimed primarily at avoiding unwanted lockouts, e.g. resulting from EMC problems.

6.5.3 Special functions during the program sequence

6.5.3.1. Reset / manual lockout

The system can be manually locked by simultaneously pressing the **InFo** button and **any other button** on the AZL2... This function enables the operator to lock the system from any of the operating levels or, in other words, to trigger non-volatile lockout. Due to the system's structure, this does not represent an emergency off function.

When making a reset, the following actions are carried out:

- The alarm relay and the fault display are switched off
- The lockout position is canceled
- The unit makes a reset and then changes to standby

There are 3 choices to reset the system.

1. Resetting on the AZL2... display and operating unit

If the unit is in the lockout position, a reset can be made by pressing the **InFo** button for 1...3 seconds. The function is available only when the unit is in the lockout position. Longer or shorter pushes on the button do not produce a reset so that the system maintains the lockout position.

Error code	Diagnostic code	Meaning for the LMV37.4... system
167	2	Manual lockout by AZL2...

2. Resetting by pressing the button at the «Reset» connection terminal on the LMV37.4... basic unit (X8-04, terminal 1)


If the unit is in the lockout position, a reset can be made by pressing the button for 1...3 seconds. Longer or shorter pushes on the button are ignored so that the system maintains the lockout position.

If the unit is **not** in the lockout position and the reset button is pressed for 1...6 seconds, a change to the lockout position takes place.


If this response is not desirable, it is possible to tap the supply for the reset button from the alarm output, thus achieving the same response as described above under 1.

Error code	Diagnostic code	Meaning for the LMV37.4... system
167	1	Manual lockout by contact

Without manual lockout



With manual lockout



3. Resetting via the PC tool

Refer to the documentation on the PC tool (J7352).

Error code	Diagnostic code	Meaning for the LMV37.4... system
167	3	Manual lockout by PC tool

6.5.3.2. Alarm upon start prevention

If start prevention occurs, the display of the AZL2... shows it.

Start prevention takes place only when a heat request is delivered **and** one of the startup criteria is not fulfilled.

The period of time to elapse from start prevention to display on the AZL2... is set to a fixed value of 5 seconds.

In addition, it is possible to indicate start preventions via the alarm output. This function can be activated per parameter.

No.	Parameter
210	Alarm in the event of start prevention 0 = deactivated 1 = activated

If «Alarm in the event of start prevention» is activated via the alarm relay, start prevention and lockout can only be distinguished via the display on the AZL2... Start preventions are displayed as **Err:**, lockouts as **Loc:**.



Note

If reset contact X8-04, terminal 1, is activated in the event of start prevention, the unit is manually locked. The period of time from occurrence of start prevention to indication by the alarm contact equals the time to the display on the AZL2...

6.5.3.3. Possible start preventions

Within the normal display, error code 201 is translated to text display **OFF UPr** (UPr = unprogrammiert = not programmed); the numerical value appears in the error history.

Error code	Diagnostic code	Meaning for the LMV37.4... system
201 OFF UPr	1	No operating mode selected
	2...3	No fuel train defined
	4...7	No curve defined
	8...15	Standardized speed undefined
	16...31	Backup / restore was not possible
		<u>Other start preventions:</u>
3	4	Air pressure on – start prevention
4	2	Extraneous light during startup – start prevention
14	64	POC open – prevention of startup
21	64	POC open – prevention of startup (software version ≤V02.00)
22 OFF S	0	Safety loop / burner flange open
83	#	Speed error VSD
97	#	Error relay supervision
	0	Safety relay contacts have welded or external power supply fed to safety relay

No.	Parameter
642	Standardized speed Index 0 = speed 1 Index 1 = speed 2 (internal supervision)
935	Absolute speed
936	Standardized speed

6.5.3.4. Repetition counter

Repetition counters are available for different types of errors. They are used to set the number of errors that are permitted until lockout occurs. The last error initiates lockout. When setting the number of errors to 3, for example, a repetition (restart) takes place after the first 3 errors, and after the third error, the system initiates lockout.



Note
Setting 16 means an infinite number of repetitions = no lockout.

Functions with adjustable repetition counter

No.	Parameter
215	Repetition limit safety loop 1 = no repetition 2...15 = number of repetitions 16 = constant repetition
223	Repetition limit pressure switch-min gas 1 = no repetition 2...15 = number of repetitions 16 = constant repetition Recharging time: After the <i>Operation</i> phase
240 280	Repetition limit loss of flame 1 = no repetition 2 = 1 repetition Recharging time: After the <i>Operation</i> phase Parameter assignment: 240 Gas / fuel 0 280 Oil / fuel 0

Error code	Diagnostic code	Meaning for the LMV37.4... system
7	0	Loss of flame
20	0	Pressure switch-min (Pmin) No min. gas / oil pressure
22 OFF S	0	Safety loop / burner flange open

If the adjustable repetition counter limits are changed, the actual counter is recharged only when the associated recharging time is reached: After power-on or after a reset.



Note
If immediate recharging shall be enforced, the basic unit can be manually locked and then reset.

Functions with fixed repetition counters

These counters cannot be set.

Meaning	Settings	
	Unit	Basic setting
Number of repetitions in the event of error: - Speed standardization VSD - Speed error - Referencing error actuator - Positioning error actuator Recharging time: - End of <i>Shutdown</i> phase	---	3
Number of repetitions in the event of error: - Relay - Relay control Recharging time: - End of <i>Operation</i> phase	---	2
Number of repetitions in the event of internal errors Recharging time: - After 24 hours of operation	---	5

Error code	Diagnostic code	Meaning
82	#	Error during speed standardization of the VSD
83	#	Speed error VSD
85	#	Referencing error of an actuator
86	#	Error fuel actuator
87	#	Error air actuator
95...98	#	Error relay supervision
99...100	#	Internal error relay control

6.5.3.5. Start without prepurging (as per EN 676)

When using valve proving and 2 fuel valves of class A, prepurging is not required (conforming to EN 676).

Prepurging can be deactivated per parameter.

No.	Parameter
222	Gas: Prepurging 0 = deactivated 1 = activated

When prepurging is activated, it is performed in accordance with the adjusted prepurge time.

If not activated, it is nevertheless performed if one or several of the following conditions apply:

- Alterable lockout position
- After an off time of >24 hours
- In the event of a power failure (power-on)
- In the event of shutdown due to an interruption of gas supply (safety shutdown)

No.	Parameter
225	Gas: Prepurge time

6.5.3.6. Gas shortage program

Valve proving via pressure switch-min-gas (P236 = 2)

As gas pressure switch-min-gas is located between the valves, the gas shortage test cannot be made in phase 22. Instead, when performing valve proving on startup, the gas shortage test is performed at the end of the filling time (end of phase 82). Without valve proving on startup, the gas shortage test is made directly before safety time 1 commences (end of phase 39).

Standard valve proving (P236 = 1)

If the gas pressure is too low, startup is aborted in phase 22.

No.	Parameter
246	Gas: Gas shortage waiting time

If gas shortage occurs with the last of the parameterized number of start attempts, the system initiates lockout.

No.	Parameter
223	Repetition limit pressure switch-min-gas 1 = no repetition 2...15 = number of repetitions 16 = constant repetition

In that case, the system with gas shortage program makes a selectable number of start attempts until lockout occurs. The waiting time from one start attempt to the next is doubled each time, starting from a waiting time that can be parameterized.

6.5.3.7. Program stop function

To simplify the burner settings in connection with commissioning and service work, the program sequence of the LMV37.4... can be stopped at the following positions:


- | | |
|------------------------------------|----|
| 1) Air damper in prepurge position | 24 |
| 2) Ignition position | 36 |
| 3) Interval 1 | 44 |
| 4) Interval 2 | 52 |

The program stops are integrated in the setting sequence when the plant is commissioned (refer to chapter *Air-fuel ratio control settings*).

After the initial settings, program stops can be activated on the parameter level.

No.	Parameter
208	Program stop 0 = deactivated 1 = PrePurgP (Ph24) 2 = IgnitPos (Ph36) 3 = Interv1 (Ph44) 4 = Interv2 (Ph52)

The program stop function is maintained until manually deactivated. If the system halts at one of the program stops, a message appears on the display of the AZL2...



Example: *c:204* alternating with *d:24* corresponds to a program stop in the prepurge position.

Figure 27: Message in the case of program stop

6.5.3.8. Forced intermittent operation (<24 hours)

When forced intermittent operation is activated, the unit shuts down for a moment after 23 hours and 45 min of uninterrupted operation.

Forced intermittent operation is a standard feature.

No.	Parameter
239	Gas: Forced intermittent operation 0 = deactivated 1 = activated
279	Oil: Forced intermittent operation 0 = deactivated 1 = activated

6.5.3.9. Low-fire shutdown

To prevent the boiler from being shut down under full or nearly full output conditions, electronic air-fuel ratio control can run the burner to the low-fire position first, when there is no more heat request (refer to section *End of running position*).

6.5.3.10. Continuous fan

For burners that can be damaged by heat (e.g. several burners using the same combustion chamber), continuous purging may be required. In that case, the fan operates in all phases.

For that purpose, the fan motor contactor is to be connected to X3-05, terminal 3, tapped after the unit fuse and the safety loop.

For checking the air pressure switch, a pressure switch relief valve must be connected to fan motor contactor X3-05, terminal 1. When output X3-05, terminal 1, is activated, the relief valve diverts the fan pressure to the air pressure switch and, when deactivated, ensures that no pressure is fed to the switch.

Example:




Figure 28: Continuous fan

6.5.3.11. Test function for approval of burner – loss-of-flame test (TÜV test)

The purpose of this test is to verify the detection time required in the event of loss of flame when applying for burner approval. When starting the test, the fuel valves are shut to determine the period of time (resolution of 0.2 seconds) until the basic unit detects loss of flame.

Procedure:

- Determine the burner output at which the test shall be made using parameter 133 (fuel 0) or parameter 134 (fuel 1). If these parameters are not used, the test is carried out at the current output of the system
- Start the test by entering value 1 for parameter 124.
If the burner's output was defined for the test (parameter 133 or 134), the system runs to that output first. To implement this functionality, the default value of parameter 121 (manual output) is used. This cancels any manual output that was previously active
- Now, the LMV37.4... shuts the fuel valves, producing loss of flame
- The evaluation is made by the basic unit by measuring the period of time the system requires from fuel valve shutdown until loss of flame is detected.
Then, the required time is displayed in the form of diagnostic code C:7 (loss of flame)

The resolution is 0.2 seconds.

Example

When the display reads C:7 D:10, the time required from valve shutdown to detection of loss of flame is 2 seconds (D:10 means $10 \times 0.2 = 2$ seconds).


When the test is successfully completed, parameter 124 is reset to 0. If unsuccessful, a negative value is delivered for diagnostic purposes and error code 150 is entered.

- 1 = invalid phase (test only possible in phase 60) – display reads C:150 D: 1
- 2 = default output < minimum output – display reads C:150 D:2
- 3 = default output > maximum output – display reads C:150 D:3
- 4 = manual abortion (no error, start variable was manually reset to 0) – display reads C:150 D:4
- 5 = timeout during TÜV test (no loss of flame after shutdown of valves within 50 seconds) – lockout C:150 D:5


Previously set output values at which the test shall be made (parameter 133 or 134) remain stored.

6.6 Fuel trains (application examples)


Gas direct ignition
(Operating mode 1, 7, 14, 19)




Gas pilot ignition 1
(Operating mode 2, 8, 15, 20)



Gas pilot ignition 2
(Operating mode 3, 9, 16, 21)



Fuel valve control program Gas (always modulate)




Legend for fuel trains:

- *) Not used
- 1) Series connection of two DC 115 V valves (each requiring approx. 25 VA control power)
- LO Light oil
- No Normally Open
- P LT Valve proving
- Pmax Pressure switch-max
- Pmin Pressure switch-min
- PV Pilot valve
- SA Actuator
- SV Safety valve (outside the building)
- TSA... Safety time
- V Fuel valve


Light oil direct ignition,
multistage
(Operating mode 5, 17)

1-stage burner




2-stage burner

(Operating mode 5, 17)




3-stage burner

(Operating mode 6, 18)




Light oil direct ignition,
modulating
(Operating mode 4, 22)

Modulating burner (without shutdown facility for adjustable head)




(Operating mode 4, 22)

Modulating burner (with shutdown facility for adjustable head)



Fuel valve control program


Light oil (transformer direct ignition)



Light oil direct ignition
modulating with 2 fuel valves


(Operating mode 12)

Modulating burner (without shutdown facility for adjustable head)



Modulating burner (with shutdown facility for adjustable head)

(Operating mode 12)



Fuel valve control program

Light oil (transformer direct ignition)





Bild 311e/0309

6.7 Sequence diagrams

The phase numbers given in the diagram can be read from the following process data:

No.	Parameter
961	Phase (state of external module and display)

6.7.3 Gas pilot ignition 2 «Gp2 mod», «Gp2 mod pneu»



310 252e/ 2C9

Figure 31: Program for gas pilot ignition (Gp2)

6.7.4 Light oil direct ignition «Lo mod», «Lo 2-stage», «Lo 3-stage»




Figure 32: Program for light oil (LO)

6.7.5 Legend to the sequence diagrams

Valve proving takes place depending on the parameter:
Between phase 62 and phase 70 or / and between phase 24 and phase 30

- 1) Parameter: Short / long preignition time for oil only
Short / long oil pumps – switch-on time – time
- 2) Only with valve proving on startup
- 3) Parameter: With / without alarm in the event of start prevention
- 4) In the event of an erroneous signal on startup, followed by phase 10, otherwise phase 70
- 5) 28 s = maximum time safety phase, followed by lockout
- 6) 5 s = time between occurrence of start prevention and signaling
- 7) Only with valve proving on startup (valve proving via pressure switch-min)
- 8) Only without valve proving on startup (valve proving via pressure switch-min)
- 9) Inverse logic with valve proving via pressure switch-min
- 10) Parameter: Oil pressure min input
1 = active from phase 38
2 = active from safety time
- 11) Only with fuel train Lo and 2 fuel valves
- 12) Parameter 223: Repetition limitation pressure switch-min-gas in connection with gas shortage
program parameter 246 (phase 90)
- 13) 30 s = max. drop-in / response time for air pressure switch

Assignment of times:

t1	Prepurge time
t8	Postpurge time
t13	Permissible afterburn time
t44	Interval 1 gas / oil
t52	Interval 2 gas / oil
TSA1	Safety time 1 gas / oil
TSA2	Safety time 2 gas / oil



Permissible position range



In standby: The actuator can be moved within the permissible position range, but is always driven to the no-load position. Phase changes necessitate the no-load position.

0°	Position as supplied (0°)
90°	Actuator fully open (90°)

AL	Alarm
FS	Flame signal
KL	Low-fire position
LK	Valve proving
LP	Air pressure switch
M	Fan motor
N	Postpurge position / postpurging
P LT	Valve proving (pressure switch)
Pmin	Pressure switch-min
Pmax	Pressure switch-max
POC	Proof Of Closure
PV	Pilot valve
R	Control thermostat or pressurestat
SA...	Actuator
SA-R	No-load position
SA-V	High-fire position
SA-Z	Ignition position
SB	Safety limiter
SK	Safety loop
SV	Safety valve
V	High-fire position
V...	Fuel valve
Z	Ignition transformer



Signal ON



Signal OFF



Permissible signal

7 Selection of operating mode

To facilitate straightforward adaptation of the LMV37.4... to different types of burners, the system offers automatic configuration of the operating mode. This means that – derived from parameter 201 – the most important settings relating to the operating mode are made automatically. Very often in that case, the only manual settings to be made are those for the air-fuel ratio control system. After selection of the operating mode, parameters that are not required will be hidden (e.g. oil parameters when firing on gas).

No.	Parameter
201	Burner operating mode (fuel train, modulating / multistage, actuators, etc.) -- = undefined (delete curves) 1 = G mod 2 = Gp1 mod 3 = Gp2 mod 4 = Lo mod 5 = Lo 2-stage 6 = Lo 3-stage 7 = G mod pneu 8 = Gp1 mod pneu 9 = Gp2 mod pneu 10 = LoGp mod 11 = LoGp 2-stage 12 = Lo mod 2 fuel valves 13 = LoGp mod 2 fuel valves 14 = G mod pneu without actuator 15 = Gp1 mod pneu without actuator 16 = Gp2 mod pneu without actuator 17 = Lo 2-stufig without actuator 18 = Lo 3-stufig without actuator 19 = G mod only gas actuator 20 = Gp1 mod only gas actuator 21 = Gp2 mod only gas actuator 22 = Lo mod only oil actuator

Operating mode P201	Fuel train	Air-fuel ratio control	Fuel actuator	Air actuator	Feedback signal VSD	Description
1	G mod	Modulating electronic	x	x	x	Gas direct ignition, modulating electronic air-fuel ratio control Optional with VSD with speed feedback signal
2	Gp1 mod	Modulating electronic	x	x	x	Gas pilot ignition 1, modulating electronic air-fuel ratio control Optional with VSD with speed feedback signal
3	Gp2 mod	Modulating electronic	x	x	x	Gas pilot ignition 2, modulating electronic air-fuel ratio control Optional with VSD with speed feedback signal
4	Lo mod	Modulating electronic	x	x	x	Oil direct ignition, modulating electronic air-fuel ratio control Optional with VSD with speed feedback signal
5	Lo 2-stage	2-stage		x	x	Oil direct ignition, electronic 2-stage air-fuel ratio control Optional with VSD with speed feedback signal
6	Lo 3-stage	3-stage		x	x	Oil direct ignition, electronic 3-stage air-fuel ratio control Optional with VSD with speed feedback signal
7	G mod pneu	Modulating pneumatic		x		Gas direct ignition, modulating pneumatic air-fuel ratio control Optional with VSD without speed feedback signal
8	Gp1 mod pneu	Modulating pneumatic		x		Gas pilot ignition 1, modulating pneumatic air-fuel ratio control Optional with VSD without speed feedback signal
9	Gp2 mod pneu	Modulating pneumatic		x		Gas pilot ignition 2, modulating pneumatic air-fuel ratio control Optional with VSD without speed feedback signal
10	Lo Gp mod	Modulating electronic	x	x	x	Oil pilot ignition, modulating electronic air-fuel ratio control Optional with VSD with speed feedback signal
11	Lo Gp 2-stage	2-stage		x	x	Oil pilot ignition, electronic 2-stage air-fuel ratio control. Optional with VSD with speed feedback signal
12	Lo mod 2V	Modulating electronic	x	x	x	Oil direct ignition, two fuel valves, modulating electronic air-fuel ratio control. Optional with VSD with speed feedback signal
13	Lo Gp mod 2V	Modulating electronic	x	x	x	Oil pilot ignition, two fuel valves, modulating electronic air-fuel ratio control. Optional with VSD with speed feedback signal
14	G mod	Modulating pneumatic				Gas direct ignition, without actuators, modulating pneumatic air-fuel ratio control. Optional with VSD without speed feedback signal
15	Gp1 mod	Modulating pneumatic				Gas pilot ignition 1, without actuators, modulating pneumatic air-fuel ratio control. Optional with VSD without speed feedback signal
16	Gp2 mod pneu	Modulating pneumatic				Gas pilot ignition 2, without actuators, modulating pneumatic air-fuel ratio control. Optional with VSD without speed feedback signal
17	Lo 2-stage	2-stage			x	Oil direct ignition, without actuators, electronic 2-stage air-fuel ratio control. Optional with VSD with speed feedback signal
18	Lo 3-stage	3-stage			x	Oil direct ignition, without actuators, electronic 3-stage air-fuel ratio control. Optional with VSD with speed feedback signal
19	G mod pneu	Modulating electronic	x		x	Gas direct ignition, only when fired on gas, modulating electronic air-fuel ratio control. Optional with VSD with speed feedback signal
20	Gp1 mod pneu	Modulating electronic	x		x	Gas pilot ignition 1, only when fired on gas, modulating electronic air-fuel ratio control. Optional with VSD with speed feedback signal
21	Gp2 mod pneu	Modulating electronic	x		x	Gas pilot ignition 2, only when fired on gas, modulating electronic air-fuel ratio control. Optional with VSD with speed feedback signal
22	Lo mod	Modulating electronic	x		x	Oil direct ignition, only when fired on oil, modulating electronic air-fuel ratio control. Optional with VSD with speed feedback signal

(Also refer to section *Fuel trains*)

The VSD can be used with any of the operating modes (refer to chapter *VSD*).

No.	Parameter
542	Activation of VSD / PWM fan 0 = inactive 1 = active



Note

For configuration of the analog output when the VSD is activated, refer to chapter *Power output X74.3!*

8 Connection to load controllers

The LMV37.4... system can be connected to different load controllers. The heat request and the required burner output are determined in accordance with the priorities of the different heat sources.

8.1 Controller on contact X5-03, terminal 1

This contact is given priority over all output sources. A heat request can be made only when this contact is closed. The contact is safety-related and can also be used in connection with controllers featuring an integrated temperature limiter function.

8.2 External load controller via contacts X5-03, terminal 2 / terminal 3

The heat request is delivered via terminal 1. Modulation of burner output is effected via terminals 2 and 3. Here, a differentiation is made between modulating and multistage operation (refer to chapter *Selection of operating mode*).

Modulating operation X5-03 (OPEN «▲» terminal 3 / CLOSE «▼» terminal 2)

If input OPEN is active, the burner's output is increased. If input CLOSE is active, the burner's output is decreased. If none of the inputs is active, the burner's output stays the same.

The rate of integration is 32 seconds for changing the output from low-fire to high-fire, that is from 20 to 100%, or vice versa. Output integration always takes place in the operation position.

200 ms is the shortest positioning step that is securely detected.




Figure 33: Modulating operation X5-03

Minimum positioning step

To prevent the actuators from making unnecessary position changes when the preselected target output varies, a minimum positioning step can be set. In that case, the basic unit changes the output only when the preselected target output exceeds the minimum positioning step. This minimum positioning step is only used in modulating operation.

No.	Parameter
123.2	Minimum output positioning step: Output of external load controller contacts

Multistage operation X5-03 (stage 2, terminal 3 / stage 3, terminal 2)

In multistage operation, one or 2 thermostats can be connected to activate the different burner stages. Multistage operation is possible only when firing on oil.

If neither input «Stage 2» nor input «Stage 3» is active, the burner switches to «Stage 1».

If input «Stage 2» becomes active, the burner switches to the second stage.

If input «Stage 3» becomes active, the burner switches to the third stage. In that case, input «Stage 2» can be active or inactive. The third stage can only be activated with 3-stage operation.




Figure 34: 2-stage operation X5-03




Figure 35: 3-stage operation X5-03

Shifting multistage operation (OPEN ▲ terminal 3 / CLOSE ▼ terminal 2)

Using a simple thermostat, a modulating burner can be operated in shifting 2-stage mode. In that case, there must be a firm connection between terminal CLOSE and the live conductor (L), and terminal OPEN must be connected to the thermostat or the controller.

If OPEN is inactive, the active CLOSE terminal drives the burner to low-fire.
 If OPEN becomes active, priority is given over terminal CLOSE so that the output is increased by driving the burner to high-fire.




Figure 36: Shifting multistage operation (OPEN ▲ terminal 3 / CLOSE ▼ terminal 2)

Parameter 205 is needed to interchange usage of the load controller contacts for multi-stage operation. In that case, the burner switches to the third stage when input stage 2 is active (load controller Off). This has no impact on modulating operation.

No.	Parameter
205	Function load controller contacts 0 = standard 1 = stages interchanged

Modulating		Standard	Stages interchanged
X5-03/1	ON / OFF	Low-fire	Low-fire
X5-03/2	Closed	Signal Closed	Signal Closed
X5-03/3	Open	Signal Open	Signal Open

2-stage		Standard	Stages interchanged
X5-03/1	ON / OFF	Stage 1	Stage 1
X5-03/2	Closed	Stage 2	Stage 1
X5-03/3	Open	Stage 2	Stage 2

3-stage		Standard	Stages interchanged
X5-03/1	ON / OFF	Stage 1	Stage 1
X5-03/2	Closed	Stage 3	Stage 2
X5-03/3	Open	Stage 2	Stage 3

8.3 Load controller via building automation X92

To control the LMV37.4... basic unit, the BAC system can predefine an output via a bus system. The BAC system is connected to the basic unit via the X92 interface.

Burner startup can take place only when contact X5-03/1 is closed (load controller (LR) On / Off).

For more detailed information about the connection of BAC systems to basic unit, refer to chapter «Connection to superposed systems» in this document and to the Modbus User Documentation (A7541).

Minimum positioning step

To avoid unnecessary positioning steps of the actuators when the predefined target output varies, a minimum positioning step can be set. The basic unit changes the output only if the change in target output exceeds the minimum positioning step. The minimum positioning step only becomes active in modulating operation.

No.	Parameter
123.0	Minimum output positioning step: Output building automation

Behavior in the event the building automation and control system fails

If the system receives no more data from building automation, it delivers the output set with parameter 148. The time that elapses until communication breakdown is detected can be set via parameter 142.

No.	Parameter
142	Setback time in the event of communication breakdown Setting values 0 = deactivate 1...7200 s
148	Performance standard at interruption of communication with building automation Setting values For modulation operation the setting range is as follows: 0...19.9 = burner off 20...100 = 20...100% burner rating For multistage operation apply to setting range: 0 = burner OFF, P1, P2, P3 Invalid = no performance standards of the building automation Default setting: <i>Invalid</i>

Setting choices:

- a) Output preset with parameter 148 set undefined (--):
In the event communication breaks down, the last valid preselected output is maintained. The next load controller activated in accordance with the priority (refer to section *Prioritization of output sources*) ensures control from this output position.
- b) Output preset with parameter 148 set to 0, 20...100%, or parameterized as multistage:
If communication breaks down, the output requested by the building automation and control system is set invalid and the output set under parameter 148 is delivered.



Note

In that case, outputs via load controllers with a priority lower than that of the building automation and control system cannot be delivered.

8.4 Manual output

A manual output can be set with the «Normal display» of the display and operating unit or via the PC tool.

Manual output via the display and operating unit

Manual output can be activated or adjusted by keeping the **F** button depressed for at least 1 second and by pressing the **+** or **-** button.

Output **0** means «Manually off».

As long as manual output is active, the output appearing on the normal display flashes. To deactivate and to change to automatic operation, press **Esc** for 3 seconds.

If «Manually off» is activated, it is stored via mains OFF.

On power return, the burner assumes the «Manually off» position (**OFF** flashing) (refer to chapter *Operation*).

Activation of «Manually off» in operation

To activate «Manually off», first run the system to the minimum output limit. Then, keep the **F** button depressed for at least 1 second and press the **-** button.

«Manually off» is activated by releasing the **F** button and by pressing again the **-** button.



Caution!

«Manually off» must not be used by it self to put a burner out of operation when doing mounting work, or when the burner is not ready for operation. The safety notes contained in chapter *Safety notes* must be observed!

Manual output via the PC tool

Refer to description of the PC tool (J7352).

8.5 Output with curve settings

To set the curves via the display and operating unit or the PC tool, a special parameterization output is provided. Using this output, it is also possible to approach the point of ignition. The output is delivered automatically and cannot be set manually. It is only mentioned here for the sake of completeness.

8.6 External load controller via analog input X64.1 / X64.2

For the preselection of external outputs, an analog 4...20 mA input is provided. Burner startup can take place only when contact X5-03/1 is closed (load controller (LR) On / Off).

Switching thresholds / minimum positioning step

A disruption of the current input or a current signal <3mA leads to deactivation of the analog input's external preselected output. To avoid unnecessary positioning steps of the actuators when the input signal varies, it is possible to set a minimum positioning step for the predefined output. The minimum positioning step only becomes active in modulating operation. For the external load controller via the analog input, a value of 1% is preset.

No.	Parameter
123.1	Minimum output positioning step: Output external load controller analog




Figure 37: External load controller via analog input X64.1 / X64.2

8.6.1 Thresholds for modulating operation

Actual value	Current	Display / output value
Low-fire	3...4mA	20%
Low-fire	4mA	20%
High-fire	20mA	100%

8.6.2 Switching thresholds for 2-stage operation

For multistage operation a hysteresis band is realized to thresholds. The hysteresis band replaces the minimum control step for multistage operation. The bandwidth is approx. 1 mA.

2-stage operation

Actual value	Current	Display / output value
Stage 1	5mA (3...12mA)	P1
Hysteresis band	12...13mA	---
Stage 2	15mA (13...20mA)	P2

3-stage operation

Actual value	Current	Display / output value
Stage 1	5mA (3...7mA)	P1
Hysteresis band 1	7...8mA	---
Stage 2	10mA (8...12mA)	P2
Hysteresis band 2	12...13mA	---
Stage 3	15mA (13...20mA)	P3

8.7 Prioritization of power sources

To simplify configuration of the system, the power source need not be selected. The system automatically detects the available power sources and selects them. If several sources are used, they are selected according to the following priorities:

Parameter 942	Priority	Active power source
	1 highest	Chapter Controller-on-contact X5-03, terminal 1 When the input is activated, the other output sources is assessed according to their priorities. When the input is deactivated, the burner is off
1	2	Chapter Output with curve settings
2	3	Chapter Manual output
3	4	Chapter Load controller via the building automation system
4	5	Chapter External load controller via analog input X64 terminal 1 / terminal 2
5	6 lowest	Chapter External load controller via contacts X5-03, terminal 2 / terminal 3

The active power source can be read out via parameter 942.

8.7.1 Emergency operation with several load controllers

By making use of the prioritization described above, it is also possible to implement emergency operation. Should the building automation and control system fail (provided parameter 148 is set to undefined (--)), the unit switches automatically over to the external load controller.

A load controller via analogue input or, if existing via contacts can be connected.

8.7.2 Manual control

If the external load controller via analogue input or via contacts is not used, a simple manual output adjustment via switch can be implemented by cutting the connection to the load controller for switching from automatic to manual operation. In that case, the system switches to the external load controller via contact. An OPEN / CLOSED switch or stage 2 / stage 3 can then be connected to its terminals.

9 Electronic air-fuel ratio control

9.1 General

Electronic air-fuel ratio control is used for controlling the burner's actuators depending on burner output. It is possible to connect 2 actuators and, optionally, one VSD. Resolution is 0.1° with the actuators and 0.1% with the VSD. Output can be regulated in increments of 0.1% in modulating mode and with a maximum of 3-stages in multistage mode.

To reduce the amount of electric power required for the actuators, they are never operated simultaneously, but in successive order, or alternately.

9.2 Behavior outside operation

Outside the running position, the actuators approach the different positions in successive order.

The program phase determines the position to be approached.

9.2.1 Running speed

The actuators' running speed is fixed at 5 seconds for a positioning angle of 90°.

The ramp speed of the VSD can be adjusted separately for higher and lower speeds.

No.	Parameter
522	Ramp up
523	Ramp down

The setting also applies to the running position (refer to subsection *Running position*).

9.2.2 No-load position

This position is approached in the *Home run* (10), *Standby* (12) and *Lockout position* (00) phases.

The position can be set via the following parameters:

Parameter	Actuator
501.00	No-load position fuel actuator
502.00	No-load position air actuator
503.00	No-load speed VSD

9.2.3 Prepurging

This position is approached in phase *Traveling to prepurging* (24).

The position can be set via the following parameters:

Parameter	Actuator
501.01	Prepurge position fuel actuator
502.01	Prepurge position air actuator
503.01	Prepurge speed VSD

No.	Parameter
222	Gas: Prepurging 0 = inactive 1 = active
262	Oil: Prepurging 0 = inactive 1 = active

9.2.4 Ignition

The ignition position is approached in phase *Traveling to the ignition position* (38).

The position is set via curve parameterization under **P0**. In modulating operation, this point is assigned to an output of 10%.

9.2.5 Postpurging

This position is approached in phase *Traveling to postpurging* (72).

The position can be set via the following parameters:

Parameter	Actuator
501.02	Postpurge position fuel actuator
502.02	Postpurge position air actuator
503.02	Postpurge speed VSD

9.3 Modulating operation

In modulating mode, it is possible to operate 2 actuators and one VSD. The burner's output can be regulated between 20.0% (low-fire) and 100.0% (high-fire) in increments of 0.1%. Since the actuators are never allowed to operate simultaneously, the output is increased in small steps of 1%. In the case of an operating ramp of 20% after 100% in 32 seconds, this represents one step in 400 ms. Within such an output step, the air actuator is operated in the first 200 ms and the VSD, and the fuel actuator in the second 200 ms.

9.3.1 Definition of curves

The air-fuel ratio curves are defined by 10 curvepoints that are firmly distributed across the output range.

The following assignment applies:

Curvepoint	Output	Meaning
P0	10%	Point of ignition, is not approached in the running position
P1	20%	Low-fire
P2	30%	
P3	40%	
P4	50%	
P5	60%	
P6	70%	
P7	80%	
P8	90%	
P9	100%	high-fire

The actuator positions can be set with a resolution of 0.1°.

Between the curvepoints, the positions are interpolated in a linear manner.




Figure 38: Definition of curves

No.	Parameter
401	Ratio control curves fuel actuator (only curve setting)
402	Ratio control curves air actuator (only curve setting)
403	Ratio control curves VSD (only curve setting)

9.3.2 Running speed / maximum curve slope

The time required to modulate from low-fire to high-fire is 32 seconds.

In connection with the actuator's ramp in the basic unit, the following maximum positioning angles or speed changes between 2 curvepoints can be covered:

Type of actuator	Positioning speed	Positioning angle
Electromotoric actuator	5 s / 90°	31°
VSD	5 s / 100%	40%
	10 s / 100%	20%
	20 s / 100%	10%

No.	Parameter
522	Ramp up
523	Ramp down

The setting also acts outside the running position (refer to subsection *Running speed*).

VSD

Between the ignition time (P0) and the low-fire point (P1), a speed differential of up to 40% can be set for the VSD, independent of the selected ramp. This means that the period of time from ignition to low-fire can vary between 4...16 seconds (5 to 20 seconds ramp).

Error code	Diagnostic code	Meaning for the LMV37.4... system
84	Bit 0 Valency 1	VSD: Curve too steep in terms of the ramp rate
	Bit 1 Valency 2..3	Fuel actuator: Curve too steep in terms of ramp speed
	Bit 2 Valency 4..7	Air actuator: Curve too steep in terms of ramp speed

The parameterized curve is steeper than permitted with the selected actuator speed.

9.3.3 Entering the running position

The burner is ignited when ignition position **P0** is reached. When entering operating phase **60**, the actuators follow the defined curves until the low-fire position is reached (20% or parameter 545).

9.3.4 Running position

As demanded by the load controller, the actuators are driven along the defined 20% and 100% curves. Point of ignition **P0** can only be reached via the curve setting.

9.3.5 Restriction of modulation range

If the modulation range shall be further restricted from 20 to 100% against the defined curve, 2 parameters are available to define a new low-fire and new high-fire position.

No.	Parameter
545	Lower output limit undefined = 20 %
546	Upper output limit undefined = 100 %




Figure 39: Restriction of modulation range

9.3.6 Setting the minimum and maximum output

When changing the setting of minimum and maximum output after making the curve settings, following is to be observed:

After leaving the curve settings with completely defined curvepoints, proceed in modulating operation by setting the minimum / maximum output (parameter 546).

In the case of warm settings, the parameterized output remains active until the minimum / maximum output setting is completed. Any change of the minimum / maximum output is adopted by the parameterized output. Automatic operation becomes active only after leaving the minimum / maximum output.

This procedure ensures that the system maintains the output set by the user, thus facilitating **troublefree** setting of the minimum / maximum output.

Benefits:

- The current output always corresponds to the minimum / maximum output presently parameterized, or to the system output of the curve settings made last, which means that the output can be ascertained accurately and free from interference
- The output sources of low priority (contacts, analog input, BACS output, manual output) are deactivated
- During the curve and the subsequent minimum / maximum output settings, the manual off function is deactivated
- Unambiguous and easy-to-understand system behavior



Note

If there is no need to limit the output, it is not necessary to set the minimum / maximum output. In that case, the undefined minimum / maximum output corresponds to a minimum output of 20% and a maximum output of 100%.

9.4 Multistage operation

This operating mode is only available when firing on oil. There is a choice of 2-stage and 3-stage operation. Hence, the burner's output can be regulated via 2 or 3-stages. Modulation is accomplished by adjustment of the air actuator or of VSD and by switching the fuel valves for changing the amount of fuel delivered.

9.4.1 Definition of curves

Air-fuel ratio control is defined via the 2 or 3 static output points. To switch the valves on and off, switch-on and switch-off points must be defined.

The following assignment is used:

Curve-point	Meaning	Valve
P0	Point of ignition (does not approached in the running position)	V1
P1	Stage 1	V1
P2on	Switch-on point stage 2. When this point is exceeded, the fuel valve for the second stage is switched on	V1
P2_d	Presetting of point P2 with no approach	V1
P2	Stage 2	V2
P2of	Switch-off point stage 2. When this point is crossed, the fuel valve for the second stage is switched off	V2
P3on	Switch-on point stage 3. When this point is exceeded, the fuel valve for the third stage is switched on	V2
P3_d	Presetting of point P3 with no approach	V2
P3	Stage 3	V3
P3of	Switch-off point stage 3. When this point is crossed, the fuel valve for the third stage is switched off	V3

The actuator positions can be set with a resolution of 0.1°, the speeds with a resolution of 0.1%.

9.4.2 Running speed

The air actuator or the VSD is operated like outside the running position. The defined ramp speeds are used.

The running speed of the actuators is fixed at 5 seconds for a positioning angle of 90°. For increasing or degrading the speed, the speed of the VSD can be separated adjusted.

No.	Parameter
522	Ramp up
523	Ramp down

The setting also acts outside the operating position.

9.4.3 Adjustment of output

When the output increases, the system moves from the curvepoint of stage 1 (P1) to the switch-on point of stage 2 (P2on). If the switch-on point is exceeded, the valve for the second stage is switched on. Then, the system moves to the curvepoint for stage 2 (P2). When the output decreases, the system moves from the curvepoint of stage 2 (P2) to the switch-off point of stage 2 (P2of). If this point is crossed, the valve for the second stage is switched off. Then, the system moves to the curvepoint for stage 1 (P1). In 3-stage operation, the output between stage 2 and stage 3 is adjusted analogously to 2-stage operation. As static outputs, only **P1**, **P2** and **P3** can be approached. The switch-on and switch-off points are crossed only when changes between stages take place. The running speeds are fixed. Depending on the positioning angles to be covered, air actuator and VSD do not reach the operating or switch-on / switch-off points at the same time. The valves are switched on / off only after both actuators have reached their correct positions.

When parameterizing the curves, the switch-on points can also be approached in a stationary manner. In addition, when setting the curve via $P2_d$ ($P3_d$), curvepoint $P2$ ($P3$) can be readjusted without traveling to it. In that case, the system is at the respective switch-on point. This procedure is used to cut the operating time if there is shortage of air.




Figure 40: Adjustment of output

9.4.4 Changing to the running position

The burner is ignited at ignition position **P0**. When entering running phase **60**, the actuators are driven from ignition position **P0** to the running position of stage 1 (P1) at the respective running speed.

9.4.5 Running position

In the running position, the burner's output can be adjusted between running positions **P1** and **P2** or **P3** in accordance with the load controller's presetting, as described in subsection 9.4.3 Adjustment of output. Ignition position **P0** does not approached anymore. It can only be reached via curve adjustment.

9.4.6 Restriction of the modulation range

If the modulation range for stage 1 and stage 2, or stage 3, shall be further restricted, 2 parameters can be used to define a new low-fire and new high-fire position.

No.	Parameter
545	Lower output limit undefined = 20 %
546	Upper output limit undefined = 100 %

9.5 End of running position

When there is no more heat request, the system switches to phase 62. Here, the burner runs down to low-fire as long as possible before the valves are shut.

The available period of time can be set via parameter 212. If this period of time is set to the minimum value, the burner is immediately shut down should the heat request disappear. If the time exceeds 32 seconds, the burner always runs to the low-fire position. Naturally, it is also possible to set intermediate times.

No.	Parameter
212	Max. time down to low-fire

9.6 Setting and parameter setting notes

- When making the settings for the electronic air-fuel ratio control system integrated in the LMV37.4..., it must be ensured that sufficient amounts of excess air are available because over a period of time, the flue gas values is impacted by a number of factors, such as air density, wear of the actuators and controlling elements, etc. For this reason, the flue gas values initially set must be checked at regular intervals
- To safeguard against accidental or unauthorized transfer of parameters from the parameter backup of the ACS410 to the LMV37.4... basic unit, the OEM (burner or boiler manufacturer) must enter an individual burner identification for every burner. Only when this requirement is satisfied does the LMV37.4... system make certain that the ACS410 does not transfer a parameter set from a plant (with unsuited and possibly dangerous parameter values) to the LMV37.4... basic unit
- With the LMV37.4..., it is to be noted that the unit's characteristics are determined primarily by the parameter settings and not so much by the type of unit. This means that – among other considerations – the parameter settings must always be checked prior to commissioning the plant, and that the LMV37.4... must never be transferred from one plant to another without adapting the parameters to the new plant
- When using the ACS410 PC software, the safety notes given in the relevant Operating Instructions (J7352) must also be observed
- The parameter level is password-protected. The OEM assigns individual passwords for the parameter levels he can access. The unit is supplied with default passwords entered by Siemens; they must be changed by the OEM. These passwords are confidential and may only be assigned to authorized staff
- The responsibility for setting parameters is assumed by the person who, in accordance with the access rights, has made changes on the respective setting level

In particular, the OEM assumes responsibility for the correct parameter settings in compliance with the standards covering the specific applications (e.g. EN 676, EN 267, EN 1643, etc.).

10 Actuators X53 / X54

One or 2 actuators can be connected to the LMV37.4... system, depending on the selected operating mode (refer to chapter *Selection of operating mode*).



Caution!

When mounting the actuators, it must be made certain that the mechanical link to the controlling elements is rigid!




Figure 41: Actuator fuel (X54)

The actuators are for direct connection to the LMV37.4...




Figure 42: Actuator air (X53)

10.1 Function principle

The actuators are driven by stepper motors. The resolution reached when making one positioning step is 0.1° . The running speed is fixed at 5 seconds for a positioning angle of 90° .

An optical incremental transducer is used to monitor the actual position. Due to the use of a gear train with almost no backlash, position control is not required.

10.2 Definition of angles

The angles and angular ranges are specified in the Data Sheets of the relevant actuators.

SQM33...: Refer to Data Sheet N7813

SQN1... refer to Data Sheet N7803

Also refer to figure *Angle definitions with SQM33...*

10.3 Referencing


An incremental transducer is used to ensure position feedback. Hence, referencing of the actuators must be performed after power-on. In addition, at the end of each shut-down in phase 10, the actuators are referenced to ensure that individual stepping errors, which could lead to shutdown, do not accumulate. If a position error occurs, the system switches to the safety phase (phase 01), enabling the actuators with detected position errors to be referenced. During the following phase 10, the only actuators that are referenced are those that were not referenced before in the safety phase (phase 01). The position of the reference point can be selected depending on the type of burner design, either the CLOSED position ($<0^\circ$) or the OPEN position ($>90^\circ$).

No.	Parameter
601	Selection of reference point Index 0 = fuel Index 1 = air 0 = closed ($<0^\circ$) 1 = open ($>90^\circ$)
602	Direction of rotation of actuator Index 0 = fuel Index 1 = air 0 = counterclockwise 1 = clockwise (exclusively for SQM3...)
603	Tolerance limit of position monitoring (0.1°) Index 0 = fuel Index 1 = air Greatest position error where an error is securely detected → Error detection band: (P606 – 0.6°) up to P606
611	Type of referencing Index 0 = fuel Index 1 = air 0 = standard 1 = stop within the usable range 2 = internal stop 3 = both


10.3.1 Reference travel

Reference travel means that 2 different reference travels are performed, aimed at unambiguously determining the actuators' permissible working range. This prevents the actuators from traveling to a range outside the optical feedback system or against a mechanical stop should a power failure during referencing occur. Parameter 611 must be set depending on the mechanical construction and the type of actuator used. In the case of reference travel type 1, the SQM33... and SQN13... actuators first travel 10° in counterclockwise direction, independent of the selected direction of rotation, the type of actuator, and the set reference point. The SQN14... first travels 10° in clockwise direction.

SQM33... / SQN13...



SQN14...




Legend

- ① Travel in counterclockwise direction
- ② Travel in clockwise direction in relation to the starting point
- ③ Travel to the reference point
- ④ Travel to the 0°-position
- ⑤ Optionally: Travel to the standby position


No.	Parameter	Setting for actuator		
		SQM33...	SQN13...	SQN14...
611	Type of referencing			
	Index 0 = Fuel	0	2	2
	Index 1 = Air	0	2	2

In the case of reference travel type 2, the SQM33... and SQN13... actuators first travel 10° in clockwise direction, independent of the selected direction of rotation, the type of actuator, and the set reference point. The SQN14... first travels 10° in counterclockwise direction.

SQM33... / SQN13...



SQN14...



Legend

- ① Travel in clockwise direction
- ② Travel to the reference point
- ③ Travel to the 0°-position
- ④ Optionally: Travel to the standby position

No.	Parameter	Setting for actuator type		
		SQM33...	SQN13...	SQN14...
611	Type of referencing			
	Index 0 = fuel	1	3	3
	Index 1 = air	1	3	3

Example of an actuator with counterclockwise rotation:

When referencing in the CLOSED position, the actuator first travels a certain distance into the working range (towards the OPEN position). Then, it travels to a position representing maximum -7.7° , thereby crossing the reference mark for the first time. Then, the actuator moves in the other direction again and detects the inner ramp of the reference mark. This is the reference point used by all positions. If the reference point is parameterized in the OPEN position, referencing takes place in a mirror-symmetrical manner. In that case, the actuator first travels into the working range (towards the OPEN position). Then, it crosses the reference mark and travels to a position representing maximum 110.6° , then back to the inner ramp of the reference mark.




Figure 43: Angle definitions with SQM33...

Error code	Diagnostic code	Meaning for the LMV37.4... system
85	0	Referencing error of fuel actuator
	1	Referencing error of air actuator
	Bit 7 Valency ≥128	Referencing error due to parameter change

10.4 Direction of rotation

With the SQM3... actuator, the direction of rotation can be selected on an individual basis.

Parameter	
602.00	Direction of rotation of fuel actuator Index 0 = fuel 0 = counterclockwise 1 = clockwise (exclusively for SQM3...)
602.01	Direction of rotation of air actuator Index 1 = air 0 = counterclockwise 1 = clockwise (exclusively for SQM3...)




Figure 44: Direction of rotation (example SQM3...)

When SQN1..., always rotation direction left must be select.

The direction of rotation is be fixed by respective type of SQN1... actuator:

- SQN13...: Direction of rotation left
- SQN14...: Direction of rotation right



Note

The actuators are always supplied with the flat of the drive shaft facing upward.

10.5 Monitoring the positions

To monitor the actuator's actual positions, an optical incremental transducer with a resolution of 0.7° is used. The correct position of the drive shaft is ensured by comparing the motor steps made with the position obtained from the incremental transducer. Due to the different resolutions of motor steps and incremental transducer plus the selected tolerance band, the following error identification band is obtained. The decision where, in the error identification band, shutdown takes place depends on the currently required position.

For the default setting made in the factory, the error detection band is as follows:

Smallest position error where an error can be detected	1.1°
Greatest position error where an error is securely detected (default setting parameter 606)	1.7°

The presetting of 1.7° (default setting, parameter 606) is suited for use with actuators type SQN1... and SQM3...



Note

When using SQN1... actuators equipped with plastic gear trains, we recommend to change the preset values as follows:

Type	Value
SQN13.14...	1,7°
SQN14.14...	1,7°
SQN13.17...	2,2°
SQN14.17...	2,2°

When referencing under output conditions, the resilience of the actuator's gear train must also be taken into consideration:

Type reference	Resilience at max. rated driving torque
SQM33.41...	0.2°
SQM33.51...	0.2°
SQN13.14...	0.3°
SQN13.17...	0.8°
SQN14.14...	0.3°
SQN14.17...	0.8°

The error detection time is <1 second.

Caution!

This means that – for the design and setting of the burner – a position error resulting from the sum of

- greatest position error from which an error is detected in all positions
- resilience at the max. rated torque
- mechanical influence from the link between actuator and regulating unit (e.g. coupling)

must not lead to a critical state in terms of safety.



No.	Parameter
606	Tolerance limit of position monitoring (0.1°) Index 0 = fuel Index 1 = air Greatest position error where an error is securely detected → Error detection band: (P606 -0.6°) up to P606

Error code	Diagnostic code	Meaning for the LMV37.4... system
86	0	Position error fuel actuator
87	0	Position error air actuator

10.6 Changing the error detection band for monitoring the positions

The error detection band can be changed via parameter 606.
A change is to be made only when using SQN13.17... / SQN14.17... actuators which, due to their mechanical design, require greater tolerances.
For these types of actuators, set parameter 606 to 2.2°.

No.	Parameter
606	Tolerance limit of position monitoring (0.1°) Index 0 = fuel Index 1 = air Greatest position error where an error is securely detected → Error detection band: (P606 -0.6°) up to P606

10.7 Forced travel

There are errors in the actuators' feedback unit that can only be detected in connection with position changes. To be able to also detect such errors when maintaining the same position for longer periods of time, travel is enforced when, for more than 50 minutes, an actuator moves no more than 2.8°. With forced travel, both actuators are driven 2.8° in the direction of smaller positioning angles and back again to the initial angular position. If a damper is less than 2.8° open, the actuator is driven in the direction of positive angles in order not to run against mechanical stops, if present. Forced travel lasts a total of 1 second.

10.8 Detection of open-circuit

The connecting line ensuring position feedback from the actuator to the basic unit is monitored for open-circuit, which means that position feedback cannot fail without being noticed.

Error code	Diagnostic code	Meaning for the LMV37.4... system
86	Bit 0 Valency 1	Open-circuit fuel actuator
87	Bit 0 Valency 1	Open-circuit air actuator

10.9 Protection against actuator mixup

Mixup of actuators can be detected through appropriate mounting (using different reference marks for the air and fuel actuator: OPEN / CLOSED / 0° / 90°). With at least one of the actuators, the reference mark not used must be blocked by a mechanical stop. Now, if the actuator connections with the basic unit have been interchanged, one of the actuators cannot reach the reference mark, which is detected by the basic unit. Protection against mixup is a question of the burner application and must be ensured by the OEM.



Caution!

To be able to detect mixup of actuators, the burner manufacturers must ensure that the 2 actuators use opposing reference points. One of the actuators uses the OPEN reference, the other the CLOSED reference. Approach of the reference point not used must be blocked with at least one of the actuators!

10.9.1 Proposal for implementation

- Parameterize referencing of the air damper in the CLOSED position
- Parameterize referencing of the fuel damper in the OPEN position. Unnecessary travel can be avoided by defining a no-load position of **90°** for the fuel damper
- Mechanical stop at the air damper in the range between 90° and 108.5°, and / or mechanical stop at the fuel damper in the range between 0° and -5.6°

Referencing process

- From any position in the working range (0...90°), but typically from the no-load position, the air damper travels to the **-7.7°** position and back again to the no-load position
- From any position in the working range (0...90°), but typically from the no-load position, the fuel damper travels to the **110.6°** position and back again to the no-load position

Process in the event of mixup

- The fuel damper (fitted in place of the air damper) travels to the **-7.7°** position and back again to the no-load position
- The air damper (fitted in place of the gas damper) tries to travel to the **110.6°** position, but is prevented from doing so by the mechanical stop. This is unsuccessful travel and identified as mixup

11 Fan control

11.1 Function principle

Optionally, the LMV37.4... system can be operated with a VSD or PWM fan. Control is accomplished via a DC 0...10 V interface. For control of the fan's speed, a safety-related speed feedback signal is required. With pneumatic air-fuel ratio control, the speed feedback signal is not evaluated. To facilitate the use of fans with different speed ranges, the fan's speed is standardized between 0...100%. If a fan control is not connected, a power output and, alternatively, a fuel meter output are available (refer to chapter *Power output X74.3* and chapter *Fuel meter input X75.1 / X75.2*).




Figure 45: Function principle of VSD

11.2 Activating the VSD / PWM fan

The VSD can be activated in any of the operating modes (P201).

No.	Parameter
542	Activation of VSD / PWM fan 0 = inactive 1 = active



Note

For configuration of the analog output when the VSD is activated, refer to chapter *Power output X74.3!*

11.3 VSD control X74.3

The VSD is controlled via a voltage interface (refer to chapter *Power output X74.3!*)

Depending on the type of VSD used, a release contact is required. This contact can be controlled via the fan motor contactor. To enable the VSD to bring the fan motor's speed to the correct no-load speed, the motor contactor's drop out delay time must be about 25 seconds.

Example:




Figure 46: Connection of VSD to the LMV37.4...

11.4 PWM fan control X64.3

The PWM fan is controlled via PWM voltage interface X64.3.



Caution!

The use of PWM fans is only possible in connection with pneumatic ratio control!

11.5 Safe separation of mains voltage and protective extra low-voltage



Caution!

All inputs and outputs of PWM fan control are designed for use with protective extra low-voltage. For this reason, strict separation from the mains voltage side must be ensured!

This necessitates an external power supply by the VSD or an external power pack (X74.1, X74.2).



Note

Power must also be supplied via X74.1/2 in the case a PWM fan is used.

11.6 Ramp time

The ramp time for **PWM fan control** can be set separately for acceleration and deceleration (also refer to subsection *Running speed / maximum curve slope*).

No.	Parameter
522	Ramp up
523	Ramp down

If shutdown occurs because the speed has not been reached, the VSD / PWM fan might not be able to follow quickly enough the set ramp.

Remedy:

Shorten further the ramp of the VSD / PWM fan or increase the ramp in the basic unit (parameters 522 / 523) (also refer to subsection *Running speed / maximum curve slope*).

For VSD operation



Caution!

The ramps parameterized in the VSD should be at least 20% shorter than the ramps in the LMV37.4...

Example:

10 s ramp	LMV37.4...	8 s ramp VSD
5 s ramp	LMV37.4...	4 s ramp VSD

11.7 Acquisition of speed

11.7.1 Acquisition of speed with proximity switch

The actual speed is acquired by an inductive proximity switch which scans a metal sensor disk. The sensor disk must be attached directly to the motor's drive shaft. Speed acquisition is safety-related. To facilitate the detection of the direction of rotation and to be able to make the plausibility check with only one sensor, a sensor disk with angular steps of 60°, 120° and 180° is used. It generates 3 pulse intervals of different length.

Speed acquisition is designed for the connection of different types of sensors.



Caution!
With electronic air-fuel ratio control, speed acquisition is safety-related!

We recommend using the AGG5.310 accessory set.
 The absolute speed can be read out via the AZL2...

No.	Parameter
935	Absolute speed

The current speed in standardized form can be read out via the AZL2...


No.	Parameter
936	Standardized speed

Speed input X74.4

Motor speed: 300...6500 1/rpm
 100% speed: 650...6500 1/rpm
 Sensor: Inductive sensor to DIN 19234 (Namur) or Open Collector (pnp) at $U_{CEsat} < 4\text{ V}$, $U_{CEmin} > DC\ 15\text{ V}$
 Power supply: DC 10 V, max. 15 mA
 Switching current: $> 10\text{ mA}$
 Cable length: Max. 100 m (sensor cable must be laid **separately!**)

Sensor disk

Sensor disk and speed sensor can be ordered as accessory set AGG5.310.



Number of tappets: 3
 Angular steps: 60°, 120°, 180°
 Accuracy: ±2°

Figure 47: Sensor disk

Speed sensor




Figure 48: Speed sensor

Selection of fan motor

Motor supplier:

Selection of a motor **with** a threaded hole M8 x 15 at the end of the fan motor's drive shaft.

Standard motor and machining (drilling hole and cutting thread M8 x 15).

11.7.2 Acquisition of speed with Hall generator

If the speed is acquired via a Hall generator, the requirements for safety-related applications are the same as those for the speed feedback signal via sensor disk.

Required is an asymmetric signal with the 3 pulses of 60°, 120° and 180° for the detection of the direction of rotation.

11.8 Speed control

The LMV37.4... controls the fan motor's speed to the setpoint. To ensure that the actual speed can still be increased when the maximum is reached, the speed is standardized when the motor is controlled at 95%. Hence, with a speed setpoint of 100%, a speed increase of 5% is still possible.

The control range of the LMV37.4... is +15% / -10%. If this range is not sufficient, error 80 or 83 can occur.

Error code	Diagnostic code	Meaning for the LMV37.4... system
80	1	Control range limitation at the bottom
	2	Control range limitation at the top



Note

Internal control with a VSD or PWM fan motor must not be activated. Otherwise, speed variations can occur, resulting from simultaneous control actions from both the basic unit and internal control.

11.9 Speed supervision

The fan's actual speed is acquired by the LMV37.4... and assessed from a safety point of view. If the fan does not operate at the speed setpoint, speed control makes a corrective action, trying to reach the setpoint. If it is not reached within a certain period of time, safety shutdown is initiated. To ensure a high level of availability and safety, a number of monitoring bands with different response times are defined.

Speed deviation in % points	Shutdown time
0...0.5%	Speed reached → no shutdown
0.6...2%	<8 s
2.1...10%	<3 s
>10%	<1 s

Error code	Diagnostic code	Meaning for the LMV37.4... system
83	Bit 0 Valency 1	Lower control range limitation
	Bit 1 Valency 2...3	Upper control range limitation
	Bit 2 Valency 4...7	Interrupt shutdown due to electromagnetic interference
	Bit 3 Valency ≥ 8	Curve too steep in terms of ramp speed
	Bit 4 Valency ≥ 16	Interruption of speed signal
	Bit 5 Valency ≥ 32	Quick shutdown due to excessive speed deviation

11.10 Parameterizing of the VSD

If the burner's rated capacity is not reached at 95% (9.5 V) control, you can proceed as follows:

- Set the maximum frequency to 105.3% of the motor's rated speed

In the case of a motor frequency of 50 Hz, this means:

Set the maximum frequency of the VSD to $50 \text{ Hz} \times 1.053 = 52.6 \text{ Hz}$ (on the VSD).

- Then, standardize the speed (refer to section *Standardizing the speed*)

There is no risk of motor overload since only 95% of the maximum control signal is delivered during standardization and, later in operation, the actual speed is controlled and monitored.

Frequencies of between 50 Hz and 52.6 Hz are delivered only if these are needed for reaching the required speed due to increased output.

- Set the ramp times of the VSD according to subsection *Setting the ramp times*

11.11 Standardization of speed

Since the different types of fans operate at different speeds and signal handling should be as straightforward as possible, all speeds in the system are standardized between 0 and 100%. For this reason, the VSD module uses a parameter which contains the «standard speed» (100% speed). All absolute speeds refer to this speed.

If changes to the VSD or the fan are made, speed standardization should be repeated.



Caution!

- If automatic speed standardization is activated or if the standardized speed is changed, the settings of air-fuel ratio control must be checked! Any change of the standardized speed alters the assignment between the percentage values parameterized on the curves and the speed
- When the parameter set (refer to ACS J7352) is restored, the standardized speed also reset. In that case, new standardization of the speed is required

Automatic speed standardization

To facilitate determination of the standardized speed, the LMV37.4... features automatic speed standardization. The speed must be standardized while in standby mode. Speed standardization is integrated in the setting process for electronic air-fuel ratio control, but can also be started later from the parameter setting level. When using a release contact for the VSD (external relay at fan output X3-05.1), the fan output is controlled during speed standardization.

1. Start speed standardization

To start automatic speed standardization, set parameter 641 to 1.

Parameter	
641	Control of VSD' speed standardization Error diagnostics of negative values (refer to error 82) 0 = no speed standardization 1 = speed standardization active

2. Drive the air damper to the prepurge position

Speed standardization begins when the air damper travels to the prepurge position. When this position is reached, the air damper should be fully open so that the fan operates at full capacity.

3. Control the VSD

Control the VSD at 95% of maximum voltage.

A margin of 5% allows the speed to be readjusted should environmental conditions change. This means that full speed (100%) is reached with 95% VSD control (refer to section *Parameterizing the VSD*).

4. Wait until the speed is higher and has stabilized

Before the 100% speed can be measured, the fan must have reached stationary conditions. This means that the fan must operate under stable conditions above 650 rpm. When this state is reached, a certain waiting time is observed, allowing the speed to finally stabilize.

5. Measure the speed and store it

When the speed has stabilized, measure and store it as the «standardized speed» (100% speed).

6. Close the standardization

When standardization is successfully completed, reset parameter 641 to **0**.
If standardization was not successful, parameter 641 assumes a negative value.

The value provides information on the cause of fault:

Value	Error	Recommended measures
-1	<i>Timeout of standardization (VSD's ramp down time too long)</i>	Timeout at the end of standardization during ramp down of VSD. 1. VSD ramp time settings are not shorter than those of the basic unit (parameter 523).
-2	<i>Storage of standardized speed not successful</i>	Error during storage of standardized speed → lock the basic unit and reset it again, repeat standardization
-3	<i>Open-circuit speed sensor</i>	Basic unit receives no pulses from the speed sensor. 1. Motor does not turn. 2. Speed sensor is not connected. 3. Speed sensor is not actuated by the sensor disk (check distance).
-4	<i>Speed variation / VSD ramp up time too long / speed below minimum limit for standardization</i>	Motor has not reached a stable speed after ramp up. 1. VSD ramp time settings are not shorter than those of the basic unit (parameters 522, 523). 2. VSD's characteristic is not linear. Configuration of voltage input at the VSD must accord with that of the basic unit (DC 0...10 V). 3. VSD does not follow quickly enough the change of the basic unit. Check VSD settings (input filter, slippage compensation, hiding various speeds). 4. Speed of VSD lies below the minimum for standardization (650 1/min).
-5	<i>Wrong direction of rotation</i>	Motor's direction of rotation is wrong. 1. Motor turns in the wrong direction → change parameterization of the direction of rotation or inter change 2 live conductors. 2. Sensor disk is fitted the wrong way → turn sensor disk.

Value	Error	Recommended measures
-6	<i>Unplausible sensor signals</i>	The required pulse pattern (60°, 120°, 180°) has not been correctly identified. 1. Speed sensor does not detect all tappets of the sensor disk → check the distance. 2. As the motor turns, other metal parts are detected also, in addition to the tappets → improve mounting. 3. Electromagnetic interference on the sensor lines → check cable routing, improve EMC.
-7	<i>Invalid standardized speed</i>	Standardized speed measured does not lie in the permissible range. 1. Motor turns too slowly or too fast.
-15	<i>Speed deviation $\mu C1 + \mu C2$</i>	The speeds of microcomputer 1 and 2 deviated too much. This can be caused by wrong standardized speeds (e.g. after restoring a data set to a new unit) → repeat standardization and check the fuel-air ratio
-20	<i>Wrong phase of phase manager</i>	Standardization was made in a wrong phase. 1. Permitted are only phases ≤ 12 → controller OFF, start standardization again.
-21	<i>Safety loop / burner flange open</i>	Safety loop or burner flange is open. 1. Repeat standardization with safety loop closed.
-22	<i>Air actuator not referenced</i>	Air actuator is not referenced or has lost its reference 1. Check if the reference position can be approached. 2. Check if actuators have been mixed up. 3. If error only occurs after standardization was started, the actuator is possibly overloaded and cannot reach the required position.
-23	<i>VSD deactivated</i>	Standardization was started with VSD deactivated → activate VSD and repeat standardization
-24	<i>No valid operating mode</i>	Standardization was started with no valid operating mode → select a valid operating mode and repeat standardization

The result of speed standardization (100% speed) can be read out via parameter. The speeds acquired by the 2 microcontrollers can differ by about 1.5%, the reason being slightly different resonator frequencies.

Parameter	
642.0	Standardized speed of $\mu C1$
642.1	Standardized speed of $\mu C2$

11.12 Control of fan motor with pneumatic air-fuel ratio control

If the control of the fan motor is employed for burners with pneumatic air-fuel ratio control, only the control path is used. There is no need to connect a speed feedback signal and to have speed control (for operating modes, refer to chapter *Selection of operating mode*).

11.13 EMC LMV37.4... – VSD

The function and EMC tests with the LMV37.4... system have been successfully conducted in connection with the following makes and types of VSDs:

Siemens: SED2-0.37 / 22 X

Danfoss: VT2807

During operation, VSDs generate electromagnetic interference on the mains network. For this reason, the instructions provided by the supplier must be strictly observed to ensure that makeup of the system is in compliance with EMC regulations:

Siemens: Operating Instructions → installation conforming to EMC

Danfoss: Technical Brochure → radio suppression filter

Data Sheet on Danfoss EMC filter for long motor cables



Caution!

When using other types of VSDs, compliance with EMC regulations and trouble-free operation are not ensured!

11.14 Description of the terminals

11.14.1 VSD




Figure 49: VSD module X74

11.14.2 PWM fan




Figure 50: PWM fan X74




Figure 51: PWM fan X64

12 Power output X74.3

The power output is only available as an alternative to VSD control. If the VSD is deactivated, the output for the VSD delivers the current burner output. The analog output is a voltage output and – using parameter 645 – can be switched between DC 0...10 V, DC 2...10 V and DC 0 / 2...10 V.

Parameter 645	Voltage range	Remarks
0	0...10 V	No detection of open-circuit
1	2...10 V	Detection of open-circuit possible
2	0 / 2...10 V	No detection of open-circuit Recommended setting in connection with Micro master VSD



Note

When changing the analog output configuration from 0...10 V to 2...10 V or 0 / 2...10 V, the voltage values with modulating, 2-stage and 3-stage operation change (refer to section *Modulating operation*, section *2-stage operation* and section *3-stage operation*).

Conversion: New value = (initial value * 0.8) + 2

Example: Initially 2 V → (2 * 0.8) + 2 = 3.6 V

Initially 5 V → (5 * 0.8) + 2 = 6 V

12.1 Safe separation of mains voltage and extra low-voltage



Caution!

The power output is designed for SELV or PELV (refer to section «Electrical connection of LMV37.4...»).

For this reason, strict separation from the mains voltage side must be ensured!

This necessitates power supply by an external power pack (X74.1, X74.2).

12.2 Modulating operation

Actual value	Voltage	Curvepoint	Display / output value
Off	0 V	---	Off
Ignition load	1 V	P0	10%
Low-fire	2 V	P1	20%
High-fire	10 V	P9	100%

The values between low-fire and high-fire are interpolated in a linear manner.

12.3 2-stage operation

Actual value	Voltage	Curvepoint	Display / output value
Off	0 V	---	Off
Stage 1	5 V	P1	P1
Stage 2	10 V	P2	P2

12.4 3-stage operation

Actual value	Voltage	Curvepoint	Display / output value
Off	0 V	---	Off
Stage 1	3 V	P1	P1
Stage 2	5 V	P2	P2
Stage 3	10 V	P3	P3

13 Fuel meter input X75.1 / X75.2

A fuel meter can be connected to acquire the amount of fuel burnt. The fuel meter function is only available as an alternative to VSD control. If the VSD is deactivated, a fuel meter can be connected to terminals X75.1 and X75.2.



Figure 52: Fuel meter input X75

13.1 Configuration of fuel meter

13.1.1 Types of fuel meters

The LMV37.4... system is designed for use with fuel meters equipped with a Reed contact. Pulse frequency at maximum fuel throughput must be below 300 Hz.

13.1.2 Configuration of pulses per volume unit

Depending on the type of fuel meter used, the number of pulses supplied by it per m³ or l fuel must be parameterized. A maximum of 400 pulses per volume unit can be preset. The correct amount of fuel is acquired only when this parameter is set.

When the parameter is 0, the fuel meter stops.

No.	Parameter
128	Fuel meter: Pulse valency (pulses / volume unit)

13.1.3 Reading and resetting the meter readings

No.	Parameter
167	Fuel volume resettable (m ³ , l, ft ³ , gal)

The cumulated fuel volume can be read out per parameter. The meter reading can also be reset on the parameter level.

13.2 Fuel throughput

With the fuel meter connected, the system calculates continuously the current fuel throughput. The time required for calculating the fuel throughput varies and lies between 1 and 10 seconds. If the fuel meter delivers no pulses for more than 10 seconds, the display shows "0" fuel throughput. This means that when fuel throughput is at its minimum, the sensor should have a pulse frequency of at least 0.1 Hz. The display is smoothed to improve the settling process. With fuel throughput at its maximum, the maximum frequency is 300 Hz.

13.2.1 Configuration

Calculation of fuel throughput is configured based on the pulse valency of the connected fuel meter.

No.	Parameter
128	Fuel meter: Pulse valency (pulses / unit of volume)

When the pulse valency is set to 0.00, the display shows "0" throughput.

13.2.2 Reading out the fuel throughput

The current fuel throughput can be read out via the following parameter on the service menu:

No.	Parameter
960	Fuel throughput in unit of volume / h (m ³ /h, l/h, ft ³ /h, gal/h)


Display of fuel throughput is possible up to 6553 units of volume / h.



Note

Display of fuel throughput up to a value of 99.9 on the service menu is made with one decimal place, from 100 with no decimal place.

14 Inputs and outputs



Shielding:

- For shielding the cables on the VSD, refer to:
- Siemens *SED2* VSD Commissioning Manual (G5192). chapter 4 and chapter 7 or
 - Danfoss Operation Manual *VLT 6000* (MG60A703). chapter «Installation»




Figure 53: Inputs and outputs

15 Special feature: Identification of burner (ID)

The OEM must assign an individual burner identification to every burner. This ensures that during backup / restore, incompatible parameter sets cannot be copied between different burners (also refer to documentation on PC tool under *Backup / Restore* and in this documentation in chapter *Backup / Restore*).

No.	Parameter
113	Burner identification

16 Connection to superposed systems

16.1 General and functions of building automation system

Communication with a building automation and control system is accomplished via a data link using the COM X92 port and a special interface with galvanic separation and physical bus level adaptation. This port can be used for connection of a Modbus, depending on the configuration made.




Figure 54: Connection via interface COM 92 to superposed systems



Note
Breakdown of bus communication.

If the basic unit detects a breakdown of bus communication, the BAC system must rewrite the following values upon restoration of communication:

- Modbus: The Modbus, Modbus operating mode and predefined target output

General setting values for connection of the basic unit to the BAC system (for factory settings, refer to the parameter list):

Bus communication may only be interrupted for the time set.

If communication is disturbed for a longer period of time, the LMV37.4... basic unit delivers a fault status message and the values set in the basic unit by the BAC system will be reset.

No.	Parameter
141	Operating mode building automation 0 = off 1 = Modbus 2 = reserved
142	Setback time in the event of communication breakdown Setting values 0 = deactivated 1...7200 s
148	Performance standard at interruption of communication with building automation Setting values For modulation operation the setting range is as follows: 0...19.9 = burner off 20...100 = 20...100% burner rating For multistage operation apply to setting range: 0 = burner OFF, P1, P2, P3 Invalid = no performance standards of the building automation Default setting: <i>Invalid</i>

The factory settings of the parameters are shown on the parameter list.



Note

For a detailed description of parameter 148, refer to section «Predefined output via BAC system».

16.2 Modbus

With this type of bus protocol, the LMV37.4... basic unit operates as a slave on the Modbus and the transmission mode used is RTU (Remote Terminal Unit). For more detailed information, refer to the Modbus User Documentation (A7541).

No.	Parameter
145	Device address for Modbus of basic unit Setting values 1...247
146	Setting of Baud rate for Modbus communication Setting values 0 = 9600 1 = 19200
147	Setting of parity for Modbus communication Setting values 0 = none 1 = odd 2 = even

The factory settings of the parameters are shown on the parameter list.



Note

If bus communication breaks down, the mode, Modbus operating mode and pre-defined target output must be rewritten.

17 PC software ACS410

The ACS410 PC software serves primarily as an operating module for the LMV37.4... system, providing the following basic functions:

- Visualization of system state via the following data:
 - Parameters
 - Process data
- Configuration and parameterization of the basic unit (individual parameters)
- Backup and recovery of parameter sets



Note
For notes on operation and commissioning, refer to chapter *Operation*




Figure 55: Communication with display / BCI (RJ11 jack) (X56)




Figure 56: Display input / BCI (RJ11 jack) X56

If communication between the LMV37.4... and the ACS410 (70 s) has broken down, the password level is reset to *Info / Service*.



Caution!
Interruption of communication between the LMV37.4... and the ACS410 (30 seconds) during the time the curves are set leads to lockout!

Error-code	Diagnostic code	Meaning for the LMV37.100... system
167	9	Manual locking via PC tool communication interruption

18 Error history

The LMV37.4... system provides an error history in which the last 25 errors are stored. The first entry represents the current error state and can also be «error-free», refer to *Error code list*.

Error code	Diagnostic code	Meaning for the LMV37.4... system
200 OFF	#	System error-free

18.1 Error classes

The errors are subdivided into error classes, depending on the severity of the switch-off response. The current error shows all classes. Only the errors of the most important classes are included in the history.

Error class	Priority	Meaning	History
0	Highest	Lockout	X
1		Safety shutdown with software reset	X
2		Undervoltage	
3		Safety shutdown: Safety phase	X
4		Safety shutdown: Start prevention	
5		Safety shutdown: Shutdown	X
6	Lowest	Message without shutdown response	

18.2 Make-up of error history

Parameter	Index	Description
701		Current error state, can also be error-free
	.01	Error code (200 = error-free) → refer to <i>Error code list</i>
	.02	Diagnostic code → refer to <i>Error code list</i>
	.03	Error class → <i>Error code list</i>
	.04	Error phase: Phase in which error occurred → sequence diagrams
	.05	Startup counter: Startup meter reading (P166) at which the error occurred
	.06	Output: Burner output at which the error occurred
702	.01..06	Latest error in the history
.		
.		
.		
725	.01..06	Oldest error in the history

Deleting the error history

Both the service menu and the parameter setting menu show the error history.

The display on the service menu can be deleted in a way that the only errors shown are those that occurred after the deletion.

The error history on the parameter setting menu cannot be deleted.

For the deletion, parameter 130 must be set to **1** and then to **2** within 6 seconds.

When the parameter has returned to **0**, the deletion process is completed.

No.	Parameter
130	Delete display of error history To delete the display: Set parameter to 1, then to 2 Return value 0: Job successful completed Return value -1: Timeout of 1_2 sequence

19 Lifecycle function

If the startup counter exceeds a defined threshold, a display error code is set and displayed. The error can be acknowledged.

The display code is always set in standby (when there is no heat request). Hence, the moment the threshold is exceeded, the user is notified that the end of the lifecycle soon reached.

Error code	Diagnostic code	Meaning for the LMV37.4... system
116	0	Designed lifecycle exceeded (250,000 startups)



Note

The unit should be replaced when the message appears.

20 Safety notes for use of the AZL2...

Caution!

To prevent the risk of fire and explosions, damage to heating plant or damage resulting from improper use of the products, ensure that the following safety notes are observed:

The Burner Management System covered by the present User Manual may only be used as specified and only in connection with the appropriate burner and heating plant.

The Burner Management System with its display and operating unit and the associated heating control system may only be installed and commissioned by authorized technical staff.



The operating unit may only be used in dry spaces. Do not use it outdoors and protect it against excessive temperatures and frost, and liquids, such as water, oil, fuel oil, etc.

Follow exactly the procedures and setting notes given in this User Manual. Appropriately identified settings must only be made by authorized technical staff.

If the display and operating unit is dusty or dirty, clean it with a dry cloth.

Do not carry out any maintenance or repair work on the unit. Such work may only be performed by authorized technical staff.

If you have any questions in connection with the display and operating unit, please contact your heating engineer or refer to one of the addresses given in this User Manual.

21 Operating the AZL2... unit

21.1 Description of the unit / display and buttons

Function and operation of unit versions AZL21... and AZL23... are identical.























Figure 57: Description of the unit / display and buttons

Button	Function
	Button F - For adjusting the fuel actuator (keep  depressed and adjust the value by pressing  or )
	Button A - For adjusting the air actuator (keep  depressed and adjust the value by pressing  or )
	Buttons A and F: VSD function - For changing to parameter setting mode P (press simultaneously  and  plus  or )
	Info and Enter button - For navigating in info or service mode * Selection (symbol flashing) (press button for <1 s) * For changing to a lower menu level (press button for 1...3 s) * For changing to a higher menu level (press button for 3...8 s) * For changing the operating mode (press button for >8 s) - Enter in parameter setting mode - Reset in the event of fault - One menu level down
	- button - For decreasing the value - For navigating during curve adjustments in info or service mode
	+ button - For increasing the value - For navigating during curve adjustments in info or service mode
	+ and - button: Escape function (press  and  simultaneously) - No adoption of value - One menu level up

21.2 Meaning of symbols on the display




Figure 58: Meaning of display

21.3 Brightness of the display

Only available with backlit LCD:

The function of the backlit display is dependent on the type of basic unit used.

The brightness of the display can be adjusted from 0...100% using the parameter 126.

No.	Parameter
126	Brightness of display

21.5 Timeout for menu operation

The time for automatically leaving the parameter setting level can be adjusted between 10 and 120 minutes, using the following parameter:

No.	Parameter
127	Timeout for menu operation

If, during that period of time, there is no operation via the AZL2..., the parameter setting level is quit and the password level reset to *Info / Service*.



Caution!

In addition, this timeout or interruption of communication between the LMV37.4... and the AZL2... during the time the curves are set leads to lockout!

Error-code	Diagnostic code	Meaning for the LMV37... system
167	8	Manual locking via AZL2... Timeout / communication interruption

21.6 Backup / restore

Using the AZL2..., the settings made on the basic unit can be stored (backup) and then restored on the basic unit at a later point in time.

Creating a backup data set

No.	Parameter
050.0	Index 0: Creation of backup

The following parameters can be used to read information about the backup data set:

No.	Parameter
055	Burner identification of the AZL2... backup data set
056	ASN extraction of the AZL2... backup data set
057	Software version used when creating the AZL2... backup data set

Restoring a backup data set


To restore a backup data set, the parameter must be set to **1**.

No.	Parameter
050.1	Index 1: Execute restore

21.6.1 Backup

		<p>Parameter 000: blinks.</p> <p>Display: Parameter 000: blinks, Int does not.</p>
 /reset		
<p>Only OEM level</p>		<p>Press to go to parameter group 041.</p> <p>Display: Parameter 041: blinks, ._._ does not.</p>
 +		<p>Press + to select parameter 050</p> <p>Display: Parameter 050. blinks, index 00: and value 0 do not.</p>
 /reset		
		<p>Press to select parameter bAC_UP</p> <p>Display: Parameter bAC_UP</p>
 /reset		
		<p>Press to select the backup process.</p> <p>Display: Value 0</p>
 +		<p>Press + to shift the value in change mode by one position to the left.</p> <p>Display: Value 1 blinks</p>
<p>Note To detect potential display errors, the value is displayed one position shifted to the left.</p>		
 /reset		<p>Press to activate the backup process.</p> <p>Display: 1 appears</p>

Approx. 5 s



After about 5 seconds (depending on the duration of the program), **0** appears on the display, indicating the end of the backup process.

Display: **0**



Note




















If an error occurs during the backup process, a negative value is displayed. For error diagnostics, the cause of the error can be determined from the diagnostic code of error message 137 (see *Error code list*).





Caution!

We recommend to make a backup whenever a parameter is changed!


21.6.2 Restore

		<p>Parameter 000: blinks.</p> <p>Display: Parameter 000: blinks, Int does not.</p>
		
<p>Only OEM level</p>		<p>Press  to go to parameter group 041.</p> <p>Display: Parameter 041: blinks, ._._ does not.</p>
<p> +</p>		<p>Press  + to select parameter 050</p> <p>Display: Parameter 050. blinks, index 00: and value 0 do not.</p>
		
		<p>Press  to go to parameter bAC_UP</p> <p>Display: Parameter bAC_UP</p>
<p> +</p>		<p>Press  + to select parameter rEStore</p> <p>Display: Parameter rEStore</p>
		
		<p>Press  to select the restore process.</p> <p>Display: Value 0</p>
<p> +</p>		<p>Press  + to shift the value in change mode by one position to the left.</p> <p>Display: Value 1 blinks.</p> <p>Note To detect potential display errors, the value is displayed one position shifted to the left.</p>



Press /reset to activate the restore process.

Display: **1** appears



Ca.
8 s

After about 8 seconds (depending on the duration of the program), **0** appears on the display, indicating the end of the backup process.

Display: **0**



Note

- Before restoring the backup data, the basic unit compares the burner identification and the product no. (ASN) with the burner identification and the product no. (ASN) of the backup data set. If the data accord, they are restored. If they do not, the restore process is aborted. In case of abortion, or if an error occurs during the restore process, the display shows a negative value. For error diagnostics, the cause of the error can be determined from the diagnostic code of error message 137 (see *Error code list*). When the restore process is successfully completed, value **0** appears on the display. The LMV37.4... is supplied with undefined burner identification. In that case, the restore process from the AZL2... is possible without having to enter the burner identification in the basic unit
- Information **Err C: 136 D: 1** (restore started) is displayed for a short moment



Caution!


- **On completion of the restore process, the sequence of functions and the parameter settings must be checked**

22 Operation of basic unit via AZL2...

22.1 Normal display

Normal display is the standard display in normal operation, representing the highest menu level. From the normal display, you can change to the info, service or parameter level.

22.1.1 Display in standby mode




The image shows a digital display with 'OFF' in large characters. Above the display are several icons: a square with a diagonal line, a fan, a sun, a snowflake, a lightning bolt, and a double-headed arrow. Below the display are navigation symbols: a downward triangle, an upward triangle, 'V', 'h', 'min', 's', '%', and a star. The text 'Bld 9/0707' is visible on the right side of the display area.

Unit is in standby mode.

Note
OFF flashes when the manual OFF function, the manual output and controller OFF is activated.

22.1.2 Display during startup / shutdown


22.1.2.1. Display of program phases



The image shows a digital display with 'PH22' in large characters. The same icons and navigation symbols as in the previous image are present. The text 'Bld 10/0707' is visible on the right side of the display area.

The unit is in **phase 22**. The controller calls for heat. The bar below the ☐ symbol appears. The individual program phases and controlled components are displayed in accordance with the program sequence.

22.1.2.2. Display of program phase with remaining running time until end of the phase is reached



The image shows a digital display with 'PH30' in large characters and '12' in smaller characters to the right. The same icons and navigation symbols are present. The text 'Bld 11/0707' is visible on the right side of the display area.


The unit is in **phase 30** and shows the remaining running time in that phase.

Example: **12 s**, phase **30**


22.1.2.3. List of phase displays

Phase	Function
Ph00	Lockout phase
Ph01	Safety phase
Ph10	Home run
Ph12	Standby (stationary)
Ph22	Fan ramp up time (fan motor = ON, safety valve = ON)
Ph24	Traveling to the prepurge position
Ph30	Prepurge time
Ph36	Traveling to the ignition position
Ph38	Preignition time
Ph39	Valve proving filling time (test of pressure switch-min when fitted between fuel valves V1 and V2)
Ph40	1st safety time (ignition transformer ON)
Ph42	1st safety time (ignition transformer OFF)
Ph44	Interval 1
Ph50	2nd safety time
Ph52	Interval 2
Ph60	Operation 1 (stationary)
Ph62	Max. time low-fire (operation 2, preparing for shutdown, traveling to low-fire)
Ph70	Afterburn time
Ph72	Traveling to the postpurge position
Ph74	Postpurge time (no extraneous light test)
Ph78	Postpurge time (t3) (abortion when load controller ON)
Ph80	Valve proving test evacuation time
Ph81	Valve proving test time atmospheric pressure, atmospheric test
Ph82	Valve proving filling test, filling
Ph83	Valve proving time gas pressure, pressure test
Ph90	Gas shortage waiting time


22.1.3 Display of operating position




Display **oP** stands for «Operating position reached».
Modulating mode: Current output in %




Display **oP: P0** stands for «Ignition point».
Multistage operating mode: Current fuel stage



Display **oP: P1** stands for «Stage 1».
Multistage operating mode: Current fuel stage






Display **oP: P2** stands for «Stage 2».
Multistage operating mode: Current fuel stage








Display **oP: P3** stands for «Stage 3».
Multistage operating mode: Current fuel stage

22.1.4 Fault status message, display of errors and info











22.1.4.1. Display of errors (faults) with lockout

	<p>The display shows Loc:, the bar under the fault status message  appears.</p>
	<p>The unit is in the lockout position.</p> <p>The display shows current error code c: alternating with diagnostic code d: (refer to <i>Blink code list</i>).</p>
<p>Example: Error code 4 / diagnostic code 3</p>	


22.1.4.2. Reset

 <p> /reset 1...3 s</p>		<p>When pressing  for 1...3 s, rESEt appears on the display.</p> <p>When the button is released, the basic unit is reset.</p> <p>If the  button is pressed for a time other than the time indicated above, a change to the previous menu is made.</p> <p>Exception If an error occurred while setting the curve, a change back to the parameter setting level is made.</p>
---	--	---

22.1.4.3. Activating info / service mode from lockout

 <p> /reset >3 s</p>		
 <p> /reset >5 s</p>		<p>When pressing  for >3 s, the display shows InFo, SEr and then OPeRAtE.</p>
 <p> /reset >8 s</p>		<p>When the button is released, a change to info / service mode is made.</p>


22.1.4.4. Error with safety shutdown



The display shows **Err:**.


The unit initiates safety shutdown.

The display shows current error code **c:** alternating with diagnostic code **d:**.

Press /reset to return to the normal display.


Example: Error code **12** / diagnostic code **0**

22.1.4.5. General information



The unit displays an event which does not lead to shutdown.

The display shows current error code **c:** alternating with diagnostic code **d:**.

Press /reset to return to the display of phases.


Example: Error code **111** / diagnostic code **0**



Note


For meaning of the error and diagnostic codes, refer to chapter *Error code list*. When an error has been acknowledged, it can still be read out from the error history.

22.1.4.6. Start prevention



A non-programmed or not completely parameterized unit, or a unit whose operating mode was reset or changed, displays **OFF UPPr**.

22.1.4.7. Safety loop



A unit whose safety loop and / or burner flange contact is open, and a controller ON signal is present, displays **OFF S**.

23 Menu-driven operation

23.1 Assignment of levels

The various levels can be accessed via different button combinations. The parameter level can only be accessed via password.




Figure 59: Assignment of levels


24 Info level



The info level displays information about the basic unit and about operation in general.



Note





On the info level, you can display the next or the previous parameter by pressing



Instead of pressing , you can also press  for <1 s.



Note

Press    or  for >3 s to return to the normal display.



Note










Fig. 60: Info level

No change of values on the info level!





If the display shows  below the parameter value, the value may consist of more than 5 digits.

The value is displayed by pressing  for >1 s and <3 s.

Press  for >3 s or press    to return to the selection of the parameter numbers (parameter no. blinks).


No.	Parameter
Info level	
167	Fuel volume resettable (m ³ , l, ft ³ , gal)
162	Operating hours resettable
164	Startups resettable
163	Operating hours when unit is live
166	Total number of startups
113	Burner identification
107	Software version
108	Software variant
102	Identification date
103	Identification number
104	Preselected parameter set: Customer code
105	Preselected parameter set: Version
143	Reserve
End	




24.1 Display of info level






 Info/reset 1...3 s		Press  until InFo appears. When releasing  , you are on the info level.
--	---	---

24.2 Display of info values (examples)

24.2.1 Identification date

		The display shows parameter 102 : flashing on the left, characters ._. on the right. Example: 102: ._.
--	---	--


 Info/reset 1...3 s		Press  for 1...3 s to show the identification date TT.MM.JJ . Example: Identification date 03.11.05
--	---	---

 Info/reset or ESC 		Press  for >3 s or  to return to the display of parameters.
--	--	---


To the next parameter



24.2.2 Identification number


		The display shows parameter 103 : flashing on the left, identification number 0 on the right. Example: 103: 0
--	---	---

To the next parameter




Back to the previous parameter


24.2.3 Identification of burner



The display shows parameter **113**: flashing on the left, characters **._._** on the right.


Example: **113**: **._._**





Press  for 1...3 s to show the burner's identification.

Default setting: **-----**

Example: **3**




Press  or  to return to the display of parameters.

The burner's identification can be set on the parameter level!


To the next parameter  Back to the previous parameter 


24.2.4 Number of startups resettable




The display shows parameter **164**: flashing on the left, characters **._._** on the right, since display of the number of startups may comprise more than 5 digits.



Example: Parameter **164**: **._._**



Press  for 1...3 s to show the number of startups (resettable).

Example: **36**




Press  or  to show parameter **164** flashing again.

The number of startups can be reset on the parameter level!


To the next parameter  Back to the previous parameter 


24.2.5 Total number of startups




The display shows parameter **166**: flashing on the left, characters **._._** on the right, since the display of the total number of startups may comprise more than 5 digits.



Example: Parameter **166**: **._._**



Press  for 1...3 s to show the total number of startups.

Example: **56**




Press  or  to return to the display of parameters.

To the next parameter



Back to the previous parameter


24.2.6 End of the info level




When this display appears, you have reached the end of the info level.



The display shows **- End -** flashing.

To the start of the info level




Back to the previous parameter



Press  for >3 s or  to return to the normal display.

OPERAtE appears for a short moment.



When this display appears, you are back on the normal display and you can change to the next level mode.

25 Service level

The service level is used to display information about errors including the error history and information about the basic unit.

Note

When on the service level, you can press or to display the next or the previous parameter.

Instead of pressing + , you can also press for <1 s.

Note

Press or for >3 s to return to the normal display.

Note




Figure 61: Service level


No change of values on the service level.

If characters **.....** are displayed by the parameter, the value may consist of more than 5 digits.

Press for >1 s and <3 s to display the value.

Press for >3 s or to return to the selection of the parameter number (blinking).

25.1 Display of the service level




Press for >3 s until **SEr** appears.

When releasing , you are on the service level.

No.	Parameter
Service level	
954	Flame intensity
960	Actual fuel throughput in unit of volume / h (m ³ /h, l/h, ft ³ /h, gal/h)
121	Manual output Undefined = automatic operation
922	Incremental position of actuators Index 0 = fuel Index 1 = air
936	Standardized speed
161	Number of faults
701	Error history: 701-725.01.Code
.	
.	
.	
725	

25.2 Display of service values (example)


25.2.1 Number of faults



The display shows parameter **161**: flashing on the left, the number of faults that occurred thus far on the right **0**.

Example: Parameter **161**: **0**

To the next parameter



Back to the previous parameter

25.2.2 Error history


Refer to section *Parameter with index, without direct display / Example of parameter 701: Error history!*



Note

Can be deleted for service (refer to chapter *Parameter list*)!

25.2.3 Intensity of flame




The display shows parameter **954**: flashing on the left.

On the right, the flame's intensity is displayed as a percentage.


Example: **954**: **0.0**

To the next parameter



Back to the previous parameter

25.2.4 End of the service level




When this display appears, you have reached the end of the service level.


Display **– End –** appears flashing.

To the start of the service level




Back to the previous parameter



Press  to return to the normal display.

OPERAtE appears for a short moment.



When this display appears, you are back on the normal display and you can change to the next level mode.

26 Parameter level

The parameters stored in the basic unit can be displayed or changed on the parameter level.

The change to the parameter level requires a password.

Siemens supplies the LMV37.4... gas basic units with the factory settings according to «Type summary».

The OEM can change the Siemens default settings to match his own requirements.

With the LMV37.4..., the basic unit's characteristics are determined primarily through parameterization. Every time the unit is recommissioned, the parameter settings must be checked. The LMV37.4... must never be transferred from one plant to another without matching the parameters to the new plant.

Caution!

Parameters and settings may only be changed by **qualified staff**.

If parameters are changed, responsibility for the new parameter settings is assumed by the person who – in accordance with the access rights – has made parameter changes on the respective access level.



After parameterization, the OEM must check to ensure that safe burner operation is warranted.

The OEM which made the settings is always responsible for the parameters, their settings and compliance of the respective application with the relevant national and international standards and safety regulations, such as EN 676, EN 267, EN 1643, etc. Siemens, its suppliers and other Group Companies of Siemens AG do not assume responsibility for special or indirect damage, consequential damage, other damage, or damage resulting from wrong parameterization.

Warning!

If the factory settings are changed, all changes made must be documented and checked by the OEM.



The OEM is obliged to mark the unit accordingly and to include at least the list of device parameters and settings in the burner's documentation.

Siemens also recommends attaching an additional mark on the LMV37.4... in the form of an adhesive label. According to EN 298, the label should be easy to read and wipe proof.

The label with a maximum size of 70 mm x 45 mm can be attached to the upper part of the housing.

Example of label:

OEM logo
Type / part no.: 1234567890ABCD

Caution! OEM settings:

Parameter no.

225 = 30 s (t1)

226 = 2 s (t3)

230 = 10 s (t4)

234 = 0 s (t8)

240 = 1 (repetition)

257 = 2 s (t3n)

TSA = t3n + 0.7 s

259 = 30 s (t11)

260 = 30 s (t12)


26.1 Entering the password



Note

The OEM's password must consist of 5 characters,
the heating engineer of 4 characters.

		<p>Press button combination to display CodE.</p>
		<p>When releasing the buttons, 7 bars appear the first of which flashes.</p>
		<p>Press to select a number or letter.</p>
		<p>Press to confirm the value. The value entered changes to a minus sign (-). The next bar starts flashing.</p>
		<p>Press to select a number or letter.</p>
		<p>After entry of the last character, the password must be confirmed by pressing . Example: Password consisting of 4 characters.</p>



As a confirmation of correct entry, **PArA** appears for a maximum of 2 seconds.



Note


For entry of passwords or burner IDs, the following numbers and letters can be used:

	= 1		= A		= L
	= 2		= b		= n
	= 3		= C		= o
	= 4		= d		= P
	= 5		= E		= r
	= 6		= F		= S
	= 7		= G		= t
	= 8		= H		= u
	= 9		= I		= Y
	= 0		= J		



26.2 Entering the burner's identification


The burner's identification is to be entered like a password (character by character), but from right to left and ending with “_”.

		<p>Parameter 113: flashes.</p> <p>Press to go to editing mode.</p>
		<p>You are on the display for undefined burner identification.</p> <p>8 bars appear.</p>
		<p>Press or to select a number.</p> <p>Example: Number 3 flashes.</p>
		<p>Press to confirm the value.</p> <p>Make the entry number by number.</p>
		<p>Press or to select the next number.</p> <p>Example: Number 9 flashes.</p>
		<p>After entry of the last number, burner identification must be confirmed by pressing .</p>




The display no longer flashes.
 Example: Burner identification **9993**





Press  to return to the parameter level.
PArAmeter 113: for burner identification.

26.3 Changing the heating engineer's password




Parameter **041:** flashes.



Press  to go to level **c:** for password changes.



Letter **n:** for new.


Proceed as described in section «Entering the password» and enter the new password (4 characters).


After entry of the last character, the password must be confirmed by pressing .




Letter **r:** for repeat.

Proceed as described in section «Entering the password» and repeat entry of the new password.

After entry of the last character, the password must be confirmed by pressing .
















SEt confirms that the new password has been saved.



Parameter **041:** flashes again.

26.4 Changing the OEM's password

		<p>Parameter 042: flashes.</p> <p>Press  to go to level c: for password changes.</p>
		<p>Letter n: for new.</p> <p>Proceed as described in section «Entering the password» and enter the new password (5 characters).</p> <p>After entry of the last character, the password must be confirmed by pressing .</p>
		<p>Letter r: for repeat.</p> <p>Proceed as described in section «Entering the password» and repeat entry of the new password.</p> <p>After entry of the last character, the password must be confirmed by pressing .</p>
		<p>SEt confirms that the new password has been saved.</p>
		<p>Parameter 042: flashes again.</p>


26.5 Use of the parameter level

The parameters stored in the LMV37.4... basic unit can be displayed and changed on the parameter level. Normally, all parameters have been set by the burner manufacturer – with the exception of those for the fuel train and for air-fuel ratio control.

A description of parameter level **400**, which is used for setting the fuel train and the fuel-air ratio curve, is given in chapter «Air-fuel ratio curves – settings and commissioning».

26.6 Assignment of the parameter levels

The parameters are assigned to different levels.



Note

The following sections explain the operating philosophy behind the parameter levels using a number of examples.




Caution!


Chapter «Safety notes on settings and parameterization» must be particularly observed!


26.7 Parameters without index, with direct display


26.7.1 Using the example of parameter 208: Program stop




PARmeter level **200**: for basic units.





Press /reset to go to menu level **200**:





Press  to select «Program stop».

Display: Parameter **208**: flashes, value **0** does not.










Press  to go to editing mode.

Display:
Program stop time set
Here: Value **0**
→ corresponding to program stop deactivated.





Press  or  to select the required program stop time.


- 0 = deactivated
- 1 = PrePurgP (Ph24)
- 2 = IgnitPos (Ph36)
- 3 = Interv1 (Ph44)
- 4 = Interv2 (Ph52)

Example: **2** IgnitPos (Ph36)

Adopt the value!





Discard the change!



Press to return to editing mode.

The value set will be adopted.





Press to return to the parameter level.

Display: Parameter **208**: blinks, value **0** does not.

Note



To detect potential display errors, the value is displayed one position shifted to the right.

Display: Value **2**



Press to return to the parameter level.

PARAmeter 208: flashes, value **2** does not.



Press to return to the parameter level.

PARAmeter 200: for basic units.














To the next parameter level





Back to the previous parameter level

26.8 Parameters without index, with no direct display (with parameters having a value range >5 digits)


26.8.1 Using the example of parameter 162: Operating hours resettable


		<p>PArAmeter level 100: for general.</p>
		<p>Press /reset to go to menu level 100:.</p>
		<p>Press  + to select «Operating hours resettable».</p> <p>Display: Parameter 162: flashes, characters --- do not.</p>
		
		<p>Press /reset to go to editing mode.</p> <p>Display: 123457</p>
		<p>You can press  or  to set the number of operating hours to 0.</p> <p>Display: Operating hours 0 flashes.</p>

Adopt the value!



Discard the change!




Press  to return to editing mode.


The value set will be adopted.

Note



To detect potential display errors, the value is displayed one position shifted to the right.


Display: Value 0



Press  to return to the parameter level.

Display: Parameter **162**: blinks, characters **---** do not.




Press  to return to the parameter level.


PArAmeter 100: for general.

26.9 Parameter with index, with direct display


26.9.1 Using the example of parameter 501: Non-flame positions fuel actuator



PARAmeter level **500**: for air-fuel ratio control.




/reset




Press **/reset** to go to menu level **500**:

Display: Parameter **501**. flashes, index **00**: and value **0.0** do not.





/reset



Press **/reset** to go to the index.


Display: Parameter **501**. does not flash, index **00**: flashes, value **0.0** does not.


Press **-** or **+** to select the required index.

- .00 = no-load position
- .01 = prepurge position
- .02 = postpurge position

Display: Index **01**: for prepurge position flashes, value **0.0** does not.





/reset



Press **/reset** to go to editing mode.



Display: Value **0.0**



Press **-** or **+** to select the required prepurge position.


Example: **1.0**

Adopt the value!



Discard the change!




Press  to return to editing mode.

The value set will be adopted.



Note


To detect potential display errors, the value is displayed one position shifted to the right.

Press  to return to the index.



Display: Parameter **501**. does not blink, index **01**: blinks, value **0.0** has not changed and does not blink.


Display: Value **1.0**





Press  to return to the index.


PARAmeter **501**: does not flash, index **01**: flashes, value **1.0** does not.



Press  to return to the parameter level.

Display: Parameter **501**. flashes, index **00**: and value **0.0** do not.



Press  to return to the parameter level.

PARAmeter **500**: for air-fuel ratio control.

26.10 Parameters with index, with no direct display

26.10.1 Using the example of parameter 701: Errors

Refer to chapter *Error code list!*



Note

Can be deleted for service, refer to chapter *Parameter list!*

HIStorie **700**: for error history.

Press /reset to go to the parameter level.

Press + to select parameter **701**.

Display: Parameter **701**. flashes, index **01**: and value **201** do not.

/reset

Press /reset to go to index **01**:

Display: Parameter **701**. does not flash, index **01**: flashes, value **201** does not.

To the next index +

Back to the previous index -

Press + to select the index:



- .01 = error code
- .02 = diagnostic code
- .03 = error class
- .04 = error phase
- .05 = startup counter
- .06 = output

Example:
Parameter **701**., index **05**: for startup counter, diagnostic code **-.-**





Press to go to display mode.

Display: Value **56**




Press to return to the index.

Display: Parameter **701.** does not flash, index **05:** flashes, characters **--** do not.



Press to return to the parameter level.

Display: Parameter **701.** flashes index **05:** does not, characters **--** do not.




To the next older error



•
•
•

Parameters cover the period of time back to the last error since history was deleted (max. to parameter **725.**)

Example:
Parameter **725.**, index **01:**, error code **111**




To the next parameter




Back to the previous parameter

When this display appears, you have reached the end of the error history index.


Display **- End -** appears flashing.



To the next parameter





Back to the previous parameter



When this display appears, you have reached the end of the error history.


Display **End** appears flashing.



Press + to return to the parameter level.

HISt 700: for error history

To the next parameter




Back to the previous parameter



Note


If you wish, you can delete the error history via parameter **130**.
To delete the display, set the parameter to **1** and then to **2**.
The error history is deleted when the parameter has returned to **0**.

26.11 Air-fuel ratio curves – settings and commissioning





The display shows **400**: flashing on the left, **SEt** appears on the right.


26.11.1 Initial commissioning






An un-programmed unit or a unit whose operating mode has been reset or changed displays **OFF UPr**.

For initial commissioning, change to the parameter level (refer to chapter *Operation*).
The settings can then be made on parameter level **400**.



Press /reset to select parameter **400** for initial commissioning and for setting air-fuel ratio control.



Press /reset to go to the settings for air-fuel ratio control and parameter **201** for selecting the operating mode.


201: appears flashing.





Note



Ensure that the fuel train is correctly set in accordance with the type of burner.


No.	Parameter	Actuator controlled	
		Air	Fuel
201	Burner operating mode (fuel train, modulating / multistage, actuators, etc.)		
	-- = undefined (delete curves)	X	X
	1 = gas modulating (G mod)	X	X
	2 = gas modulating with pilot valve (Gp1 mod) ¹⁾	X	X
	3 = gas modulating with pilot valve (Gp2 mod) ¹⁾	X	X
	4 = oil modulating (Lo mod)	X	X
	5 = oil 2-stage (Lo 2 stage)	X	---
	6 = oil 3-stage (Lo 3 stage) ¹⁾	X	---
	7 = gas modulating (G mod pneu)	X	---
	8 = gas modulating (Gp1 mod pneu) ¹⁾	X	---
	9 = gas modulating (Gp2 mod pneu) ¹⁾	X	---
	10 = oil modulating with gas pilot (LoGp mod)	X	X
	11 = oil 2-stage with gas pilot (LoGp 2-stage)	X	---
	12 = oil modulating with 2 fuel valves (Lo mod 2V)	X	X
	13 = oil modulating with gas pilot and 2 fuel valves (LoGp mod 2V)	X	X
	14 = gas modulating (G mod pneu, 0 active)	---	---
	15 = gas modulating with pilot (Gp1 mod pneu, 0 active)	---	---
	16 = gas modulating with pilot (Gp2 mod pneu, 0 active)	---	---
	17 = oil 2-stage (Lo 2-stage, 0 active)	---	---
	18 = oil 3-stage (Lo 3-stage, 0 active)	---	---
	19 = gas modulating only when fired on gas (G mod fuel active)	---	X
	20 = gas modulating with pilot only when fired on gas (Gp1 mod fuel active)	---	X
21 = gas modulating with pilot only when fired on gas (Gp2 mod fuel active)	---	X	
22 = oil modulating only when fired on oil (Lo mod fuel active)	---	X	



 /reset




Press  /reset to go to editing mode.


 OR 





Press  or  to select the required setting.


Example: **3** for gas modulating with pilot valve (Gp2 mod)



 /reset




Press  /reset to save the selected setting.


 ESC




Press   to return to the parameter level.

To the next parameter 


 /reset




Press  /reset to change to parameter **542**: to activate the VSD.

You can choose:
 0 = VSD OFF
 1 = VSD ON

To the next parameter  Back to the previous parameter 



Press  to change to parameter **641**: to control speed standardization of the VSD.

You can choose:
 0 = speed standardization OFF
 1 = speed standardization ON

After setting speed standardization to **1**, standardization of the VSD commences. If successful, the parameter is reset to **0**. Negative values indicate errors (refer to subsection *Automatic speed standardization*).

- For operating modes 1...4, 7...10, 12...16 and 19...22, refer to subsection **Setting curvepoints P0, P1 and P9 for modulating mode («G mod», «Gp1 mod», «Gp2 mod» and «Lo mod»)**
- For operating modes 5, 6, 11, 17 and 18, refer to subsection **Setting the curvepoints for multistage mode («Lo 2-stage» and «Lo 3-stage»)**

To the next parameter 

26.11.2 Setting curvepoints P0 and P9 for modulating mode («G mod», «Gp1 mod», «Gp2 mod» and «Lo mod»)



Note

Not all actuators used in the following example can be set, depending on the selected operating mode.

Example of «G mod»

		<p>Display P0 appears flashing.</p> <p>Curvepoint for ignition load.</p>
		<p>Keep F depressed.</p> <p>You are now in setting P0 of fuel setting F for ignition position P0.</p>
		<p>Press simultaneously F and - or + to set ignition position P0 of the fuel damper.</p> <p>Example: 30.0</p>
		<p>Release F.</p> <p>The selected value is adopted.</p> <p>Example: 30.0</p>
		<p>Keep A depressed.</p> <p>You are now in setting P0 of air actuator A for ignition position P0.</p>
		<p>Press simultaneously A and - or + to set ignition position P0 of the air actuator.</p> <p>Example: 22.0</p>
		<p>Release A.</p> <p>The selected value is adopted.</p> <p>Example: 22.0</p>
		<p>Keep F and A depressed.</p> <p>You are now in setting n0, speed n is for ignition position n0</p>

Press simultaneously **F** and **A** and **-** or **+** to adjust speed **n0** of the load controller.

Example: **20.0**

Release **F** and **A**.

The selected value is adopted.

Example: **20.0**

To the next curvepoint

Press **+**.

P9 appears flashing.

Curvepoint for high-fire.

Same procedure as with **P0**

Note:

If **-** is pressed first, the display jumps to 90!

To the next curvepoint

Back to the previous curvepoint

Press **+**.

The display shows **run** (identification of start for setting the curve parameters).

Note


When pressing , you are given the choice of proceeding with the "warm settings" (refer to subsection *Warm settings for modulating mode* («G mod», «Gp1 mod», «Gp2 mod» and «Lo mod») or, by pressing **-** **+**, with the "cold settings" (refer to subsection *Cold settings for* «G mod», «Gp1 mod», «Gp2 mod» and «Lo mod»).

26.11.3 Setting curvepoints P0 and P9 for «G mod pneu», «Gp1 mod pneu» and «Gp2 mod pneu»



Note

Refer to subsection *Setting curvepoints P0 and P9 for modulating mode («G mod», «Gp1 mod», «Gp2 mod» and «Lo mod»!*

Here, only the air must be adjusted with  .

26.11.4 Warm settings for modulating mode («G mod», «Gp1 mod», «Gp2 mod» and «Lo mod»)




Note

With the "warm settings", the burner is started up after pressing **InFo**. Air-fuel ratio control can now be accurately set while the flame is present. When traveling along the precalculated curve to high-fire point **P9**, all intermediate curvepoints (**P2...P8**) must be set.

Automatic operation is released when – after reaching **P9** – the curve settings are quit by pressing **Esc**. If the curve settings are aborted earlier (**Esc** or shutdown due to fault), start prevention **OFF UPr** continues to be active until all points are set.

If required, the gas pressure can be set at the high-fire point. In case the gas pressure is changed, all points must be checked by traveling along the curve downward and – if required – must be readjusted.



Identification of start for setting the curve parameters.




When there is a request for heat.




Note


If, during the time the curve is parameterized, an error occurs which leads to safety shutdown, parameterization of the curve is quitted.



Phase *Standby* (stationary)



Phase *Fan ramp up* (fan motor = ON, safety valve = ON)



Phase *Traveling to prepurge position*



Phase *Prepurging*

Phase *Traveling to ignition position*

Wait until the burner is in operation and symbol ▲ or ▼ is no longer highlighted!
 The startup sequence stops in phase 36 *Traveling to ignition position*.
 The ignition position can be adjusted under "cold" conditions.

Ignition position **P0** can only be set after symbol ▲ or ▼ is no longer highlighted.

For fuel, keep **F** depressed, for air, **A**, as well as for VDS **F** and **A**

Press **-** or **+** to adjust the value.

As soon as symbol ▲ or ▼ is no longer highlighted, the next curvepoint **P1** can be selected with **+**.

+

Phase *Traveling to ignition position*

Phase *Preignition*

Phase *1st safety time (ignition transformer ON)*

Phase *1st safety time (ignition transformer OFF), preignition time OFF*

Phase *Interval 1*

Starting the “warm settings“

○ F or A
and
▭ - or +
as well as
○ F and A
and
▭ - or +


BMH 1180707

Ignition position **P0** can only be set when symbol ▲ or ▼ is no longer highlighted.

For fuel, keep **F** depressed, for air, **A**, as well as for VSD **F** and **A**

Press **-** or **+** to adjust the value.

As soon as symbol ▲ or ▼ is no longer highlighted, the next curvepoint **P1** can be selected with **+**.



○ F or A
and
▭ - or +
as well as
○ F and A
and
▭ - or +

BMH 1230707

Low-flame position **P1** can only be set when symbol ▲ or ▼ is no longer highlighted.

The value is adopted from **P0**.

For fuel, keep **F** depressed, for air, **A**, as well as for VSD **F** and **A**

Press **-** or **+** to adjust the value.

As soon as symbol ▲ or ▼ is no longer highlighted, the next curvepoint **P2** can be selected with **+**.

To the next curvepoint



Back to the previous curvepoint

BMH 1240707

When changing from **P1** to **P2** for the first time, curvepoints **P2...P8** automatically calculated and saved.

CALC appears for a short moment.




Figure 62: Setting the curvepoints



Note

Curvepoints **P2 to P8** are automatically computed as a straight line between **P1** and **P9**.

Example 1 = gas modulating

P0, P1 and P9 are set as described:	Curvepoint	Value 1 fuel	Value 2 air
	P0	30.0	22.0
	P1	32.0	24.0
	P9	80.0	90.0

P2 through P8 have automatically been calculated:	Curvepoint	Value 1 fuel	Value 2 air
	P2	38.0	32.3
	P3	44.0	40.5
	P4	50.0	48.8
	P5	56.0	57
	P6	62.0	65.3
	P7	68.0	73.5
P8	74.0	81.8	

Continue the same way with P2 through P9!

F OR A
and
- OR +
as well as
F and A
and
- OR +

High-fire position **P9** can only be set when symbol ▲ or ▼ is no longer highlighted. If required, readjust the gas pressure.

For fuel, keep F depressed, for air, A, as well as for VSD F and A

Press - or + to adjust the value. As soon as symbol ▲ or ▼ is no longer highlighted, the next curvepoint P8 can be selected with -.

After setting the high-fire point (P9), either a change to parameter 546 (automatic operation) can be made (Esc) or all curvepoints can be run through in the reverse order. If the gas pressure is changed, all curvepoints must be checked and – if required – readjusted.

The maximum capacity is displayed. If the display shows - - - -, the maximum capacity has not yet been specified. The system can be run up to 100%.

You can press to go to editing mode, enabling you to change the maximum capacity.




To the next parameter

The minimum capacity is displayed. If the display shows - - - -, the minimum capacity has not yet been entered. The system can be run down to 20%.

You can press to go to editing mode, enabling you to change the minimum capacity.

Completing parameterization of the curve


Back to the previous parameter



The “warm settings“ for air-fuel ratio control by the LMV37.4... are now completed.

26.11.5 Warm settings for modulating mode («G mod pneu», «Gp1 mod pneu» and «Gp2 mod pneu»)



Note
Refer to subsection *Warm settings for modulating mode («G mod», «Gp1 mod», «Gp2 mod» and «Lo mod»)*! Here, only the air must be adjusted with .


26.11.6 Cold settings for «G mod», «Gp1 mod», «Gp2 mod» and «Lo mod»



Note
Refer to subsection *Warm settings for modulating mode («G mod», «Gp1 mod», «Gp2 mod» and «Lo mod»)*! With no flame, however, no actuator travel and no automatic operation after the settings have been made.

26.11.7 Cold settings for «G mod pneu», «Gp1 mod pneu» and «Gp2 mod pneu»



Note
Refer to subsection *Warm settings for modulating mode («G mod», «Gp1 mod», «Gp2 mod» and «Lo mod»)*! With no flame, however, no actuator travel and no automatic operation after the settings have been made. Here, only the air must be adjusted with .

26.11.8 Editing the curvepoints





Note

To check the change on the burner, a curvepoint change in the cold settings necessitates a new approach of all curvepoints in the warm settings. After changing the curvepoint, **OFF UPR** appears on the normal display of the AZL2...

To the next curvepoint		or		To select the curvepoint
				The selected curvepoint is displayed.
				Keep depressed. The fuel actuator has been selected for editing.
				Keep depressed and press or to adjust the fuel actuator. In the case of "warm settings", the actuator follows directly the adjustments made. The changes are saved.
				After releasing , the curvepoint is selected again.
				Keep depressed. The air actuator has been selected for editing.
				Keep depressed and press or to adjust the air actuator. In the case of "warm settings", the actuator follows directly the adjustments made. The changes are saved.
				After releasing , the curvepoint is selected again.
To the next curvepoint				Back to the previous curvepoint

26.11.9 Interpolating the curvepoints






Identification of start for setting the curve parameters.




Example 1 = gas modulating

P0, P1 and P9 are set as described:	Curvepoint	Value 1 fuel	Value 2 air
	P0	30.0	22.0
	P1	32.0	24.0
	P9	80.0	90.0

P2 through P8 have automatically been calculated:	Curvepoint	Value 1 fuel	Value 2 air
	P2	38.0	32.3
	P3	44.0	40.5
	P4	50.0	48.8
	P5	56.0	57
	P6	62.0	65.3
	P8	74.0	81.8



P5 shall now be changed:



Keep **F** or **A** depressed.

Example: **F**

Press **-** or **+** to change the value as required.

Example: 50.0

F and A
and
- or +

Press or to change the value as required.
 Example: **00.0**

F or A

Release .
 The required value is adopted.
 Example: **P5:50.0:46.0**

+
>3 s

Keep depressed for >3 s.
CALC appears.

The display jumps to **P6**.

All curvepoints from **P5** to **P9** have now been automatically recalculated (linear interpolation):

Curvepoint	Value 1 fuel	Value 2 air
P5	50.0	46.0
P6	57.5	57.0
P7	65.0	68.0
P8	72.0	79.0
P9	80.0	90.0

-
>3 s

Keep depressed for >3 s.
CALC appears.

The display jumps to **P4**.

All curvepoints from **P1** to **P5** have now been automatically recalculated (linear interpolation):

Curvepoint	Value 1 fuel	Value 2 air
P5	50.0	46.0
P4	45.5	40.0
P3	41.0	35.0
P2	36.5	29.5
P1	32.0	24.0



If it is not only the current curvepoint that shall be changed but all other curvepoints in the direction of travel as well, a new straight line from the current curvepoint to **P9** (press +) or **P1** (press -) can be calculated by a long push on - or + .

Display **CALC**

Example of presentation




Figure 63: Changing several curvepoints



Note

Due to interpolation, a number of curvepoints change. To be able to make a check on the burner itself, the changed curvepoints must be approached in the warm settings. If these curvepoints have not yet been completely approached, **OFF UPR** appears on the normal display of the AZL2...

26.11.10 Setting the curvepoints for multistage mode («Lo 2-stage» and «Lo 3-stage»)

Example of «Lo 2-stage»

		<p>P0 appears flashing.</p> <p>Curvepoint for ignition load.</p>
		<p>Keep depressed.</p> <p>You are now at P0 of air actuator A.</p>
		<p>Press simultaneously and or to adjust ignition position P0 of the air actuator.</p> <p>Example: 20.0</p>
		<p>Keep and depressed.</p> <p>You are now at n0 of the VSD.</p>
		<p>Press simultaneously and and or to adjust speed n0 of the VSD.</p> <p>Example: 20.0</p>
		<p>Now, release .</p> <p>The selected value is adopted.</p> <p>Example: 20.0</p>
		<p>Identification of start for setting the curve parameters.</p>




Note









You are now given the choice of proceeding with the "warm settings" by pressing











reset (refer to subsection *Warm settings for modulating mode «G mod», «Gp1 mod»,*


«Gp2 mod» and «Lo mod»), or with the "cold settings" by pressing  **- +** (refer to subsection *Cold settings for «G mod», «Gp1 mod», «Gp1 mod», «Gp2 mod» and «Lo mod»*).

26.11.11 Warm settings for «Lo 2-stage» and «Lo 3-stage»

		<p>Identification of start for setting the curve parameters.</p>
 		<p>Provided the controller is enabled!</p>
		<p>Phase <i>Standby</i> (stationary)</p>
		<p>Phase <i>Fan ramp up</i> (fan motor = ON, safety valve = ON)</p>
		<p>Phase <i>Traveling to prepurge position</i></p>
		<p>Phase <i>Prepurging</i></p>
		<p>Phase <i>Traveling to ignition position</i></p>

Wait until the burner is in operation and symbol ▲ or ▼ is no longer highlighted!
 The startup sequence stops in phase 36 *Traveling to ignition position*.
 The ignition position can be adjusted under "cold" conditions.

		<p>Ignition position P0 can be set only when symbol ▲ or ▼ is no longer highlighted.</p> <p>Keep  depressed and, for VSD,  and .</p> <p>Press  or  to adjust the value.</p> <p>As soon as symbol ▲ or ▼ is no longer highlighted, the next curvepoint P1 can be selected with  + .</p>
---	---	--




Phase *Traveling to ignition position*

Phase *Preignition*

Phase *1st safety time (ignition transformer ON)*

Phase *Interval 1*




P0.00:20.00

Ignition position **P0** can be set only when symbol ▲ or ▼ is no longer highlighted.

Keep **A** depressed and, for VSD, **F** and **A**.

Press **-** or **+** to adjust the value.

As soon as symbol ▲ or ▼ is no longer highlighted, the next curvepoint **P1** can be selected with **+**.



○
A
and

- or +
as well as

○ ○
F and **A**
and

- or +

Low-fire position **P1** can be set only when symbol ▲ or ▼ is no longer highlighted.

Set stage 1 **P1**.

Fuel valve **V1** is switched on.

Keep ○ **A** depressed and, for VSD, ○ **F** and ○ **A**.

Press - or + to adjust the value.

As soon as symbol ▲ or ▼ is no longer highlighted, the next curvepoint **P2on** can be selected with +.

To the next curvepoint ▶
+

○
A
and

- or +
as well as

○ ○
F and **A**
and

- or +

Curvepoint **P2on** can be set only when symbol ▲ or ▼ is no longer highlighted.

Set switch-on point stage 2 **P2**.

Fuel valve **V2** is still off.

Keep ○ **A** depressed and, for VSD, ○ **F** and ○ **A**.

Adjust the value with - or +.

As soon as symbol ▲ or ▼ is no longer highlighted, the next curvepoint **P2_d** can be selected with +.

To the next curvepoint ▶
+ ◀
- Back to the previous curvepoint

○
A
and

- or +
as well as

○ ○
F and **A**
and

- or +

Curvepoint **P2_d** can be set only when symbol ▲ or ▼ is no longer highlighted.

Fuel valve **V2** is still off and the system remains at curvepoint **P2on**. Presetting of operating stage **P2** with no travel, aimed at cutting the operating time if there is shortage of air.

Keep ○ **A** depressed and, for VSD, ○ **F** and ○ **A**.



Press - or + to adjust the value.

As soon as symbol ▲ or ▼ is no longer highlighted, the next curvepoint **P2** can be selected with -.

To the next curvepoint



Back to the previous curvepoint



Curvepoint **P2** can only be adjusted when symbol ▲ or ▼ is no longer highlighted.

Fuel valve **V2** is switched on.

Keep **A** depressed and, for VSD, **F** and **A**.

Press **-** or **+** to adjust the value.

As soon as symbol ▲ or ▼ is no longer highlighted, the next curvepoint **P2of** can be selected with **-**.

Back to the previous curvepoint



Curvepoint **P2of** is now adjusted.


The system remains at P2.

Adjust the switch-off point with no travel.


Now, the curvepoint is approached dynamically when traveling from **P2** to **P1**.

As soon as symbol ▲ or ▼ is no longer highlighted, the next curvepoint **P1** can be selected with **-**.

To the next curvepoint





Back to the previous curvepoint




Automatic mode is released when, after reaching **P1**, the curve settings are quit with **Esc**.

If the settings are aborted earlier (**Esc** or shutdown due to fault), start prevention **OFF UPr** is still active until all curvepoints are set.




As soon as symbol ▲ or ▼ is no longer highlighted, **Esc** can be pressed a second time.



The "warm settings" for air-fuel ratio control of the LMV37.4... have now been configured.

26.11.12 Cold settings for multistage mode («Lo 2-stage» and «Lo 3-stage»)

 **Note**
Refer to subsection *Warm settings for «Lo 2-stage» and «Lo 3-stage»!* But with no flame, no traveling of the actuators and no automatic operation after the settings has been made.

27 Parameter list LMV37.4...

Par. no.	Parameter	Number of elements	Type	Edit	Value range		Resolution	Default setting	Password level
					Min	Max			
000	Internal parameters								
041	Password heating engineer (4 characters)	1	Std_u16	edit	0	65535	1		OEM
042	OEM password (5 characters)	1	Std_u16	edit	0	65535	1		OEM
050	Start backup / restore via AZL2.../ PC tool (set parameter to 1) Index 0: Create backup Index 1: Execute restore Error diagnostics via negative values (see error code 137)	2	Std_s8	edit	-99	2	1	0; 0	SO
055	Burner identification of AZL2... backup data set	1	Std_s32	read only	0	99999999	1	0	SO
056	ASN extraction of AZL2... backup data set	8	Std_u8	read only	0	127	1	0	SO
057	Software version when creating the AZL2... backup data set	1	Hex_16	read only	0x100	0xFFF9	1	0	SO

Par. no.	Parameter	Number of elements	Type	Edit	Value range		Resolution	Default setting	Password level
					Min	Max			
100	General								
102	Identification date	1	Date	read only	0	255	1		Info / Service
103	Identification number	1	Std_u16	read only	0	65535	1		Info / Service
104	Preselected parameter set: Customer code	1	Std_u8	read only	0	255	1	9	Info / Service
105	Preselected parameter set: Version	1	Hex_16	read only	0	0xFFFF	1	LMV37.400...: V 01.04 LMV37.420...: V 01.05	Info / Service
107	Software version	1	Hex_16	read only	0x100	0xFFF9	1	V 03.10	Info / Service
108	Software variant	1	Std_u8	read only	0	255	1	1	Info / Service
111	ASN extraction for verification with the AZL2... backup data set	8	Std_u8	read only	0	127	1	0	SO
113	Burner identification	1	Std_s32	edit	0	99999999	1	undefined	Info / Service Password level write: SO
121	Manual output Undefined = automatic mode	1	Output	edit / clear	0%	100%	0.1%	undefined	Info / Service
123	Minimum output positioning step Index 0: BACS output Index 1: Output of external load controller, analog Index 2: Output of external load controller contacts	3	Output	edit	0 %	100 %	0.1 %	0 %; 1 %; 0 %	SO
124	Start loss-of-flame test (TÜV test) (set parameter to 1) (shutdown of fuel valves → loss of flame) Error diagnostics via negative values (see error code 150)	1	Std_s8	edit	-6	1	1	0	SO
125	Mains frequency 0 = 50 Hz 1 = 60 Hz	1	Selection	edit	0	1	1	LMV37.400...: 0 LMV37.420...: 1	SO
126	Display brightness	1	Std_u8	edit	0%	100%	1%	LMV37.400...: 75 % LMV37.420...: 100 %	SO
127	Timeout for menu operation	1	Std_u8	edit	10 min	120 min	1 min	LMV37.400...: 30 min LMV37.420...: 60min	OEM
128	Fuel meter: Pulse valency [pulses / volumetric flow unit]	1	Std_u16	edit	0	400	0.01	0	SO

Par. no.	Parameter	Number of elements	Type	Edit	Value range		Resolution	Default setting	Password level
					Min	Max			
130	Delete display of error history To delete the display. Set parameter to 1, then to 2 Return value 0: Job successfully completed Return value -1: Timeout of 1 2 sequence	1	Std_s8	edit	-5	2	1	0	SO
133	Default output for TÜV test Invalid = TÜV test when output is active 2.000...10.000 = low-fire...high-fire or stage 1 / stage 2 / stage 3	1	Output	edit / clear	20 %	100 %	0.1 %	undefined	SO
141	Operating mode BACS 0 = off 1 = Modbus 2 = reserved	1	Selection	edit	0	2	1	0	SO
142	Setback time in the event of communication breakdown Setting values 0 = inactive 1...7200 s	1	Std_u16	edit	0 s	7200 s	1 s	600 s	SO (BA)
143	Reserved	1	Std_u8	edit	1	8	1	1	Info / Service
144	Reserved	1	Std_u16	edit	10 s	60 s	1 s	30 s	SO
145	Device address for Modbus of basic unit Setting values 1...247	1	Std_u8	edit	1	247	1	1	SO
146	Setting of Baud rate for Modbus communication Setting values 0 = 9600 1 = 19200	1	Selection	edit	0	1	1	1	SO
147	Parity for Modbus 0 = none 1 = odd 2 = even	1	Selection	edit	0	2	1	0	SO

Par. no.	Parameter	Number of elements	Type	Edit	Value range		Resolution	Default setting	Password level
					Min	Max			
148	Performance standard at interruption of communication with building automation Setting values For modulation operation the setting range is as follows: 0...19.9 = burner off 20...100 = 20...100% burner rating For multistage operation apply to setting range: 0 = burner OFF, P1, P2, P3 Invalid = no performance standards of the building automation Default setting: <i>Invalid</i>	1	Output	edit / clear	0%	100%	0.1%	undefined	SO (BA)
161	Number of faults	1	Std_u16	read only	0	65535	1	0	Info / Service
162	Operating hours resettable	1	Std_s32	reset	0 h	9999999 h	1 h	0 h	Info / Service
163	Operating hours when unit is live	1	Std_s32	read only	0 h	9999999 h	1 h	0 h	Info / Service
164	Number of startups resettable	1	Std_s32	reset	0	9999999	1	0	Info / Service
166	Total number of startups	1	Std_s32	read only	0	9999999	1	0	Info / Service
167	Fuel volume resettable [m ³ , l, ft ³ , gal]	1	Std_s32	reset	0	99999999	1	0	Info / Service
186	Software drop out delay of flame signal (100 ms) Index = = QRB... / QRC... (0 = inactive, >1) Index 1 = ION / QRA... (0 = inactive, >3 - only 200 ms-steps)	2	Std_u8	edit	0	20	1	0; 0	OEM

Par. no.	Parameter	Number of elements	Type	Edit	Value range		Resolution	Default setting	Password level
					Min	Max			
200	Basic unit								
201	Burner operating mode (fuel train, modulating / multi-stage, actuators, etc.) -- = undefined (delete curves) 1 = G mod 2 = Gp1 mod 3 = Gp2 mod 4 = Lo mod 5 = Lo 2-stage 6 = Lo 3-stage 7 = G mod pneu 8 = Gp1 mod pneu 9 = Gp2 mod pneu 10 = LoGp mod 11 = LoGp 2-stage 12 = Lo mod 2 fuel valves 13 = LoGp mod 2 fuel valves 14 = G mod pneu without actuator 15 = Gp1 mod pneu without actuator 16 = Gp2 mod pneu without actuator 17 = Lo 2-stage without actuator 18 = Lo 3-stage without actuator 19 = G mod only gas actuator 20 = Gp1 mod only gas actuator 21 = Gp2 mod only gas actuator 22 = Lo mod only oil actuator	1	Selection	edit / clear	1	22	1	undefined	SO
205	Function of load controller contacts, staged 0 = standard 1 = stages interchanged	1	Std_u8	edit	0	1	1	0	OEM
208	Program stop 0 = deactivated 1 = PrePurgP (Ph24) 2 = IgnitPos (Ph36) 3 = Interval 1 (Ph44) 4 = Interval 2 (Ph52)	1	Selection	edit	0	4	1	0	SO (BA)

Par. no.	Parameter	Number of elements	Type	Edit	Value range		Resolution	Default setting	Password level
					Min	Max			
210	Alarm in the event of start prevention 0 = deactivated 1 = activated	1	Selection	edit	0	1	1	LMV37.400...: 0 LMV37.420...: 1	SO
211	Fan ramp up time	1	Time	edit	2 s	60 s	0.2 s	2 s	SO
212	Max. time down to low-fire	1	Time	edit	0.2 s	10 min	0.2 s	45 s	SO
213	Waiting time home run	1	Time	edit	2 s	60 s	0.2 s	2 s	OEM
214	Max. time start release	1	Time	edit	0.2 s	10 min	0.2 s	LMV37.400...: 25 s LMV37.420...: 35 s	OEM
215	Repetition limit safety loop 1 = no repetition 2...15 = number of repetitions 16 = constant repetition	1	Std_u8	edit	1	16	1	LMV37.400...: 16 LMV37.420...: 1	SO
217	Max. waiting time for detection of a detector or pressure switch signal (e.g. home run, preignition)	1	Time	edit	5 s	10 min	0.2 s	30 s	OEM
221	Gas: Active detector flame evaluation 0 = QRB / QRC 1 = ION / QRA	1	Selection	edit	0	1	1	1	SO
222	Gas: Prepurging 0 = deactivated 1 = activated	1	Selection	edit	0	1	1	1	SO
223	Repetition limit pressure switch-min-gas 1 = no repetition 2...15 = number of repetitions 16 = constant repetition	1	Std_u8	edit	1	16	1	LMV37.400...: 16 LMV37.420...: 1	SO
225	Gas: Prepurge time	1	Time	edit	20 s	60 min	0.2 s	LMV37.400...: 20 s LMV37.420...: 30 s	SO
226	Gas: Preignition time	1	Time	edit	0.4 s	60 min	0.2 s	2 s	SO
227	Gas: Safety time 1 (TSA1)	1	Time	edit	1 s	10 s	0.2 s	LMV37.400...: 3 s LMV37.420...: 5 s	OEM
229	Gas: Time to respond to pressure faults in safety time 1 (TSA1) and safety time 2 (TSA2)	1	Time	edit	0.4 s	9.6 s	0.2 s	1.8 s	OEM
230	Gas: Interval 1	1	Time	edit	0.4 s	60 s	0.2 s	2 s	SO

Par. no.	Parameter	Number of elements	Type	Edit	Value range		Resolution	Default setting	Password level
					Min	Max			
231	Gas: Safety time 2 (TSA2)	1	Time	edit	1 s	10 s	0.2 s	LMV37.400...: 3 s LMV37.420...: 7 s	OEM
232	Gas: Interval 2	1	Time	edit	0.4 s	60 s	0.2 s	2 s	SO
233	Gas: Afterburn time	1	Time	edit	0.2 s	60 s	0.2 s	8 s	SO
234	Gas: Postpurge time (no extraneous light test)	1	Time	edit	0.2 s	108 min	0.2 s	LMV37.400...: 0,2 s LMV37.420...: 15 s	SO
236	Gas: Pressure switch-min input 0 = inactive 1 = pressure switch-min (upstream of fuel valve 1 (V1)) 2 = valve proving via pressure switch-min (between fuel valves 1 (V1) and 2 (V2))	1	Selection	edit	1	2	1	1	SO
237	Gas: Pressure switch-max / POC input 0 = inactive 1 = pressure switch-max 2 = POC	1	Selection	edit	1	2	1	LMV37.400...: 1 LMV37.420...: 2	SO
239	Gas: Forced intermittent operation 0 = inactive 1 = activated	1	Selection	edit	0	1	1	1	SO
240	Repetition limit loss of flame 1 = no repetition 2 = 1 repetition	1	Std_u8	edit	1	2	1	LMV37.400...: 2 LMV37.420...: 1	OEM
241	Gas: Execution valve proving 0 = no valve proving 1 = valve proving on startup 2 = valve proving on shutdown 3 = valve proving on startup and shutdown	1	Selection	edit	0	3	1	LMV37.400...: 2 LMV37.420...: 0	SO
242	Gas: Valve proving evacuation time	1	Time	edit	0.2 s	10 s	0.2 s	3 s	OEM
243	Gas: Valve proving time atmospheric pressure	1	Time	edit	0.2 s	60 s	0.2 s	10 s	OEM
244	Gas: Valve proving filling time	1	Time	edit	0.2 s	10 s	0.2 s	3 s	OEM
245	Gas: Valve proving time gas pressure	1	Time	edit	0.2 s	60 s	0.2 s	10 s	OEM
246	Gas: Waiting time gas shortage	1	Time	edit	0.2 s	60 s	0.2 s	10 s	OEM
248	Gas: Postpurge time (t3) (abortion with load controller (LR)-ON	1	Time	edit	1 s	108 min	0.2 s	1 s	SO

Par. no.	Parameter	Number of elements	Type	Edit	Value range		Resolution	Default setting	Password level
					Min	Max			
261	Oil: Active detector flame evaluation 0 = QRB / QRC 1 = ION / QRA	1	Selection	edit	0	1	1	LMV37.400....: 0 LMV37.420....: 1	SO
262	Oil: Prepurging 0 = inactive 1 = active	1	Selection	edit	0	1	1	1	OEM
265	Oil: Prepurge time	1	Time	edit	15 s	60 min	0.2 s	LMV37.400....: 15 s LMV37.420....: 30 s	SO
266	Oil: Preignition time	1	Time	edit	0.6 s	60 min	0.2 s	2 s	SO
267	Oil: Safety time 1 (TSA1)	1	Time	edit	1 s	15 s	0.2 s	5 s	OEM
269	Oil: Time to respond to pressure faults in safety time 1 (TSA1) and safety time 2 (TSA2)	1	Time	edit	0.4 s	14.6 s	0.2 s	1.8 s	OEM
270	Oil: Interval 1	1	Time	edit	0.4 s	60 min	0.2 s	2 s	SO
271	Oil: Safety time 2 (TSA2)	1	Time	edit	1 s	15 s	0.2 s	LMV37.400....: 5 s LMV37.420....: 10 s	OEM
272	Oil: Interval 2	1	Time	edit	0.4 s	60 min	0.2 s	2 s	SO
273	Oil: Afterburn time	1	Time	edit	0.2 s	60 s	0.2 s	8 s	SO
274	Oil: Postpurge time (no extraneous light test)	1	Time	edit	0.2 s	108 min	0.2 s	LMV37.400....: 0,2 s LMV37.420....: 15 s	SO
276	Oil: Pressure switch-min input 0 = inactive 1 = active from phase 38 2 = active from safety time (TSA)	1	Selection	edit	1	2	1	1	'SO
277	Oil: Pressure switch-max- / POC input 0 = inactive 1 = Pressure switch-max 2 = POC	1	Selection	edit	1	2	1	1	SO
279	Oil: Forced intermittent operation 0 = inactive 1 = active	1	Selection	edit	0	1	1	1	SO
280	Repetition limit value loss of flame 1 = no repetition 2 = 1 repetition	1	Std_u8	edit	1	2	1	LMV37.400....: 2 LMV37.420....: 1	OEM

Par. no.	Parameter	Number of elements	Type	Edit	Value range		Resolution	Default setting	Password level
					Min	Max			
281	Oil: Time oil ignition 0 = short preignition (Ph38) 1 = long preignition (with fan) (Ph22)	1	Selection	edit	0	1	1	LMV37.400...: 1 LMV37.420...: 0	SO
284	Oil: Postpurge time (t3) (abortion with load controller (LR)-ON)	1	Time	edit	1 s	108 min	0.2 s	1 s	SO
400 Ratio curves									
401	Ratio control curve fuel actuator (only curve settings)	13	Std_s16	edit	0 °	90 °	0.1 °	0 °; 0 °; 15 °; undefined	SO
402	Ratio control curve air actuator (only curve settings)	13	Std_s16	edit	0 °	90 °	0.1 °	0 °; 90 °; 45 °; undefined	SO
403	Ratio control curve VSD (only curve settings)	13	Std_s16	edit	20%	100%	0.1%	0%; 100%; 50%; undefined	SO

Par. no.	Parameter	Number of elements	Type	Edit	Value range		Resolution	Default setting	Password level
					Min	Max			
500	Ratio control								
501	No-flame positions fuel actuator Index 0 = no-load position Index 1 = prepurge position Index 2 = postpurge position	3	Std_s16	edit	0 °	90 °	0.1 °	0 °; 0 °; 15 °	SO
502	No-flame positions air actuator Index 0 = no-load position Index 1 = prepurge position Index 2 = postpurge position	3	Std_s16	edit	0 °	90 °	0.1 °	0 °; 90 °; 45 °	SO
503	No-flame speeds VSD Index 0 = no-load speed Index 1 = prepurge speed Index 2 = postpurge speed	3	Std_s16	edit	0%	100%	0.1%	0%; 100%; 50%	SO
522	Ramp up	1	Std_u8	edit	5 s	20 s	1 s	10 s	SO
523	Ramp down	1	Std_u8	edit	5 s	20 s	1 s	10 s	SO
542	Activation of VSD / PWM fan 0 = inactive 1 = active	1	Selection	edit	0	1	1	0	SO
545	Lower output limit undefined = 20 %	1	Output	edit / clear	20%	100%	0.1%	undefined	SO (BA)
546	Upper output limit undefined = 100 %	1	Output	edit / clear	20%	100%	0.1%	undefined	SO (BA)

Par. no.	Parameter	Number of elements	Type	Edit	Value range		Resolution	Default setting	Password level
					Min	Max			
600	Actuators								
601	Selection of reference point Index 0 = fuel Index 1 = air 0 = closed (<0°) 1 = open (>90°)	2	Selection	edit	0	1	1	1; 0	OEM
602	Actuator's direction of rotation Index 0 = fuel Index 1 = air 0 = counterclockwise 1 = clockwise (exclusively for SQM3...)	2	Selection	edit	0	1	1	0; 0	OEM
606	Tolerance limit of position monitoring [0.1°] Index 0 = fuel Index 1 = air Greatest position error where a fault is securely detected → Error detection band: (P606-0.6°) to P606	2	Std_u8	edit	0.5 °	4°	0.1 °	1.7 °; 1.7 °	SO Password level write: OEM
611	Type of referencing Index 0 = fuel Index 1 = air 0 = standard 1 = stop within usable range 2 = internal stop (SQN1...) 3 = both	2	Std_u8	edit	0	3	1	0; 0	OEM
641	Control of speed standardization of VSD Error diagnostics of negative values (refer to error code 82) 0 = no speed standardization 1 = speed standardization active	1	Std_s8	edit	-25	1	1	0	SO
642	Standardized speed Index 0 = speed 1 Index 1 = speed 2 (internal supervision)	2	Std_u16	read only	650	6500	0.1	undefined	SO
645	Configuration of analog output 0 = DC 0...10 V 1 = DC 2...10 V 2 = DC 0/2...10V	1	Std_u8	edit	0	2	1	0	SO

Par. no.	Parameter	Number of elements	Type	Edit	Value range		Resolution	Default setting	Password level
					Min	Max			
700	Error history								
701	Error history: 701-725.01.Code	25	Std_u8	read only	0	255	1	0	Info / Service
•	Error history: 701-725.02.Diagnostic code	25	Std_u8	read only	0	255	1	0	Info / Service
•	Error history: 701-725.03.Error class	25	Std_u8	read only	0	6	1	0	Info / Service
•	Error history: 701-725.04.Phase	25	Std_u8	read only	0	255	1	0	Info / Service
•	Error history: 701-725.05.Startup counter	25	Std_s32	read only	0	99999999	1	0	Info / Service
725	Error history: 701-725.06.Output	25	Output	read only	0%	100%	0.1%	0%	Info / Service

Par. no.	Parameter	Number of elements	Type	Edit	Value range		Resolution	Default setting	Password level
					Min	Max			
900	Process data								
903	Current output Index 0 = fuel Index 1 = air	2	Output	read only	0%	100%	0.1%	0%	Info / Service
922	Incremental position of actuators Index 0 = fuel Index 1 = air	2	Std_s16	read only	-50°	150°	0.01°	0°	Info / Service
935	Absolute speed	1	Std_u16	read only	0	6553.5	0.1	0	SO
936	Standardized speed	1	Std_s16	read only	-200%	200%	0.1%	0%	Info / Service
942	Active heat source 1 = output during curve settings 2 = manual output 3 = output preselected via BACS 4 = output preselected via analog input 5 = external load controller via contacts	1	Selection	read only	0	255	1	0	SO
947	Result of contact sensing (bit-coded) Bit 0.0 = 1: Pressure switch-min Bit 0.1 = 2: Pressure switch-max Bit 0.2 = 4: Pressure switch valve proving Bit 0.3 = 8: Pressure switch air pressure switch Bit 0.4 = 16: Load controller OPEN Bit 0.5 = 32: Load controller ON Bit 0.6 = 64: Load controller CLOSED Bit 0.7 = 128: Safety loop Bit 1.0 = 1: Safety valve Bit 1.1 = 2: Ignition Bit 1.2 = 4: Fuel valve 1 Bit 1.3 = 8: Fuel valve 2 Bit 1.4 = 16: Fuel valve 3 / pilot valve Bit 1.5 = 32: Reset	2	Std_u8	read only	0	255	1	0	Info / Service

Par. no.	Parameter	Number of elements	Type	Edit	Value range		Resolution	Default setting	Password level
					Min	Max			
950	Required relay state (bit-coded) Bit 0 = 1: Alarm Bit 1 = 2: Safety valve Bit 2 = 4: Ignition Bit 3 = 8: Fuel valve 1 Bit 4 = 16: Fuel valve 2 Bit 5 = 32: Fuel valve 3 / pilot valve	1	Std_u8	read only	0	255	1	0	Info / Service
954	Intensity of flame	1	Std_u8	read only	0%	100%	1%	0%	Info / Service
960	Actual flow rate (m³/h, l/h, ft³/h, gal/h)	1	Std_u16	read only	0	6553.5	0.1	0	Info / Service
961	Phase (state for external modules and display)	1	Std_u8	read only	0	255	1	0	Info / Service
981	Error memory: Code	1	Std_u8	read only	0	255	1	0	Info / Service
982	Error memory: Diagnostic code	1	Std_u8	read only	0	255	1	0	Info / Service
992	Error flags	10	Hex_32	reset	0	0xFFFFFFFF	1	0	SO

Legend

Std_u8 8 bit integer, not signed
Std_u16 16 bit integer, not signed
Std_u32 32 bit integer, not signed
Std_s8 8 bit integer, signed



Note
This data type is also used to mark an invalid or non-signed value by using the value of -1!

Std_s16 16 Bit integer, signed



Note
This data type is also used to mark an invalid or non-signed value by using the value of -1!

Std_s32 32 Bit integer, signed



Note
This data type is also used to mark an invalid or non-signed value by using the value of -1!

28 Error code list

Error code	Diagnostic code	Meaning for LMV37.4... system	Recommended measures
no Comm		No communication between LMV37.4... basic unit and AZL2...	Check wiring for open-circuit / loose contact
2	#	No flame at the end of the safety time (TSA)	
	1	<i>No flame at the end of safety time 1 (TSA1)</i>	
	2	<i>No flame at the end of safety time 2 (TSA2)</i>	
3	#	Air pressure failure	
	0	<i>Air pressure off</i>	
	1	<i>Air pressure on</i>	
	4	<i>Air pressure on – start prevention</i>	
4	#	Extraneous light	
	0	<i>Extraneous light during startup</i>	
	1	<i>Extraneous light during shutdown</i>	
	2	<i>Extraneous light during startup – start prevention</i>	
7	#	Loss of flame	
	0	<i>Loss of flame</i>	
	3	<i>Loss of flame (software version \leq V02.00)</i>	
	3...255	<i>Loss of flame during TÜV test</i>	Diagnostics covers the period of time from shutdown of the fuel valves to the point in time loss of flame is detected (resolution 0.2 s → value 5 = 1 s)
12	#	Valve proving	
	0	<i>Fuel valve 1 (V1) leaking</i>	Check to see if valve on the gas side is leaking Check to see if there is an open-circuit
	1	<i>Fuel valve 2 (V2) leaking</i>	Check to see if valve on the burner side is leaking Check to see if pressure switch for the valve proving is closed when gas pressure is present Check wiring to see if there is a short-circuit
14	#	POC	
	0	<i>POC open</i>	Check to see if the valve's closing contact is closed
	1	<i>POC closed</i>	Check wiring Check to see if the valve's closing contact opens when valve is controlled
	64	<i>POC open – prevention of startup</i>	Check wiring to see if there is an open-circuit. Check to see if the valve's closing contact is closed

Error code	Diagnostic code	Meaning for LMV37.4... system	Recommended measures
20	#	Pressure switch-min (Pmin)	
	0	<i>No minimum gas /oil pressure</i>	Check wiring for open-circuit
	1	<i>Gas shortage – start prevention</i>	Check wiring for open-circuit
21	#	Pressure switch-max (Pmax) / POC	
	0	Pressure switch-max (Pmax): Max. gas / oil pressure exceeded POC: POC open (<i>software version ≤ V02.00</i>)	Check wiring to see if there is an open-circuit. POC: Check to see if the valve's closing contact is closed.
	1	<i>POC closed (software version ≤ V02.00)</i>	Check wiring. Check to see if the valve's closing contact opens when the valve is controlled.
	64	<i>POC open – start prevention (software version ≤ V02.00)</i>	Check wiring. Check whether valve's make contact opens when valve is controlled
22 OFF S	#	Safety loop / burner flange	
	0	<i>Safety loop / burner flange open</i>	
	1	<i>Safety loop / burner flange open – start prevention</i>	
50	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
51	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
55	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
56	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
57	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
58	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
60	0	<i>Internal error: No valid output source</i>	Make a reset; if error occurs repeatedly, replace the unit
65	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
66	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
67	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
70	#	Error air-fuel ratio control: Position calculation modulating	
	23	<i>Output invalid</i>	No valid output
	26	<i>Curvepoints undefined</i>	Adjust the curvepoints for all actuators
71	#	Special position undefined	
	0	<i>No-load position</i>	Parameterize the no-load position for all actuators used
	1	<i>Prepurge position</i>	Parameterize the prepurge position for all actuators used
	2	<i>Postpurge position</i>	Parameterize the postpurge position for all actuators used
	3	<i>Ignition position</i>	Parameterize the ignition position for all actuators used
72	#	Internal error air-fuel ratio control	Make a reset; if error occurs repeatedly, replace the unit

Error code	Diagnostic code	Meaning for LMV37.4... system	Recommended measures
73	#	Internal error air-fuel control: Position calculation multistep	
	23	<i>Output invalid</i>	No valid output
	26	<i>Curvepoints undefined</i>	Adjust the curvepoints for all actuators
75	#	Internal error air-fuel ratio control: Data clocking check	
	1	<i>Current output different</i>	
	2	<i>Target output different</i>	
	4	<i>Target positions different</i>	
	16	<i>Different positions reached</i>	Can be caused by different standardized speeds (e.g. after restore of data set) when the VSD is activated → standardize again and check adjustment of the air-fuel ratio control system
76	#	Internal error air-fuel ratio control	Make a reset; if error occurs repeatedly, replace the unit
80	#	Control range limitation of VSD	Basic unit could not correct the difference in speed and reached a control range limit. 1. Basic unit is not standardized for this motor → repeat standardization. Caution! Settings of air-fuel ratio control must be checked! 2. Ramp time settings of the VSD are not shorter than those of the basic unit (parameters 522, 523). 3. Characteristic of the VSD is not linear. Configuration of the voltage input at the VSD must accord with that of the basic unit (parameter 645). 4. VSD does not follow quickly enough the changes of the basic unit. Check settings of the VSD (input filter, slippage compensation, hiding different speeds)
	1	<i>Control range limitation at the bottom</i>	VSD speed was too high
	2	<i>Control range limitation at the top</i>	VSD speed was too low
81	1	<i>Interrupt limitation speed input</i>	Too much electromagnetic interference on the sensor line → improve EMC

Error code	Diagnostic code	Meaning for LMV37.4... system	Recommended measures
82	#	Error during VSD's speed standardization	
	1	<i>Timeout of standardization (VSD ramp down time too long)</i>	Timeout at the end of standardization during ramp down of the VSD 1. Ramp time settings of the VSD are not shorter than those of the basic unit (parameter: 523)
	2	<i>Storage of standardized speed not successful</i>	Error during storage of the standardized speed → lock the basic unit, then reset it and repeat the standardization
	3	<i>Open-circuit speed sensor</i>	Basic unit receives no pulses from the speed sensor: 1. Motor does not turn. 2. Speed sensor is not connected. 3. Speed sensor is not activated by the sensor disk (check distance)
	4	<i>Speed variation / VSD ramp up time too long / speed below minimum limit for standardization</i>	Motor has not reached a stable speed after ramp up. 1. Ramp time settings of the VSD are not shorter than those of the basic unit (parameters 522, 523). 2. Characteristic of the VSD is not linear. Configuration of the voltage input at the VSD must accord with that of the basic unit (parameter 645). 3. VSD does not follow quickly enough the changes of the basic unit. Check settings of the VSD (input filter, slippage compensation, hiding different speeds) 4. Speed of VSD lies below the minimum for standardization (650 1/min)
	5	<i>Wrong direction of rotation</i>	Motor's direction of rotation is wrong. 1. Motor turns indeed in the wrong direction → change parameterization of the direction of rotation or interchange 2 live conductors. 2. Sensor disk is fitted the wrong way → turn the sensor disk.
	6	<i>Unplausible speed sensor signals</i>	The required pulse pattern (60°, 120°, 180°) has not been correctly identified. 1. Speed sensor does not detect all tappets of the sensor disk → check distance 2. As the motor turns, other metal parts are detected also, in addition to the tappets → improve mounting. 3. Electromagnetic interference on the sensor lines → check cable routing, improve EMC
	7	<i>Invalid standardized speed</i>	The standardized speed measured does not lie in the permissible range. 1. Motor turns too slowly or too fast.
	15	<i>Speed deviation $\mu C1 + \mu C2$</i>	The speeds of microcomputer 1 and 2 deviated too much. This can be caused by wrong standardized speeds (e.g. after restoring a data set to a new unit) → repeat standardization and check the air-fuel ratio
	20	<i>Wrong phase of phase manager</i>	Standardization was made in a wrong phase. Permitted are only phases ≤ 12 → controller OFF, start standardization again

Error code	Diagnostic code	Meaning for LMV37.4... system	Recommended measures
	21	<i>Safety loop / burner flange open</i>	Safety loop or burner flange is open → repeat standardization with safety loop closed
	22	<i>Air actuator not referenced</i>	Air actuator has not been referenced or has lost its referencing. 1. Check if the reference position can be approached. 2. Check if actuators have been mixed up. 3. If error only occurs after the start of standardization, the actuator might be overloaded and cannot reach its destination.
	23	<i>VSD deactivated</i>	Standardization was started with VSD deactivated → activate the VSD and repeat standardization
	24	<i>No valid operation mode</i>	Standardization was started without valid operation mode → activate valid operation mode and repeat standardization
	128	<i>Running command with no preceding standardization</i>	VSD is controlled but not standardized → make standardization
	255	<i>No standardized speed available</i>	Motor turns but is not standardized → make standardization

Error code	Diagnostic code	Meaning for LMV37.4... system	Recommended measures
83	#	Speed error VSD	Required speed has not been reached
	Bit 0 Valency 1	Lower control range limitation	Speed has not been reached because control range limitation has become active → for measures, refer to error code 80
	Bit 1 Valency 2...3	Upper control range limitation	Speed has not been reached because control range limitation has become active → for measures, refer to error code 80
	Bit 2 Valency 4...7	Interrupt shutdown due to electromagnetic interference	Speed has not been reached due to too much electromagnetic interference on the sensor line → for measures, refer to error code 81
	Bit 3 Valency ≥ 8	Curve too steep in terms of ramp speed	Speed has not been reached because detected curve slope was too steep. 1. With a LMV3... ramp of 20 s, the curve's slope may be a maximum of 10% speed change between 2 curvepoints in modulating mode. With a LMV3... ramp of 10 s, the curve's slope may be a maximum of 20% speed change between 2 curvepoints in modulating mode. With a LMV3... ramp of 5 s, the curve's slope may be a maximum of 40% speed change between 2 curvepoints in modulating mode. → Between the ignition point (P0) and the low-fire point (P1), the speed change in modulating mode may be a maximum of 40%, independent of the LMV3... ramp. 2. The setting of the VSD ramp must be about 20% faster than the ramps in the basic unit (parameters 522, 523).
	Bit 4 Valency ≥ 16	Interruption of speed signal	No speed detected in spite of control. 1. Check if the motor turns. 2. Check if the speed sensor delivers a signal (LED / check distance from the sensor disk). 3. Check wiring of the VSD.
	Bit 5 Valency ≥ 32	Quick shutdown due to excessive speed deviation	Speed deviation was for about 1 s >10% outside the anticipated range. 1. Check ramp times of the LMV37.4... and VSD. 2. Check wiring of the VSD.

Error code	Diagnostic code	Meaning for LMV37.4... system	Recommended measures
84	#	Curve slope actuators	
	Bit 0 Valency 1	VSD: Curve too steep in terms of ramp speed	<p>1. The curve's slope may be a maximum of 10% speed change between 2 curvepoints in modulating operation, with a LMV3... ramp of 20 seconds</p> <p>The curve's slope may be a maximum of 20% speed change between 2 curvepoints in modulating operation, with a LMV3... ramp of 10 seconds</p> <p>The curve's slope may be a maximum of 40% speed change between 2 curvepoints in modulating operation, with a LMV3... ramp of 5 seconds</p> <p>→ Between the ignition point (P0) and the low-fire point (P1), the speed change in modulating mode may be a maximum of 40%, independent of the LMV3... ramp.</p> <p>2. Setting of the VSD ramp must be about 20% shorter than the ramps in the basic unit (parameters 522 and 523)</p>
	Bit 1 Valency 2..3	Fuel actuator: Curve too steep in terms of ramp rate	The slope of the curve may be a maximum position change of 31° between 2 curvepoints in modulating mode
	Bit 2 Valency 4..7	Air actuator: Curve too steep in terms of ramp rate	The slope of the curve may be a maximum position change of 31° between 2 curvepoints in modulating mode
85	#	Referencing error ones actuators	
	0	Referencing error of fuel actuator	<p>Referencing of fuel actuator not successful. Reference point could not be reached.</p> <p>1. Check to see if actuators have been mixed up</p> <p>2. Check to see if actuator is locked or overloaded</p>
	1	Referencing error of air actuator	<p>Referencing of fuel actuator not successful Reference point could not be reached.</p> <p>1. Check to see if actuators have been mixed up</p> <p>2. Check to see if actuator is locked or overloaded</p>
	Bit 7 Valency ≥ 128	Referencing error due to parameter change	<p>Parameterization of an actuator (e.g. the reference position) has been changed. To trigger new referencing, this error is set</p>
86	#	Error fuel actuator	
	0	Position error	<p>Target position could not be reached within the required tolerance band.</p> <p>1. Check to see if actuator is locked or overloaded.</p>
	Bit 0 Valency 1	Open-circuit	<p>Open-circuit detected at the actuator's terminals.</p> <p>1. Check wiring (voltage X54 across pin 5 or 6 and pin 2 >0.5 V).</p>
	Bit 3 Valency ≥ 8	Curve too steep in terms of ramp rate	The slope of the curve may be a maximum position change of 31° between 2 curvepoints in modulating mode
	Bit 4 Valency ≥ 16	Step deviation in comparison with last referencing	<p>Actuator was overloaded or mechanically twisted.</p> <p>1. Check to see if the actuator is blocked somewhere along its working range.</p> <p>2. Check to see if the torque is sufficient for the application.</p>

Error code	Diagnostic code	Meaning for LMV37.4... system	Recommended measures
87	#	Error air actuator	
	0	Position error	Target position could not be reached within the required tolerance band. 1. Check to see if actuator is locked or overloaded.
	Bit 0 Valency 1	Open-circuit	Open-circuit detected at the actuator's terminals. 1. Check wiring (voltage X53 across pin 5 or 6 and pin 2 >0.5 V).
	Bit 3 Valency ≥ 8	Curve too steep in terms of ramp rate	The slope of the curve may be a maximum position change of 31° between 2 curvepoints in modulating mode
	Bit 4 Valency ≥ 16	Sectional deviation in comparison with last referencing	Actuator was overloaded or mechanically twisted. 1. Check to see if the actuator is blocked somewhere along its working range. 2. Check to see if the torque is sufficient for the application.
90	#	Internal error basic unit	
91	#	Internal error basic unit	
93	#	Error flame signal acquisition	
	3	Short-circuit of sensor	Short-circuit at QRB... 1. Check wiring. 2. Flame detector possibly fault.
95	#	Error relay supervision	
	3 Ignition transformer 4 Fuel valve 1 5 Fuel valve 2 6 Fuel valve 3	External power supply active contact	Check wiring
96	#	Error relay supervision	
	3 Ignition transformer 4 Fuel valve 1 5 Fuel valve 2 6 Fuel valve 3	Relay contacts have welded	Test the contacts: 1. Unit connected to power: Fan output must be dead. 2. Disconnect power: Disconnect fan. No resistive connection between fan output and neutral conductor allowed. If one of the 2 tests fails, release the unit since contact have definitively welded and safety can no longer be ensured.
97	#	Error relay supervision	
	0	Safety relay contacts have welded or external power supply fed to safety relay	Test the contacts: 1. Unit connected to power: Fan output must be dead. 2. Disconnect power: Disconnect fan. No resistive connection between fan output and neutral conductor allowed. If one of the 2 tests fails, release the unit since contacts have definitively welded and safety can no longer be ensured.

Error code	Diagnostic code	Meaning for LMV37.4... system	Recommended measures
98	#	Error relay supervision	
	2 Safety valve 3 Ignition transformer 4 Fuel valve 1 5 Fuel valve 2 6 Fuel valve 3	Relay does not pull in	Make a reset; if error occurs repeatedly, replace the unit
99	#	Internal error relay control	Make a reset; if error occurs repeatedly, replace the unit
100	#	Internal error relay control	Make a reset; if error occurs repeatedly, replace the unit
105	#	Internal error contact sampling	
	0 Pressure switch min 1 Pressure switch max / POC 2 Pressure switch valve proving 3 Air pressure 4 Load controller open 5 Load controller on / off 6 Load controller closed 7 Safety loop / Burner flange 8 Safety valve 9 Ignition transformer 10 Fuel valve 1 11 Fuel valve 2 12 Fuel valve 3 13 Reset	Stuck-At failure	Can be caused by capacitive loads or supply of DC voltage to the mains voltage inputs. The diagnostic code indicates the input where the problem occurred
106	#	Internal error contact request	Make a reset; if error occurs repeatedly, replace the unit
107	#	Internal error contact request	Make a reset; if error occurs repeatedly, replace the unit
108	#	Internal error contact request	Make a reset; if error occurs repeatedly, replace the unit
110	#	Internal error voltage monitor test	Make a reset; if error occurs repeatedly, replace the unit
111	#	Mains undervoltage	Mains voltage to low Conversion factor diagnostic code → voltage value (AC 230 V: 1,683; AC 120 V: 0,843)
112	0	Mains voltage recovery	Error code for triggering a reset on power restoration (no error)
113	#	Internal error mains voltage supervision	Make a reset; if error occurs repeatedly, replace the unit
115	#	Internal error system counter	
116	0	Designed lifecycle exceeded (250,000 startups)	Warning threshold has been reached. The unit should be replaced
117	0	Life time exceeded Operation no longer allowed	Switch-off threshold has been reached

Error code	Diagnostic code	Meaning for LMV37.4... system	Recommended measures
120	0	<i>Interrupt limitation fuel counter input</i>	Too many disturbance pulses at the fuel meters input → Improve EMC
121	#	Internal error EEPROM access	Make a reset, repeat last parameterization / check. Restore the parameter set, if error occurs repeatedly, replace the unit
122	#	Internal error EEPROM access	Make a reset, repeat last parameterization / check. Restore the parameter set, if error occurs repeatedly, replace the unit
123	#	Internal error EEPROM access	Make a reset, repeat last parameterization / check. Restore the parameter set, if error occurs repeatedly, replace the unit
124	#	Internal error EEPROM access	Make a reset, repeat last parameterization / check. Restore the parameter set, if error occurs repeatedly, replace the unit
125	#	Internal error EEPROM read access	Make a reset, repeat last parameterization / check. If error occurs repeatedly, replace the unit
126	#	Internal error EEPROM write access	Make a reset, repeat last parameterization / check. If error occurs repeatedly, replace the unit
127	#	Internal error EEPROM access	Make a reset, repeat last parameterization / check. Restore the parameter set, if error occurs repeatedly, replace the unit
128	0	<i>Internal error EEPROM access - synchronization during initialization</i>	Make a reset; if error occurs repeatedly, replace the unit
129	#	Internal error EEPROM access – command synchronization	Make a reset, repeat last parameterization / check. If error occurs repeatedly, replace the unit
130	#	Internal error EEPROM access - timeout	Make a reset, repeat last parameterization / check. If error occurs repeatedly, replace the unit
131	#	Internal error EEPROM access - page on abort	Make a reset, repeat last parameterization / check. If error occurs repeatedly, replace the unit
132	#	Internal error EEPROM register initialization	Make a reset; if error occurs repeatedly, replace the unit
133	#	Internal error EEPROM access – Request synchronization	Make a reset, repeat last parameterization / check. If error occurs repeatedly, replace the unit
134	#	Internal error EEPROM access – Request synchronization	Make a reset, repeat last parameterization / check. If error occurs repeatedly, replace the unit
135	#	Internal error EEPROM access – Request synchronization	Make a reset, repeat last parameterization / check. If error occurs repeatedly, replace the unit
136	1	<i>Restore started</i>	Restore of a backup has been started (no error)

Error code	Diagnostic code	Meaning for LMV37.4... system	Recommended measures
137	#	Internal error – backup / restore	
	157 (-99)	<i>Restore – ok, but backup < data set of current system</i>	Restore successful, but backup data set is smaller than in the current system
	239 (-17)	<i>Backup – storage of backup in AZL2... faulty</i>	Make reset and repeat backup
	240 (-16)	<i>Restore – no backup in AZL2...</i>	No backup in AZL2...
	241 (-15)	<i>Restore – interruption concerning unpassable ASN</i>	<i>The Backup has a unpassable ASN and may not restore of the unit</i>
	242 (-14)	<i>Backup – backup made is inconsistent</i>	Backup is faulty and cannot be transferred back
	243 (-13)	<i>Backup – data comparison between μCs faulty</i>	Repeat reset and backup
	244 (-12)	<i>Backup data are incompatible</i>	Backup data are incompatible with the current software version, restore not possible
	245 (-11)	<i>Access error to parameter Restore_ Complete</i>	Repeat reset and backup
	246 (-10)	<i>Restore – timeout when storing in EEPROM</i>	Repeat reset and backup
	247 (-9)	<i>Data received are inconsistent</i>	Backup data set invalid, restore not possible
	248 (-8)	<i>Restore cannot at present be made</i>	Repeat reset and backup
	249 (-7)	<i>Restore – abortion due to unsuitable burner identification</i>	Backup has an unsuitable burner identification and must not be transferred to the unit
	250 (-6)	<i>Backup – CRC of one page is not correct</i>	Backup data set invalid, restore not possible
	251 (-5)	<i>Backup – burner identification is not defined</i>	Define burner identification and repeat backup
	252 (-4)	<i>After restore, pages still on ABORT</i>	Repeat reset and backup
	253 (-3)	<i>Restore cannot at present be made</i>	Repeat reset and backup
	254 (-2)	<i>Abortion due to transmission error</i>	Repeat reset and backup
	255 (-1)	<i>Abortion due to timeout during restore</i>	Make a reset, check the connections and repeat the backup
146	#	Timeout building automation interface	Refer to User Documentation Modbus (A7541)
	1	<i>Modbus timeout</i>	

Error code	Diagnostic code	Meaning for LMV37.4... system	Recommended measures
150	#	TÜV test	
	1 (-1)	<i>Invalid phase</i>	TÜV test may only be started in phase 60 (operation)
	2 (-2)	<i>TÜV test default output too low</i>	TÜV test default output must be lower than the lower output limit
	3 (-3)	<i>TÜV test default output too high</i>	TÜV test default output must be higher than the upper output limit
	4 (-4)	<i>Manual abortion</i>	No error: Manual abortion of TÜV test by the user
	5 (-5)	<i>TÜV test timeout</i>	No loss of flame after fuel valves have been shut 1. Check for extraneous light 2. Check wiring for short-circuit 3. Check to see if one of the valves is leaking
165	#	Internal error	
166	0	<i>Internal error watchdog reset</i>	
167	#	Manual locking	Unit has been manually locked (no error)
	1	<i>Manual locking by contact</i>	
	2	<i>Manual locking by AZL2...</i>	
	3	<i>Manual locking by PC tool</i>	
	8	<i>Manual locking by the AZL2... Timeout / communication breakdown</i>	During a curve adjustment via the AZL2..., the timeout for menu operation has elapsed (setting via parameter 127), or communication between the LMV37.4... and the AZL2... has broken down
	9	<i>Manual locking by the PC tool Communication breakdown</i>	During a curve adjustment via the ACS410, communication between the LMV37.4... and the ACS410 was interrupted for more than 30 seconds
	33	<i>Manual locking after PC tool reset attempt</i>	PC tool made a reset attempt although the system worked correctly
168	#	Internal error management	Make a reset; if error occurs repeatedly, replace the unit
169	#	Internal error management	Make a reset; if error occurs repeatedly, replace the unit
170	#	Internal error management	Make a reset; if error occurs repeatedly, replace the unit
171	#	Internal error management	Make a reset; if error occurs repeatedly, replace the unit
200 OFF	#	System error-free	No error
201 OFF UPr	#	Start prevention	Start prevention because unit has not been parameterized
	1	<i>No operating mode selected</i>	
	2..3	<i>No fuel train defined</i>	
	4..7	<i>No curves defined</i>	
	8..15	<i>Standardized speed undefined</i>	
	16..31	<i>Backup / restore was not possible</i>	

Error code	Diagnostic code	Meaning for LMV37.4... system	Recommended measures
202	#	Internal error operating mode selection	Redefine the operating mode (parameter 201)
203	#	Internal error	Redefine the operating mode (parameter 201). Make a reset; if error occurs repeatedly, replace the unit
204	Phase number	Program stop	Program stop is active (no error)
205	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
206	0	<i>Inadmissible combination of units (basic unit - AZL2...)</i>	
207	#	Version compatibility basic unit - AZL2...	
	0	<i>Basic unit version too old</i>	
	1	<i>AZL2... version too old</i>	
208	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
209	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
210	0	<i>Selected operation mode is not released for the basic unit</i>	Select a released operation mode for the basic unit
240	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
245	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit
250	#	Internal error	Make a reset; if error occurs repeatedly, replace the unit

29 Revision history of basic unit LMV37.4...

Software changes

Software version V01.20

- Optimizations regarding ACS410 (backup / restore)
- Faster parameterization with AZL2... (3-stage)
- Burner identification setting (entering the password)
- Optimization "System hooks itself up in phase 38"
- Optimization "Cold setting via P0" (adoption P0 → P1, correct CALC function)
- Optimization "Delete history" (acknowledgement upon completion)
- Prepurging oil – activated / deactivated (parameter 262) for OEM level released
- Setting range of pulse valency fuel meter (parameter 128) increased to 400 pulses per volume unit
- New parameter 645 = configuration analog output

Software version V01.30

- Optimization of phase manager (rectification of error 107)
- Presetting of parameter 281 (time oil ignition) changed to long preignition (with fan)

Software version V01.40

- Optimization: Modbus mode and operating mode are maintained when a reset is made
- Extension: Additional Modbus addresses (refer to Modbus Documentation A7541)
- Extension: Actuator tolerance can be parameterized by OEM and read by the heating engineer
- Change: The heating engineer can set the time when valve proving takes place
- Extension: Calculation of fuel throughput
- Optimization: Plausibility check for continuous operation with ionization amplifier
- Optimization: Separate diagnostic code in the event standardization has not been successful due to an undefined operating mode
- Optimization: Change of password without having to enter the currently valid password
- Extension: Restore of data set possible only when type references of basic unit and data set are identical
- Optimization: Alarm in the event of start prevention after a fixed time of 5 seconds
- Extension: Selection of POC function or Pmax

Software version V01.60

- Optimization: Filtering of analog power output
- Optimization: Plausibility check of ionization amplifier revised

Software version V01.70

Optimization: Final test sequence revised

Software version V01.80

- Optimization: Valve proving during shutdown after display error in operation
- Optimization: Any valve proving aborted by Pmin during shutdown is repeated with the next startup

Software version V01.90

- Scaling of analog input changed (no *burner OFF* functionality)
- Optimization: Variable step width between ignition and low-fire (40% difference in speed, independent of ramp time; traveling time varies between 4 and 16 seconds with a 5- to 20-second ramp)
- Optimization: Checking the standardized speed between microcomputer 1 and microcomputer 2 (wrong standardized speeds after restore)
Objective: Avoiding wrong standardized speeds after restore to new hardware resulting from resonator tolerances of the 2 microcomputers
- Revision of standardization of VSD signal in terms of control and evaluation of errors
- Optimization: Curve adjustment with pneumatic air-fuel ratio control. Here, the curve can be adjusted with no need for making the standardization beforehand of VSD
- Optimization: Parameter access when firing on oil
- Optimization: Assessment of *Pmin* in phase 62

Software version V2.00

- Correction to fuel train Gp1: Safety time 1 was up to 0.4 seconds too long
- Correction to fuel train Gp1: Evaluation of pressure switches in phases 40 to 50 (Pmin / Pmax were not valued in phase 44, Pmin / Pmax were evaluated in phase 50 although the main valve was switched on)
- First error reception for gas shortage with first setting (gas shortage error was exceeded with first setting of *OFF UPr* – both errors occur in the same cycle)
- Timeout (parameter 127) or communication breakdown with the AZL2... leads to lockout during the time the curves are set (error code: 167, diagnostics: 8)
→ with cold setting, no startup on completion of the password time
- Communication breakdown with the ACS410 (30 seconds) leads to lockout during the time the curves are set (error code: 167, diagnostics 9)

Software version V02.90

- Optimization: Indication of errors on the parameter and info / service menu
- Optimization: Rectification of eBus error telegrams, correction of manufacturer's code for safety limit thermostat, extension of service data interrogation PB:03h SB:10h by the meter readings of the second fuel, PB:05h SB:09h shows the fuel currently burnt
- Optimization: Curve setting invalid (OFF Upr) upon change to cold settings
- Optimization: Setting of minimum / maximum output via the parameterized output
- Optimization: Shorter startup time with valve proving (prepurge or postpurge time simultaneously with valve proving)
- New function: Loss-of-flame test (TÜV test), forced shutdown of fuel valves
- Extension: Pressure switch-min-oil active from phase 38 or safety time (phase 40)
- Extension: Setting of dead band zone for load controller contacts, analog input and BACS output
- Extension: POC for fired on oil (alternative to pressure switch-max)
- New function: Valve proving via pressure switch-min
- New function: Abortion of postpurging (see postpurge time, extraneous light test in phase 78)
- New function: Evaluation of load controller contacts for multistage operation (normal / interchanged)
- New fuel trains LOGp, LO-2V, LOGp-2V
- New operating modes (e.g. without actuator)
- New function: Backup / restore via AZL2... (only with new software version AZL2...)

Software version V03.00

- Optimization: Maximum time of safety phase reduced from 28 to 27 seconds

Software version V03.10

- Optimization: If power supply fails during the restore process, the data set can be repaired by starting a new restore process (since the backup / restore option is not yet available with V03.00 because there is no suitable AZL2..., this effect cannot occur)
- Optimization: When making a reset via the AZL2..., an *incomplete* reset occurred in very rare cases (display showed *RESEt*, but reset was not triggered)
- Optimization: The time ascertained by the loss-of-flame test was 0.2 seconds too long
- Optimization: Reduced detection of undervoltage when fan motor is started in phase 22 (when a single-phase motor and the LMV37.8... 120 V were powered via the same phase, undervoltage detection could occur on startup; in that case, the LMV37.8... system was not operated as specified)
- Optimization: Better overview through text changes of groups 200=PAr0, 300=PAr1 and 600=ACtr on the parameter menu (initially PArA), and hiding of unused parameters after selection of fuel train / operating mode
- Optimization: Control of the fan output during standardization (standby) for using a release contact via an external relay at the fan's output
- Optimization: Curve setting invalid (OFF UPr) after new / further standardization
- Optimization: To shorten the startup time, there is no referencing when postpurging is aborted via controller-ON (direct start)
- Automatic return travel of the SQN1... at the lower internal stop
- Parameter on Siemens level
Longer ignition off time during safety time 1 (TSA1) (increased from 0.4 to 0.6 seconds) to prevent wrong error diagnostics in connection with QRA2... (C:7 in place of C:2)

Index

Fehler! Keine Indexeinträge gefunden.

30 List of figures

Figure 1: Electrical connection.....	15
Figure 2: Ionization input at AC 120 V / AC 230 V	26
Figure 3: QRB... input at AC 120 V / AC 230 V	28
Figure 4: LMV37.4...: Dimension	29
Figure 5: Flame signal input X10-05	30
Figure 6: Flame signal input X10-06	30
Figure 7: Safety loop X3-04	34
Figure 8: Burner flange X3-03.....	35
Figure 9: Inputs for external load controller ON / OFF X5-03	35
Figure 10: Inputs external load controller Opening / Closing X5-03	35
Figure 11: Air pressure switch (APS) X3-02.....	36
Figure 12: Pressure switch valve proving gas (P LT) X9-04	37
Figure 13: Pressure switch-min-gas (Pmin) / -min-oil X5-01.....	38
Figure 14: Pressure switch-max-gas (Pmax) / -max-oil or POC X5-02.....	40
Figure 15: Reset X8-04	42
Figure 16: Output alarm X3-05	43
Figure 17: Fan motor contactor X3-05	43
Figure 18: Fan continuous purging X3-05.....	43
Figure 19: Output ignition (Z) X4-02.....	44
Figure 20: Output fuel valve (V1) X8-02	45
Figure 21: Output fuel valve (V2) X7-01	45
Figure 22: Output fuel valve (V3) / pilot valve (PV) X7-02.....	45
Figure 23: Output safety valve (SV) X6-03	45
Figure 24: Output for indication of operation X8-04	45
<i>Figure 25: Valve proving with separate pressure switch (P LT).....</i>	<i>48</i>
Figure 26: Valve proving via pressure switch-min-gas	49
<i>Figure 27: Message in the case of program stop.....</i>	<i>56</i>
Figure 28: Continuous fan.....	57
Figure 29: Program for gas direct ignition (G)	64
Figure 30: Program for gas pilot ignition (Gp1)	65
Figure 31: Program for gas pilot ignition (Gp2)	66
Figure 32: Program for light oil (LO).....	67
Figure 33: Modulating operation X5-03.....	71
Figure 34: 2-stage operation X5-03.....	72
Figure 35: 3-stage operation X5-03.....	72

Figure 36: Shifting multistage operation (OPEN ▲ terminal 3 / CLOSE ▼ terminal 2)	73
Figure 37: External load controller via analog input X64.1 / X64.2	76
Figure 38: Definition of curves	80
Figure 39: Restriction of modulation range	82
Figure 40: Adjustment of output	85
Figure 41: Actuator fuel (X54)	88
Figure 42: Actuator air (X53)	88
Figure 43: Angle definitions with SQM33	91
Figure 44: Direction of rotation (example SQM3...)	92
Figure 45: Function principle of VSD	96
<i>Figure 46: Connection of VSD to the LMV37.4</i>	97
Figure 47: Sensor disk	99
Figure 48: Speed sensor	100
Figure 49: VSD module X74	107
Figure 50: PWM fan X74	107
Figure 51: PWM fan X64	107
Figure 52: Fuel meter input X75	110
Figure 53: Inputs and outputs	112
Figure 54: Connection via interface COM 92 to superposed systems	113
Figure 55: Communication with display / BCI (RJ11 jack) (X56)	116
Figure 56: Display input / BCI (RJ11 jack) X56	116
Figure 57: Description of the unit / display and buttons	120
Figure 58: Meaning of display	121
Figure 59: Assignment of levels	134
Fig. 60: Info level	135
Figure 61: Service level	139
Figure 62: Setting the curvepoints	166
Figure 63: Changing several curvepoints	172