

Accessories and Spare Parts

ALT-A...
ALT-C...
ALT-R...

For thermostats RAK-..., RAZ-... and sensors

- Perforated protection pocket for air duct mounting
- Mounting kit
- Spare part accessory kit
- Adjustable mounting flange

Type summary


Type reference	Name	Use	Material	Immersion length [mm]	Inner dia. of pocket [mm]	Weight [kg]
ALT-AB200	Protection pocket, perforated, with coupling spring	Air duct mounting	Steel, galvanized	200	12	0.095

Type reference	Name	Contents	Use	Material	Weight [kg]
ALT-C001	Mounting kit	1 spring 200 mm	For fixing the sensing element inside the perforated protection pocket (to prevent noise caused by vibrations)	Steel	0.034
		1 clamping band 330 mm	For fitting the RAK to pipes	Steel, galvanized	
		4 clamps	Wall mounting: For securing the sensing element inside the protection pocket	Steel	
ALT-R001	Spare part accessory kit	2 setting knobs	For setpoint adjustments: RAK-TR, RAZ-TW, RAZ-ST	ABS+PC	0.040
		2 cable entry glands	For RAK-... and RAZ-..., consisting of: Sleeve, seal, strain relieve (M16 x 1.5)	ABS+PC rubber	
		4 covers for reset knob	For RAK-ST, RAK-TB, RAZ-ST	ABS+PC	
		3 screws with metal plate	For fixing the protection pocket (all types)	Steel	
		4 fixing screws for the cover	For all types of RAK-... and RAZ-...	Steel, galvanized	
		4 IP43 cover ¹⁾	For fitting to pipes	Plastic	
AQM63.0	Mounting accessories	1 mounting flange, adjustable	Suited for air ducts with up to 70 mm insulation	PA66GF35	0.038

1) Prior to fitting the thermostat on a pipe, the IP43 cover ist to be inserted in the capillary hole (12 mm dia.) in the thermostat's base. The prevents spray water from entering the thermostat.

Dimensions (in mm)

ALT-AB200



AQM63.0

